

## Sweep

The R&S SML /R&S SMV03 features digital, step-by-step sweep for the following parameters:

- RF frequency
- LF frequency
- RF level

A sweep is set in four basic steps, which are demonstrated by the following example, ie the setting of a frequency sweep:

1. Set sweep range (Start Freq and Stop Freq or Center Freq and Span).
2. Select linear or logarithmic sweep (Spacing).
3. Select step size (Step Lin or Step Log) and dwell time (Dwell).
4. Switch on sweep (Mode set to Auto, Single, Step, Ext Single or Ext Step).

### Setting the Sweep Range (Start Freq, Stop Freq, Center Freq, Span)

The sweep range for RF sweeps can be entered in two ways. Either the Start Freq and Stop Freq are entered or Center Freq and Span. Please note that the two parameter sets mutually affect each other as follows:

Start Freq altered:	Stop Freq	=	unaltered
	Center Freq	=	$(\text{Start Freq} + \text{Stop Freq})/2$
	Span	=	$(\text{Stop Freq} - \text{Start Freq})$
Stop Freq altered:	Start Freq	=	unaltered
	Center Freq	=	$(\text{Start Freq} + \text{Stop Freq})/2$
	Span	=	$(\text{Stop Freq} - \text{Start Freq})$
Center Freq altered:	Span	=	unaltered
	Start Freq	=	$(\text{Center Freq} - \text{Span}/2)$
	Stop Freq	=	$(\text{Center Freq} + \text{Span}/2)$
Span altered:	Center Freq	=	unaltered
	Start Freq	=	$(\text{Center Freq} - \text{Span}/2)$
	Stop Freq	=	$(\text{Center Freq} + \text{Span}/2)$

## Selecting Linear or Logarithmic Sweep (Spacing Lin, Log)

Linear or logarithmic sweep can be selected with Spacing. For RF and LF sweeps, both the linear and logarithmic modes are selectable. For level sweeps, only the logarithmic mode is possible.

With logarithmic sweeps, the step size (Step) is equal to a constant fraction of the current setting. The logarithmic step size for RF and LF sweeps is entered in % and for level sweeps in dB.

## Operating Modes (Mode)

The following sweep modes are available:

**Auto** Sweep from start point to stop point with automatic restart at start point. If another sweep mode was active prior to selection of the auto mode, the sweep is continued from the setting active at that time.

IEC/IEEE bus commands

RF sweep:

SOUR:FREQ:MODE SWE  
SOUR:SWE:MODE AUTO  
TRIG:SOUR AUTO

LF sweep:

SOUR2:FREQ:MODE SWE  
SOUR2:SWE:MODE AUTO  
TRIG2:SOUR AUTO

Level sweep:

SOUR:POW:MODE SWE  
SOUR:SWE:POW:MODE AUTO  
TRIG:SOUR AUTO

**Single** Single sweep from start point to stop point. The selection of Single does not start a sweep run. The sweep run is started by means of the Execute Single Sweep function, which is displayed below the Mode line.

IEC/IEEE bus commands

RF sweep:

SOUR:FREQ:MODE SWE  
SOUR:SWE:MODE AUTO  
TRIG:SOUR SING

LF sweep:

SOUR2:FREQ:MODE SWE  
SOUR2:SWE:MODE AUTO  
TRIG2:SOUR SING

Level sweep:

SOUR:POW:MODE SWE  
SOUR:SWE:POW:MODE AUTO  
TRIG:SOUR SING

**Step** Step-by-step, manual run within the sweep limits. Activating Step stops a running sweep and the cursor moves to the value indicated for Current. The sweep can now be controlled upwards or downwards in discrete steps using the rotary knob or the numeric keys.

IEC/IEEE-bus commands:

RF sweep:

SOUR:FREQ:MODE SWE  
SOUR:SWE:MODE STEP  
TRIG:SOUR SING

LF sweep:

SOUR2:FREQ:MODE SWE  
SOUR2:SWE:MODE STEP  
TRIG2:SOUR SING

Level sweep:

SOUR:POW:MODE SWE  
SOUR:SWE:POW:MODE STEP  
TRIG:SOUR SING

**Ext Single** Single sweep from start point to stop point as with Single, but triggered by an external signal

IEC/IEEE-bus commands:

RF sweep:

SOUR:FREQ:MODE SWE  
SOUR:SWE:MODE AUTO  
TRIG:SOUR EXT

LF sweep:

SOUR2:FREQ:MODE SWE  
SOUR2:SWE:MODE AUTO  
TRIG2:SOUR EXT

Level sweep:

SOUR:POW:MODE SWE  
SOUR:SWE:POW:MODE AUTO  
TRIG:SOUR EXT

**Ext Step** Step-by-step run controlled by an external trigger signal. Each trigger event triggers a single step.

IEC/IEEE-bus commands:

<b>RF sweep:</b>	<b>LF sweep:</b>	<b>Level sweep:</b>
SOUR:FREQ:MODE SWE	SOUR2:FREQ:MODE SWE	SOUR:POW:MODE SWE
SOUR:SWE:MODE STEP	SOUR2:SWE:MODE STEP	SOUR:SWE:POW:MODE STEP
TRIG:SOUR EXT	TRIG2:SOUR EXT	TRIG:SOUR EXT

**Off** Switching-off sweep mode.

IEC/IEEE-bus commands:

<b>RF sweep:</b>	<b>LF sweep:</b>	<b>Level sweep:</b>
SOUR:FREQ:MODE CW	SOUR2:FREQ:MODE CW	SOUR:POW:MODE CW

**Sweep Inputs**

**TRIGGER** An external signal at the rear input triggers the sweep in the Ext Single and Ext Step modes or stops the sweep in all modes.

**RUN**

Queries whether a sweep is being performed.

IEC/IEEE bus commands: **RF sweep:** SOUR:SWE:RUNN? **LF sweep:** SOUR2:SWE:RUNN? **Level sweep:** SOUR:SWE:POW:RUNN?

**Note:** This query may cause distortions in the course of the sweep, depending on the frequency of checkimng and dwell time.

**RF Sweep**

Settings for RF sweeps can be made in the Sweep - Freq menu.

Menu selection: Sweep – Freq

100.0000000 MHz		-10.0 dBm	
Sweep/Freq	RF On		
Start Freq	100.0000000 MHz		
Stop Freq	500.0000000 MHz		
Center Freq	300.0000000 MHz		
Span	400.0000000 MHz		
Current Freq	100.0000000 MHz		
Spacing	Lin		
Step Lin	1.0000000 MHz		
Dwell	15.0 ms		
Mode	Off		
Reset Sweep			
Back ↵			

Fig. 4-19 Sweep - Freq menu

<b>Start Freq</b>	Input value of start frequency. IEC/IEEE-bus command : SOUR:FREQ:STAR 100MHz
<b>Stop Freq</b>	Input value of stop frequency. IEC/IEEE-bus command : SOUR:FREQ:STOP 500MHz
<b>Center Freq</b>	Input value of center frequency. IEC/IEEE-bus command : SOUR:FREQ:CENT 300MHz
<b>Span</b>	Input value of span. IEC/IEEE-bus command : SOUR:FREQ:SPAN 400MHz
<b>Current Freq</b>	Display of current frequency value. In Step mode: input value of frequency.
<b>Spacing</b>	Selection of linear or logarithmic sweep. IEC/IEEE-bus command : SOUR:SWE:SPAC LIN
<b>Spacing Lin</b>	Input value of step size. Depending on whether Spacing Lin or Log is selected, Step Lin or Step Log is displayed. IEC/IEEE-bus command : SOUR:SWE:STEP:LIN 1MHz
<b>Dwell</b>	Input value of dwell time per step. IEC/IEEE-bus command : SOUR:SWE:DWEL 15ms
<b>Mode</b>	Selection of sweep mode. See section "Operating Modes". IEC/IEEE-bus commands : SOUR:FREQ:MODE SWE; : SOUR:SWE:MODE AUTO; : TRIG:SOUR SING
<b>Reset Sweep</b>	Resets the start frequency. IEC/IEEE-bus command : ABOR
<b>Exec Single Sweep</b>	Starts a single sweep. This function is displayed and is effective only if Single Mode is selected. IEC/IEEE-bus command : TRIG

### Level Sweep

Settings for level sweeps can be made in the Sweep - Level menu.

Menu selection: Sweep - Level



Fig. 4-20 Sweep - Level menu

<b>Start Level</b>	Input value of start level. IEC/IEEE-bus command : SOUR:POW:STAR -30dBm
<b>Stop Level</b>	Input value of stop level. IEC/IEEE-bus command : SOUR:POW:STOP -10dBm
<b>Current Level</b>	Display of current level. In Step mode: Input value of level.
<b>Step</b>	Input value of step width. IEC/IEEE-bus command : SOUR:SWE:POW:STEP 1dB
<b>Dwell</b>	Input value of dwell time per step. IEC/IEEE-bus command : SOUR:SWE:POW:DWEL 15ms
<b>Mode</b>	Selection of sweep mode (see "Operating Modes"). IEC/IEEE-bus command : SOUR:POW:MODE SWE; : SOUR:SWE:POW:MODE AUTO; :TRIG:SOUR SING
<b>Reset Sweep</b>	Sets the start level. IEC/IEEE-bus command : ABOR
<b>Exec Single Sweep</b>	Starts a single sweep. This function is displayed and is effective only if Single Mode is selected. IEC/IEEE-bus command : TRIG

## LF Sweep

Settings for LF sweeps can be made in the Sweep - LFGGen menu.

Menu selection: Sweep - LFGGen

100.000 000 MHz		-10.0 dBm	
Sweep/LFGGen		RF On	
Start Freq		1.0000 kHz	
Stop Freq		100.0000 kHz	
Current Freq		1.00000 kHz	
Spacing		Lin	
Step Lin		1.0000 kHz	
Dwell		15.0 ms	
Mode		Off	
Reset Sweep			
Back ↵			

Fig. 4-21 Sweep - LFGGen menu

<b>Start Freq</b>	Input value of start frequency. IEC/IEEE-bus command	: SOUR2:FREQ:STAR 1kHz
<b>Stop Freq</b>	Input value of stop frequency. IEC/IEEE-bus command	: SOUR2:FREQ:STOP 100kHz
<b>Current Freq</b>	Display of current frequency value. In Step mode: input value of frequency.	
<b>Spacing</b>	Selection of linear or logarithmic sweep. IEC/IEEE-bus command	: SOUR2:SWE:SPAC LIN
<b>Step Lin</b>	Input value of step size. IEC/IEEE-bus command	: SOUR2:SWE:STEP:LIN 1kHz
<b>Dwell</b>	Input value of dwell time per step. IEC/IEEE-bus command	: SOUR2:SWE:DWEL 15ms
<b>Mode</b>	Selection of sweep mode (see "Operating Modes"). IEC/IEEE-bus command	: SOUR2:FREQ:MODE SWE; : SOUR2:SWE:MODE AUTO; : TRIG2:SOUR SING
<b>Reset Sweep</b>	Sets the start frequency. IEC/IEEE-bus command	: ABOR
<b>Exec Single Sweep</b>	Starts a single sweep. This function is displayed and is effective only if Single Mode is selected. IEC/IEEE-bus command	: TRIG