





- Verify operational integrity of GPS receivers quickly
- Selectable Satellite Vehicle (SV) and Navigation (NAV) Data
- Adjustable RF levels from -85 dBm to -145 dBm in 1 dB steps
- Doppler control allows the operator to select a positive or negative carrier frequency shift of approximately 4 kHz
- Stored GPS Almanac with real time clock
- Direct connect to receiver or via antenna coupler
- Battery operated portability

Aeroflex is a leader in the design, manufacture and marketing of Avionics test systems.

The IFR GPS-101 Global Positioning Simulator provides accurate and repeatable testing of Global Positioning Satellite (GPS) receivers. The GPS-101 achieves this testing capability by simulating a Global Positioning Satellite and generating a specific Satellite Vehicle (SV) and Navigation (NAV) data pattern. Coupled with remotely loaded GPS almanac information and RF levels/frequency control, the GPS-101 provides a portable test solution for verifying the operational integrity of GPS systems. The GPS-101 verifies the operational integrity of:

- An integrated GPS receiver antenna system (e.g. a hand held unit) with built-in test modes accessible by transmitting special satellite (SV) numbers and navigational (NAV) data word that will cause an indication or received signal strength.
- An installed GPS receiver with remote antenna system.
- Any GPS receiver or installation capable of indicating that a single satellite with appropriate navigation data was detected.

## Operation

The GPS-101 provides dedicated front panel keys for all primary functions. Selected parameters are displayed on a wide viewing angle, high contrast, backlit LCD display.

## MODE KEYS

## **RF LVL**

The RF level can be adjusted from -85 to -145 dBm in 1 dB steps via slew wheel control to verify GPS.

## DPLR

The doppler control allows the operator to select a positive or negative carrier frequency shift of approximately 4 kHz to verify receiver acquisition and lock performance.

## SV

Selects the satellite vehicle to be simulated (1 through 37). The almanac data is utilized to display an asterisk alongside the selected satellite vehicle if the satellite is unhealthy or not available.

## **RF CONT**

The RF control selects the modulating source for the 1575.42 MHz

generator. The selections are RFOFF: turns carrier off, RFCW: unmodulated carrier, RFON: C/A code and NAV data (spread spectrum signal), RFEXT: external BPSK modulation through AUX I/O connector and RFSQR: 511.5 kHz square wave modulation (maintenance purposes).

### SETUP:

Provides access to menus for setting RS-232/422 communications port parameters, test set operational characteristics and self test.

### TEST:

Selects one of three stored NAV data patterns. (Three data patterns reserved for future use)

- T<sub>1</sub>: NAV data that contains programmable almanac information and GPS week and time of week fields. The almanac data is valid for a 30 day period and may be downloaded in 'YUMA' ASCII text format via the RS-232 port. Current almanac data is available from the U.S. Coastguard Internet Web Site. The GPS-101 has an internal real time clock that keeps UTC time and is programmable by the user.
- 2. T<sub>2</sub>: NAV data pattern that contains fixed GPS week and time of week.
- 3. T<sub>3</sub>: Fixed 11001100.. repeating test pattern.

Select Keys: Moves cursor to selected field/parameter.

Display Keys: Contrast setting keys and display backlight on/off key.

ESC Key: Returns to main operation screen.

Slew Wheel: Allows rapid data slewing.

## **SPECIFICATION**

#### GENERATOR

### Frequency

1575.42 MHz

#### Accuracy

Same as Master Timebase

#### Doppler

Selectable frequency offset ±4.0 kHz

#### **Offset Accuracy**

See Master Oscillator

#### Channels

Single SV simulation, selectable from 1 to 37

#### Phase Modulation

BPSK

#### PRN Code

C/A code = 1.023 MHz, 1023 bit gold code

#### NAV Data

50 Hz, Programmable test pattern, built-in patterns

#### **Output Level**

-85 to -145 dBm in 1 dB steps,  $\pm 2$  dB accuracy into 50  $\Omega$  (AC Coupled) Standard Cable, 4 dB loss

### Spurious

<-40 dBc over the bandwidth (20 MHz)

#### **External Modulation Input**

TTL

## MASTER OSCILLATOR

#### Standard Timebase

#### Frequency

10 MHz nominal (see note)

### **Temperature Stability**

±1 ppm

#### Ageing Rate

±1 ppm/yr, ±5 ppm/10 yr

Uncertainty

#### ±1 ppm

#### **Option Timebase**

Frequency

10 MHz nominal (see note)

### **Temperature Stability**

±0.1 ppm

### Ageing Rate

±0.1 ppm/yr

### Uncertainty

±0.1 ppm

Note: Internal timebase frequency is a function of timebase calibration, ageing rate, temperature stability and uncertainty.

### **External Reference Input**

#### Input Level

0.25 to 6.0 Vp-p

#### Input Impedance

150  $\Omega$  nominal

### Input Frequency

10.0 MHz

#### **External Reference Output**

**Output Level** 

1.5 Vp-p nominal into 50  $\Omega$ 

#### **Output Frequency**

10.0 MHz nominal

### COUPLER

## Coupling

-20 dB typical at 1575.42 MHz

### Assumes

4.77 dB patch antenna gain and 4 dB cable loss

### Isolation

>25 dB at 1575.42 MHz

>30 dB typical at 1575.42 MHz

### GENERAL

### **Calibration Interval**

1 year

#### AC Input

90 to 120 VAC, 50 to 400 Hz

200 to 240 VAC, 50 to 60 Hz

#### **Battery Operation Time**

120 minutes minimum, 360 minutes nominal

#### **AC Power Consumption**

<50 W maximum, <40 W typical

#### **Battery Charge Time**

#### Unit Operating

8 hours for full charge @ 115 VAC, 60 Hz

#### Unit non-operating

6 hours for full charge @ 115 VAC, 60 Hz

#### **Operating Temperature**

-20° to +55°C

### Storage Temperature

-20° to +70°C

### Humidity

95% (±5%), non-condensing

+10° to +30°C

### Dimensions

292 mm wide; 131 mm high; 412 mm deep, does not include handle. 11.4 in. wide; 5.1 in. high; 16.1 in. deep, does not include handle.

### Weight

9 kg (20 lbs.) maximum (with battery) does not include lid and lid contents

## **CONNECTOR TYPES**

### **RF Output**

TNC, Female

### Auxiliary Port

25-pin D-Sub, Male

## RS-232 "REMOTE" (COMM 1)

9-pin D-Sub, Male, PC compatible

### RS-232/422 "RECEIVER" (COMM 2)

25-PIN D-Sub, Male, PC compatible

FCC Type Accepted, CFR47 Part 87.

Complies with UL/CSA/EU Product Safety Standards

# VERSIONS AND ACCESSORIES

When ordering please quote the full ordering number information.

### **Ordering Numbers**

GPS-101 Global Positioning System Ramp Test Set, 110 VAC operation
GPS-101 Global Positioning System Ramp Test Set, 220 VAC operation
0.1 ppm High Stability Time Base

All Aeroflex Avionics products delivered with Factory Certificate of Calibration

#### CHINA Beijing

Tel: [+86] (10) 6467 2761 2716 Fax: [+86] (10) 6467 2821

CHINA Shanghai Tel: [+86] (21) 6282 8001 Fax: [+86] (21) 62828 8002

**FINLAND** Tel: [+358] (9) 2709 5541 Fax: [+358] (9) 804 2441

FRANCE Tel: [+33] 1 60 79 96 00 Fax: [+33] 1 60 77 69 22

As we are always seeking to improve our products, the information in this document gives only a general indication of the product capacity, performance and suitability, none of which shall form part of any contract. We reserve the right to make design changes without notice. All trademarks are acknowledged. Parent company Aeroflex, Inc. ©Aeroflex 2004.

GERMANY

Tel: [+49] 8131 2926-0 Fax: [+49] 8131 2926-130

HONG KONG Tel: [+852] 2832 7988 Fax: [+852] 2834 5364

INDIA Tel: [+91] 80 5115 4501 Fax: [+91] 80 5115 4502

KOREA Tel: [+82] (2) 3424 2719 Fax: [+82] (2) 3424 8620 SCANDINAVIA Tel: [+45] 9614 0045

Fax: [+45] 9614 0047 **SPAIN** Tel: [+34] (91) 640 11 34 Fax: [+34] (91) 640 06 40

**UK Burnham** Tel: [+44] (0) 1682 604455 Fax: [+44] (0) 1682 662017

#### UK Stevenage Tel: [+44] (0) 1438 742200

Fax: [+44] (0) 1438 727601 Freephone: 0800 282388 USA Tel: [+1] (316) 522 4981 Fax: [+1] (316) 522 1360 Toll Free: 800 835 2352





Our passion for performance is defined by three attributes represented by these three icons: solution-minded, performance-driven and customer-focused.

www.aeroflex.com

info-test@aeroflex.com

Part No. 46891/034, Issue 3, 08/03