Keysight Technologies eDP 1.4 Electrical Performance and Characterization Software For Infiniium Series Oscilloscopes

Data Sheet

eDP Provides a High-Speed, Bi-Directional Data Path Between the System Host and Display



Verify and debug your eDP designs more easily

Keysight Technologies eDP 1.4 electrical performance and characterization software for Infiniium Series oscilloscopes (see Table 2) provides you with a fast and easy way to verify and debug your eDP interface designs for embedded systems. The eDP 1.4 electrical test software is designed to be uniquely flexible to handle the wide variety of configurations that are possible in embedded systems and pose characterization challenges. It offers the standard tests that are recommended as well as other informative tests, so it functions equally well as a validation tool. It displays the measurement data results in a flexible report format, and the report also provides a margin analysis that shows how closely your device passed or failed each test.

To make measurements with the eDP 1.4 electrical performance and characterization (EP&C) software, you will also need an eDP TPA fixture for high-speed signal access as well as for AUX channel and other lines of the interface. Available fixtures are identified in Table 5.

The eDP 1.4 EP&C software is based broadly on the widely-industry-accepted Keysight DisplayPort application, which extends utility to include a wizard graphic user interface that enables test selection, parameter election, test specification entry, and test template sharing. These features are *unique* in the industry and are supported to enable ecosystem sharing of test process specifics for highly variant embedded designs.

There is no official interoperability program for eDP 1.4, though this software goes a long way to create a defacto program – if only for a specific product or family of products. The default specifications are those found in the VESA¹ test guideline eDP PHY CTG v1.0. The tests available in the eDP 1.4 EP&C software package are identified in Table 1. However, there is no limit to what tests you can have available with the Infiniium framework add-in feature, with which you can add your own tests or tests from colleagues to the test suite offered. Details of the add-in capability are covered in the *Extensibility* section below.

1. Video Electronics Standards Association (www.vesa.org)

Features

The eDP 1.4 electrical performance and characterization software offers new and unique capabilities as well as the standard features available with all Keysight Infiniium frame-work applications:

- Full physical layer testing of high-speed lanes and AUX channel
- Verification of link layer physical layer control
- Test status tracking
- Measurement process configurability
- Automated scope measurement setup
- Bit rate parameters: nominal value of bit rate, number of bit rates and test line limit for frequency accuracy
- Level parameters: nominal value of level, number of levels and test line limits for level accuracy or value of relative change between level settings
- Pre emphasis parameters: nominal value of pre-emphasis, number of pre-emphasis settings and test line limits for pre-emphasis accuracy or value of relative change between pre-emphasis settings
- Eye diagram mask testing: entry of arbitrary mask through mask files vs. bit rate
- Jitter testing: entry of arbitrary RJ, DJ, TJ values vs. bit rate
- Test plan creation: selection of device conditions to test
- Test template: create default templates for device types avoiding re-entry AND share complete test process setup with others for consistent settings for same process requirements in different locations
- Test results reports with pass/fail margin analysis
- Automation control through AUX channel controller

With the eDP 1.4 EP&C test software, you can finally solve the myriad of test issues that embedded test systems present with one application.

Easy test process definition

The eDP 1.4 electrical performance and characterization software extends the easeof-use advantages of Keysight's Infiniium Series oscilloscopes and previous DisplayPort standard test software to testing eDP 1.4 designs.

The application will guide you through device setup and test connection with setup wizards to capture all the test process details. In doing so, you will create a tailored process to validate or characterize your device and get exactly what you need.

Using the eDP 1.4 electrical performance and characterization software

The eDP application is started from the analyze tab in the Infiniium GUI. When selected and finished loading, the screen in Figure 1 is presented. This screen looks much like other applications in the Infiniium framework. Of particular note, after selecting the standard to test (eDP 1.4) and the test suite (High-Speed Physical Layer Tests) are the *Device Definition* and *Connection Setup* buttons.

These are selected in progression, *Device Definition* first and then *Connection Setup*. If the labels below these buttons are blue, you can test with the device definition defaults (determined by the template the user can set) and with the connections defined without any further manipulations. You can proceed to *Select Tests* tab to select tests you want to run for the test session and continue to running tests.



Figure 1. eDP 1.4 DisplayPort test environment setup.

Device definition

The *Device Definition* tab is where much of the eDP 1.4 EP&C software's power resides. When you click on the *Device Definition* button, you will see a sequence of windows for you to define your device's capabilities and the specifications for these. You can see in Figure 2 how much information is shown in the second tab, *Link Rate*.

| Device Definition Wizard |
|---|
| eDP Device Link Rate Level Eye Diagram Jitter Rise/Fall Time Inter Pair Skew Main Link And SSC Intra Pair S |
| Link Rate |
| Specification Limit Unit Type: O bps O ppm Number of Link Rates: 4 V |
| Link Rate 1 : 1.62 - Gbps 617.3 ps RBR Min: -5300 ppm Max: 300 ppm CTLE |
| Link Rate 2 : 2.7 🗸 Gbps 370.4 ps HBR Min: -5300 ppm Max: 300 ppm CTLE |
| Link Rate 3 : 3.24 🗸 Gbps 308.6 ps HBR2 Min: -5300 ppm Max: 300 ppm CTLE |
| Link Rate 4 : 5.4 🗸 Gbps 185.2 ps HBR2 Min: -5300 ppm Max: 300 ppm CTLE |
| |
| Spread Spectrum Clocking |
| Spread Spectrum Clocking State : Settable - |
| SSC Modulation Frequency 32 kHz Min: 30 kHz Max: 33 kHz |
| SSC Modulation Deviation -2500 ppm Min: -5000 ppm Max: 0 ppm |
| |
| |
| |
| << Back Next >> Close |

Figure 2. Link rate tab in Device Definition sequence.

First, note that the tabs across the top of the window cover not only the device capabilities such as link rate and level but also capture the details necessary for all the tests that can be conducted. (Example: For eye diagram testing, you can set the pattern at which to test as well as the mask file to be used.)

The fundamental issues for eDP 1.4 testing are addressed with this screen, and they are:

- The number of bit rates of which the device is capable,
- The nominal values of those bit rates,
- The manner to display the frequency accuracy of those bit rates: absolute error (bps) or ppm versus nominal link rate value. The minimum and maximum values are displayed for convenience.
- The CTLE (continuous time linear equalizer) attributes you want to use in the analysis measurements (eye diagram and jitter) to use for each bit rate. These are defaulted to the values in the eDP standard v1.0 but are easily alterable.

Finally, since spread spectrum clocking (SSC) is a favored technique in embedded systems to keep EMI low, the SSC tests parameters and specifications are selectable here. It can be set to 'Always On,' 'Always Off,' and 'Settable.'

When the entries for the *Link Rate* window are complete, you will press 'Next' and proceed to the *Eye Diagram* and *Jitter* tabs to complete the product and test requirements. Figure 3 shows attributes of the *Jitter* tab and, at the same time, illustrates a very useful construct called Test Plan.'



Figure 3. Jitter setup in the device definition sequence.

In the *Jitter* setup window, you will immediately see how comprehensive and flexible the software is. Firstly, it allows for all the link rates to be tested for jitter and allows for pattern type selection for the jitter measurement (selections are: PRBS7, HBR2CPAT, D10.2, random pattern). Then, you can enter the upper limits of jitter in the various components of jitter. Since the capability of your device includes different level settings and pre-emphasis settings, you might be interested in testing jitter for ALL combinations of these or just a few. By simply clicking the boxes in the *Test Plan Wizard*, you can select the device combinations to be tested.

When you have finished with the Jitter setup, you can save the setup as a template for the next time you test. Further, you can send this template to a colleague or partner so they can use the same setup, conditions and test line limits. You will see a blue label below the *Device Definition* button, and you can click on this to select another template. At this time you now click the *Connection Setup* button to enter the *Test Session* details: attributes of your work bench and test connection.



Figure 4. When finished with device setup, your specific template file is loaded.

Test session

The eDP 1.4 EP&C test session wizard is leveraged from the DisplayPort test software wizard. Its purpose is to identify the connection to the oscilloscope and enable selecting the scope of testing for your current test session – say because of troubleshooting. For example, though a device might be defined in the Device Definition wizard, to have 4 bit rates and 4 lanes, you might be interested in only one lane and the eye diagram of one bit rate for a given experiment or characterization. The session test sequence is four screens, the purpose of which is to specify connection to the oscilloscope and to select only what you need for your immediate test objectives.

Test Session Setup

The second screen of the test session sequence is the session test details screen, and it allows you to narrow in on a specific lane, bit rate or level for a focused characterization test. The screen is shown below:

| Test Session Setup | | |
|----------------------------|--------------------|--------------------------|
| Session Test Details | | |
| | | |
| Lane | Bit Rate | Spread Spectrum Clocking |
| O 1 Lane | Bit Rate 1 | SSC Enabled |
| ① 2 Lanes | Bit Rate 2 | SSC Disabled |
| C 4 Lanes | Bit Rate 3 | |
| | Bit Rate 4 | |
| | | |
| Differential Voltage Level | Pre-Emphasis Level | Post-Cursor2 Level |
| Swing 0 | ✓ Pre-emphasis 0 | Level 0 |
| Swing 1 | Pre-emphasis 1 | |
| Swing 2 | ✓ Pre-emphasis 2 | |
| Swing 3 | Pre-emphasis 3 | |
| | | |
| | | |
| | | |
| | [] | |
| | << Back | Next >> Close |
| | | |

Figure 5. eDP 1.4 session test details in setup.

You can select the specifics to test easily. For instance, if you just want to test 5.4 Gbs (bit rate 4), you would choose bit rate 4 and leave the other bit rates unselected. If you select all the bit rates for all the tests you selected in the test select tab, the software will run at all the bit rates you have selected.

The final screen in the test session setup sequence is the channel assignment setup. It will portray the connection expected in number of channels and type of connection requested. It is editable, and if there are channel assignment conflicts, the user is alerted to the fact. In a prior screen, you can select whether you want to use direct connection to the oscilloscope or connect with oscilloscope differential probes. Direct connection is recommended; however, using differential probe heads (SMA probe heads), you can connect four lanes simultaneously and measure all the differential tests in one test connection.



Figure 6. Channel assignment setup: lane and oscilloscope assignment: 2 lane single-ended connection using all four scope channels.

Test selection

After defining the test environment through the test setup loop, you are presented with only those tests that are appropriate for the device defined AND environment chosen. For example, if spread spectrum clocking (SSC) is not selected in the session description, then no SSC tests will appear; nor will they regardless of if the device definition setup defined the device to be SSC OFF only. A similar logic holds for pre-emphasis and levels as well. If your device definition is one lane only or defined device connection is one lane (one differential probe or two single-ended connections), then no inter-pair skew tests will appear in the test suite. This dynamic filtering simplifies your job by ensuring you attempt to test only what is possible for the DUT and connection model you have chosen.

The eDP 1.4 test suite is shown in the test selection screen (see Figure 7). It is partitioned in groups of tests as a function of the pattern that is required to test. By grouping them so, the number of required test interruptions is minimized. Shown is D10.2 (clock pattern), PRBS7 (127-bit repetitive pattern), and HBR2CPAT, which is a 2520-bit repeating pattern that was defined specifically for HBR2 in DisplayPort 1.2 – it is considered a key pattern to test with in most circumstances. Other patterns that may be used are PLTPAT (divide-by-10 clock) and random pattern, which is offered for flexibility.

Tests may be selected independently, and any number of tests may be selected for a given run. If more than one lane is possible to run (as determined by the selections in setup), then test selection by lane is also possible. If different connections or conditions of test are required from one test to another, a splash screen is presented to the user indicating the required change. When automation mode is used with the AUX channel controller, the device is changed automatically, and there is no need for the splash screens.

| (BETA VERSION 0.99.9055) eDP Test eDP Device 1 * | | | | |
|--|--|--|--|--|
| File View Tools Help | | | | |
| | | | | |
| Task Flow Set Up Select Tests Configure Connect Run Tests Automation Results Html Report Set Up Embedded DisplayPort Tests Embedded DisplayPort Tests Embedded DisplayPort Tests Set Up Source Tests Embedded DisplayPort Tests Set Up Final DisplayPort Tests Set Up Big Source Differential Tests Embedded Display matching Embedded Display matching Embedded Display matching Set Up Source Differential Tests Embedded Display matching Embedded Display matching Embedded Display matching Embedded Display matching Set Up Source Differential Tests Embedded Display matching Embedded Display matching Empediate Tests Embedded Display matching Embedded Display matching Empediate Tests Embedded Display matching Embedded Display matching Empediate Tests Embedded Display matching Select Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests Empediate Tests | | | | |
| Configure Image: Configure Image: Connect D10.2 Tests Image: Connect Image: Connect Deterministic Jitter (TP3_EQ) Image: Connect Deterministic Deterministic Jitter (TP3_EQ) Image: Connect Deterministic Deterministic Deterministic Deterministic Deterministic Jitter (TP3_EQ) Image: Connect Deterministic Determinis | | | | |
| (Click a test's name to see description) | | | | |
| Limit Set: Embedded DisplayPort (eDP) Standard Version 1.4 | | | | |
| G Tests Check the test(s) you would like to run Connection: UNKNOWN | | | | |

Figure 7. Lists the tests that are selectable and their status. Status bubbles indicate successful completion, failure or incompletion.

Configurability and guided connection

The eDP 1.4 electrical performance and characterization software provides further flexibility in your test setup through the configure tab and will guide you to make connection changes with hookup diagrams when the tests you select require it.

While the most configurability is afforded in the test definition sequence, the configure tab allows for further possibility of modification of the test session operation for testing debug or 'what-if' analysis. For instance, you can alter transfer function, equalization or bandwidth of the measurement. In Figure 8, you can see some of the configurable parameters that can be altered in a given test session.

| ung (BETA VERSION 0.99.9055) eDP Test eDP Device 1 * | | | | | |
|---|--|--|--|--|--|
| File View Tools Help | | | | | |
| | | | | | |
| Task Flow _ Set Up Set Up Set Up Set Up Compliance © Debug Activate/Refresh Limit Set Active: (Official) Embedded DisplayPort (eDP) Standard Version | | | | | |
| Olock Recovery Damping Factor - Link Rate 4 (Settings For: Eye Diagram Movement | | | | | |
| Select Tests Gendalizer Settings Gendalizer Enable (True) Use Custom Transfer Function (False) Custom Transfer Function File Name (CustomEmbe Cable Embedding (False) Custom Transfer Function File Name (CustomEmbe Cable Embedding (False) Custom Transfer Function File Name (CustomEmbe Cable Embedding (False) Custom Transfer Function File Name (CustomEmbe Cable Embedding (False) Level Pattern Count (1000) Level Memory Depth (kpts) (500) Eye Diagram Memory Depth (kpts) (2000) Eye Diagram Passing Start Location (UI) (0.375) Eye Diagram Passing Start Location (UI) (0.375) Eye Diagram Passing Start Location (UI) (0.375) Eye Diagram Passing End Location (UI) (0.625) Eye Diagram Eye Mask (False) Eye Diagram Eye Mask Movement (Fixed) Transition Time Edges (100) Transition Time Edges (100) Transition Time Edges (100) Transition Time Memory Depth (kpts) (500) Emperimental Transition Time Memory Depth (kpts) (500) Emperi | | | | | |
| ☑ 6 Tests Configure options for the tests you checked Connection: UNKNOWN | | | | | |

Figure 8. The eDP 1.4 configure tab enables changing measurement parameters in the 'Debug' mode to support characterization and debug activities.

After you configure the test to meet your needs, the eDP 1.4 EP&C user interface displays the connection screen, which is specific to the configuration data you have selected. Figure 9 illustrates the typical connection guidance provided for a one-channel "A minus B" connection model for a one lane test setup.



Figure 9. The final step before test is to illustrate the anticipated connection for the test.

| view Tool | s Heip | | | | | | | | | |
|---------------------|--|--|--|--|---|--|---|--|--|-----------------------|
| F 🖬 🛛 😒 |) 🕅 🗖 🗖 🖌 | K | | | | | | | | |
| sk Flow _ | Set Up Select Tests | Configure Connec | t Run Tests | Automation | Results Html | Report | | | | |
| etUn | Test Name | | | Wor | st Actual Wors | t Margin Pass | Limits | | | |
| | √ Lane 0 - Eye Diad | ram Test (TP3 EQ) (H | IBR2CPAT) | 0.00 | 0 50.0 | % -500 | 1 m <= VALUE <= 500 m | | | |
| | √ Lane 0 - Non-ISI | Jitter Test (HBR2CPAT | T) | 21.1 | 000 mUI 92.4 | % VALU | JE <= NonISIJitterLimit | IL | | |
| ¥ į | 🗸 Lane 0 - Total Jit | ter Test (TP3_EQ) (HB | R2CPAT) | 83.8 | 00 mUI 83.2 | % VALU | JE <= TotalJitterLimit UI | | | |
| ct Tests | 🗸 Lane 0 - Determin | nistic Jitter Test (TP3_ | EQ) (HBR2CPAT |) 60.1 | 00 mUI 85.3 | % VALU | JE <= DeterministicJitte | Limit UI | | |
| | √ Lane 0 - Random | Jitter Test (TP3_EQ) | (HBR 2CPAT) | 2.00 | 0 mUI 99.19 | % VAL | JE <= RandomJitterLimit | UI | | |
| \mathbf{v} | | | | | | | | | | |
| fours | | | | | | | | | | |
| ingure | | | | | | | | | | |
| | | | | | | | | | | |
| ¥. | | | | | | | | | | |
| | | | | | | | | | | |
| onnect | | | | | | | | | | |
| Connect | | | | | | | | | | |
| Connect | | | | 2 50 1 21 | | | | | | |
| Connect | Details: Lane 0 - E | ye Diagram Test (1 | FP3_EQ) (HBR | 2CPAT) | | | | | | |
| onnect Un Tests | Details: Lane 0 - E | ye Diagram Test (1 | TP3_EQ) (HBR Trial 1 (Worst) | 2CPAT) | 2 | | | | | |
| in Tests | Details: Lane 0 - E Summary Trials: 2 | ye Diagram Test (1 | TP3_EQ) (HBR Trial 1 (Worst) | 2CPAT) | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| n Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Pasced: 2 | ye Diagram Test (1 | Trial 1 (Worst) | EZCPAT) | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| n Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 | ye Diagram Test (1 Summary / Trial Mean Stdev | TP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 | 2CPAT) Trial Margin 50.00 % 0.000 % | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| n Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial | tye Diagram Test (1 | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 | 2CPAT) V Trial Margin 50.00 % 0.000 % 0.000 % | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| n Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial <u>Trial 1</u> | ye Diagram Test (1 V Summary V Trial Mean Stdev Range Min | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 | 2CPAT) ✓ Trial Margin 50.00 % 0.000 % 0.000 % 50.00 % | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| n Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial Trial 1 | ye Diagram Test (1 V Summary V Trial Mean Stdev Range Min Max | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) ✓ Trial Margin 50.00 % 0.000 % 0.000 % 50.00 % 50.00 % | 2 | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyeł |
| in Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial Trial 1 | ye Diagram Test (1 Summary Summary Summ | TP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) Trial Margin 50.00 % 0.000 % 0.000 % 50.00 % 50.00 % 100.0 % | 2 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eyel |
| in Tests | Details: Lane 0 - E Summary Trials 2 Failed: 0 Passed: 2 Worst trial Trial 1 | ye Diagram Test (1 V Summary V Trial Mean Stdev Range Min Max Sum V Trial (Worst) | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) √ Trial Margin 50.00 % 0.000 % 0.000 % 50.00 % 50.00 % 50.00 % 50.00 % | 12 Number of UI | Mask Width | Mask Height (VHigh) | Mask Height (VLow) | Eye Width Measured | Eye H |
| in Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial Trial 1 | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Stdev Range Min Max Sum ✓ Trial 1(Worst) ✓ Trial 2 | PP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 22CPAT) Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.00 % 50.00 % 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width | Mask Height (VHigh) 37.500 mV 37.500 mV | Mask Height (VLow) | Eye Width Measured | Eye 1 |
| un Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial <u>Trial 1</u> | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Sciev Range Min Max Sam ✓ Trial 1 Worst) ✓ Trial 2 | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 22CPAT) ✓ Trial Margin 50.00 % 0.000 % 0.000 % 50.00 % 50.00 % 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width | Mask Height (VHigh) 37.500 mV 37.500 mV | Mask Height (VLow) -37.500 mV -37.500 mV | Eye Width Measured 171.970 ps 172.330 ps | Eye 220. 219. |
| in Tests | Details: Lane 0 - E Summary Trials: 2 Falled: 0 Passed: 2 Worst trial <u>Trial 1</u> | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Sclev Range Min Max Sum ✓ Trial 1 (Worst) ✓ Trial 2 | TP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 22CPAT) ✓ Trial Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.00 % 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width 500.000 mUI 500.000 mUI | Mask Height (VHigh) 37,500 mV 37,500 mV | Mask Height (VLow) -37.500 mV -37.500 mV | Eye Width Measured | Eye 220. 219. |
| ionnect un Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial Trial i | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Sidev Range Min Max Sum ✓ Trial 1 Worst) ✓ Trial 2 | Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) V Trial Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.00% 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width 500.000 mUI 500.000 mUI | Mask Height (VHigh) 37.500 mV 37.500 mV | Mask Height (VLow) -37,500 mV -37,500 mV | Eye Width Measured 171.970 ps 172.330 ps | Eye 220. 219. |
| ionnect | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial <u>Trial 1</u> | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Sclev Range Min Max Sum ✓ Trial 1 (Worst) ✓ Trial 2 | FP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) √ Trial Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.00 % 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width 500.000 mUI 500.000 mUI | Mask Height (Hsiph) 37.500 mV 37.500 mV | Maak Height (VLow) -37,500 mV -37,500 mV | Eye Width Measured 171.970 ps 172.330 ps | Eye H 220. 219. |
| in Tests | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial <u>Trial 1</u> | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Stdev Man Max Sum ✓ Trial 1 (Worst) ✓ Trial 2 | PP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 | 2CPAT) Margin 50.00 % 0.000 % 0.000 % 50.00 % 50.00 % 50.0% 50.0% | 2) Number of UI 1.000000 M 1.000000 M | Mask Width 500.000 mUI 500.000 mUI | Mask Height (Heigh) 37,500 mV 37,500 mV | Mask Height (VLow) -37,500 mV -37,500 mV | Eye Width Measured | Eye H 220 219 |
| onnect | Details: Lane 0 - E Summary Trials: 2 Failed: 0 Passed: 2 Worst trial Trial_i | ye Diagram Test (1 ✓ Summary ✓ Trial Mean Stolev Range Min Max Sum ✓ Trial (Worst) ✓ Trial 2 | IP3_EQ) (HBR Trial 1 (Worst) Actual Value 0.000 0.000 0.000 0.000 0.000 0.000 | 22CPAT) ✓ Trial Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.0% | 2 Number of UI | Mask Width 500.000 mUI 500.000 mUI | Mask Height (VHigh) 37,500 mV 37,500 mV | Mask Height (VLow) -37.500 mV -37.500 mV | Eye Width Measured 71.970 ps 172.330 ps | Eye H 220 219 |
| onnect | Details: Lane 0 - E Summary Trials: 2 Pased: 2 Worst trial Trial 1 | ye Diagram Test (1 √ Summary √ Trial Mean Solev Pange Min Max Sum √ Trial 1 (Worst) √ Trial 2 | FP3_EQ) (HBR Trial 1 (Worst) <u>Actual Value</u> 0.000 0.000 0.000 0.000 0.000 0.000 0.000 | 22CPAT) ✓ Trial Margin 50.00 % 0.000 % 50.00 % 50.00 % 50.00 % 50.0% | 2 Number of UI 1.000000 M 1.000000 M | Mask Width 500.000 mUI 500.000 mUI | Mask Height (High) 37.500 mV 37.500 mV | Maek Height (VLow) -37.500 mV -37,500 mV | Eye Width Measured 171.970 ps 172.330 ps | 220. 219. |

Figure 10. eDP 1.4 EP&C test software results report documents your test and indicates the pass/fail status, test specification range, measured values and margin.

Thorough performance reporting

The eDP 1.4 electrical performance and characterization software generates thorough reports that not only capture the performance and status of the device under test, but also capture the screen shots of your most significant measurements for your perusal and evaluation. The first page of the report lists equipment and configuration details required in standard quality-assurance programs. It also provides a hot-linked results table that will quickly get you to the measurement report section of interest.

| C Home - Projects X C Financials X C eDP Device 1 Results 2014 X | | | | |
|---|---|---------------|---|-----------------|
| 🔄 🔿 🖸 🗋 file:///C:/Users/fetz/Documents/AAA_Fetz/Specific%20Problems/edp/eDP%20Device%201%20Results%202014-11-10_19-15-02/e[🖧 ا | | | | |
| Apps 📄 Index of / 🧰 Agilent Administrati | | | | Other bookmarks |
| | | | | _ |
| AA KEYSIGHT | | | | |
| TECHNOLOGIES | | | | |
| | e | DP Tes | st Report | |
| | _ | | | |
| | C C | verall Re | sult: PASS | |
| | | Test Config | uration Details | |
| | | Device D | escription | |
| 1 | Test Specification | eDP 1.4 | ice 1 | - |
| | Device iD | Test Sess | sion Details | = |
| | Fixture Type | Wilder Te | sch eDP-TPA40 | |
| | Infiniium SW Version | 04.60.00 | 23 | _ |
| | Infinitum Model Numbe | No Seria | 504A | - |
| | Application SW Version | 0.99.905 | 5 | = |
| | Debug Mode Used | No | | |
| | Compliance Limits (official) | | ed DisplayPort (eDP) Standard Version 1 10.19:15:02 UTC +09:00 | 4 |
| | Last Test Date 2014-11-10 19:15:02 UTC +08:00 | | | |
| Summary of Results | | | | |
| Test Statistics | | | | |
| Failed 0 | | | | |
| Passed 5 | | | | |
| | | | | |
| Margin Thresholds | | | | |
| Critical < 0 % | | | | |
| | | | | |
| Pass # Failed # Trials Test Name | Worst Actu | al Worst Marg | in Pass Limits | |
| O O Z Lane D - Eve Diagram Test (IP3 EQ) | (HBR2CPAT) 0.000 | 50.0 % | -500 m <= VALUE <= 500 m | |
| O Z Lane 0 - Non-ISI Sitter Test (HBR2CH) O Z Lane 0 - Total litter Test (TP3 EO) (H | BR2CRAT) 83.800 mU | 83.2 % | VALUE <= NoniSisterLimit UI | |
| Compared a state of a contract of the state of the s | EQ) (HBR2CPAT) 60.100 mUI | 85.3 % | VALUE <= DeterministicJitterLimit UI | |
| ✓ 0 2 Lane 0 - Random Jitter Test (TP3 EQ | (HBR2CPAT) 2.000 mUI | 99.1 % | VALUE <= RandomJitterLimit UI | |
| | | | | |
| 1 | | | | |
| Report Detail | | | | |
| | | | | |

Figure 11. The eDP 1.4 software generates a summary report where you can see the total test results for your device quickly and clearly. Additional details are available for each test, including the test limits, test description and test results, including waveforms, if appropriate. All are hot-linked to more detailed results further in the report. In addition, the margin of the result is indicated to provide further insight.



Figure 12. Summary report detail: The eDP 1.4 software's summary report provides screen shots of all the measurements that have been performed. In this figure, you can see the data-eye. Observe the clear status and description at the top and the measurement data just above the eye.

eDP test point adapters

The eDP 1.4 specification is standardized on IBEX connectors on the display panel to connect to a graphics processor board/motherboard through a ribbon-like flexible PC board.



Figure 13. IBEX connector with ribbon-like flexible PC board.

By virtue of this standardization, testing for eDP 1.4 must be done at the panel connector. In DisplayPort and eDP, this point is called Testpoint 3 (or TP3 for short). TP3 necessarily includes the loss of the ribbon cable and whatever connection characteristics are at the motherboard where the ribbon connector is connected. To acquire at TP3, you will need a mating connector to your IBEX connectorized flexible PC board. Wilder Technologies makes a family of products to connect to the flexible PC board.



Figure 14. Wilder Technologies' eDP-TPA40L-PC test point adapter fixture.

This eDP fixture has high-speed breakout cables that terminate with SMA female connectors with an assumption that there will be cables from the oscilloscope channels to the fixture. While these cables do increase loss to the measured lines, they can be kept to a minimum to reduce their effect and can be effectively removed using PrecisionProbe software available in the Infiniium oscilloscope (see Table 4).

While TP3 will show the actual performance through a flexible PC board, it is often desired to render the acquired waveform in 'compensated' fashion to simulate a minimal correction that a receiving device might make. In DP and eDP, we call this TP3EQ (or TP3 equalized). We use CTLE (Continue Time Linear Equalizer) equalization, and the parameters for the CTLE are given in the eDP 1.4 specification. The settability of these is discussed above in *Device Definition*.

Extensibility

You may add additional custom tests or steps to your application using the N5467B/ N5467C User-Defined Application (UDA) development tool (www.keysight.com/find/ uda). Use UDA to develop functional "add-ins" that you can plug into your application.



Figure 15. Importing a UDA add-in into a compliance application.

Add-ins may be designed as:

- Complete custom tests (with configuration variables and connection prompts)
- Any custom steps such as pre-/post-processing scripts, external instrument control and your own device control

| Set Up | Select Tests | Configure | Connect | Run Tests |
|-----------|--------------|---------------|-------------|-----------|
| DD | O All DDR2 T | ests | | |
| ÷. | - O Electri | cal Tests | | |
| ÷. | - O Timing | Tests | | |
| Ė. | O User D | efined | | |
| | | y Custom Te | st | |
| | - O M | y Custom St | ep | |
| | - O M | y Post-proce | ssing Step | |
| | - O M | y External Ir | nstrument (| Control |
| | ✓ O M | y Device Cor | ntrol | |
| | | | | |

Figure 16. UDA add-in tests and utilities.

Automation

You can completely automate execution of your application's tests and add-ins from a separate PC using the remote interface feature (download free toolkit from **www.keysight.com/find/scope-apps)**. You can even create and execute automation scripts right inside the application using a convenient built-in client.



Figure 17. Remote programming script in the automation tab.

The commands required for each task may be created using a command wizard or the "remote hints" accessible throughout the user interface.

Using automation, you can accelerate complex testing scenarios and even automate manual tasks such as:

- Opening projects, executing tests and saving results
- Executing tests repeatedly while changing configurations
- Sending commands to external instruments
- Executing tests out of order

Combine the power of built-in automation and extensibility to transform your application into a complete test suite executive:

- Interact with your device controller to place it into desired states or test modes before test execution
- Configure additional instruments used in your test suite such as a pattern generator and probe switch matrix
- Export data generated by your tests and post-process it using your favorite environment, such as MATLAB, Python, LabVIEW, C, C++, Visual Basic, etc.
- Sequence or repeat the tests and "add-in" custom steps execution in any order for complete test coverage of the test plan



Figure 18. Combine the power of built-in automation and extensibility to transform your application into a complete test suite executive.

Tests performed

The eDP 1.4 electrical performance and characterization software performs standard tests found in the DisplayPort electrical performance and compliance software and are provided for the specific purpose of eDP designs. Testing is assumed to be TP3 (a flexible cable from graphics processor in place) so the user needs to consider whether TP3 or TP3Eq makes sense for their application. There is nothing that prevents a Testpoint 2 measurement except test access. If a model of the flexible cable is had (S-parameter model), a transfer function can be made to undo its effects to show what the TP2 waveform looks like.

| Assertion no. | Test description | Test plan | Comments |
|-----------------------------------|--------------------------------------|------------|--|
| DisplayPort CTS 1.2b Section3. | Source tests | controlled | |
| Test ID 3.1 | Data eye eiagram | Yes | Custom eye mask per data rate |
| Test ID 3.2 | Non Pre-emphasis level verification | Yes | Referential (Level $_{\rm x-1}$) or absolute voltages |
| Test ID 3.3 | Pre-emphasis level verification | Yes | Provided for system check. Referential or absolute |
| Test ID 3.4 | Inter-pair skew | Yes | Pattern required |
| Test ID 3.5 | Intra-pair skew | Yes | D10.2 pattern |
| Test ID 3.6 | Differential transition time | Yes | Entry of thresholds |
| Test ID 3.10 | AC common mode noise | Yes | Single-ended test connection required. DP 1.2 informative test |
| Test ID 3.11 | Non-ISI jitter measurements | Yes | Non-equalizable jitter |
| Test ID 3.12 | Total jitter measurements | Yes | 10-9 BER |
| Test ID 3.14 | Main link frequency compliance | Yes | D10.2 pattern preferred |
| Test ID 3.15 | Spread spectrum modulation frequency | Yes | D10.2 pattern preferred |
| Test ID 3.16 | Spread spectrum modulation deviation | Yes | D10.2 pattern preferred |

Table 1. eDP 1.4 tests performed by the eDP 1.4 software.

Ordering information

The eDP 1.4 electrical performance and characterization software is compatible with Keysight Infiniium Series oscilloscopes with operating software revision 5.20 or higher. For oscilloscopes with earlier revisions, free upgrade software is available at www.keysight.com/find/scope-apps-sw

Recommended oscilloscopes

| eDP specification | Infiniium software application | Minimum bandwidth | Compatible oscilloscopes |
|-------------------|--------------------------------|-------------------|-------------------------------------|
| eDP 1.4 | eDP 1.4 EP&C | 13 GHz | Infiniium 90000 Series and Z-Series |

Table 2. Recommended oscilloscopes.

To purchase the eDP 1.4 software with a new or existing Infiniium Series oscilloscope, order one of the following options.

eDP 1.4 software options

| Application | License type | | Infiniium Z-Series | Infiniium 90000 Series |
|-----------------------|--------------|-------------------|--------------------|------------------------|
| eDP 1.4 EP&C software | Fixed | Factory-installed | N6469A-1FP | Option 083 |
| | | User-installed | N6469A -1FP | N6469A -1FP |
| | Floating | Transportable | N6469A -1TP | N6469A -1TP |
| | | Server-based | N5435A-083 | N5435A-083 |

Table 3. eDP 1.4 EP&C software options.

Oscilloscope measurement software

| Application | License type | | Infiniium Z-Series | Infiniium 90000 Series |
|----------------------------|--------------|-------------------|--------------------|------------------------|
| Equalization (required) | Fixed | Factory-installed | N5400A-1FP | Option 004 |
| | | User-installed | N5400A-1FP | N5400A-1NL |
| | Floating | Transportable | N5400A-1TP | N5400A-1TP |
| | | Server-based | N5435A-001 | N5435A-001 |
| Equalization (required) | Fixed | Factory-installed | N5461A-1FP | Option 012 |
| | | User-installed | N5461A-1FP | N5461A-1NL |
| | Floating | Transportable | N5461A-1TP | N5461A-1TP |
| | | Server-based | N5435A-025 | N5435A-025 |
| PrecisionProbe calibration | Fixed | Factory-installed | N2809A-1FP | Option 001 |
| (optional) | | User-installed | N2809A-1FP | N2809A-1NL |
| | Floating | Transportable | N2809A-1TP | N2809A-1TP1,2 |
| | | Server-based | N5435A-003 | n/a |
| InfiniiSim (optional) | Fixed | Factory-installed | N5465A-1FP | Option 014 |
| | | User-installed | N5465A-1FP | N5465A-1NL |
| | Floating | Transportable | N5465A-1TP | N5465A-1TP |
| | | Server-based | N5435A-027 | N5435A-027 |

Table 4. Infiniium measurement software.

| Model number | Description |
|---------------|---|
| eDP-TPA40L-PC | Wilder Technologies 40 pin test point adapter |
| N4871A | 3.5mm cables phase matched +/- 5ps |
| 15443 | SMA cable set phase matched +/-25ps |

Table 5. Fixture and connection tools.

myKeysight

myKeysight

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.

www.axiestandard.org

AdvancedTCA® Extensions for Instrumentation and Test (AXIe) is an open standard that extends the AdvancedTCA for general purpose and semiconductor test. Keysight is a founding member of the AXIe consortium. ATCA®, AdvancedTCA®, and the ATCA logo are registered US trademarks of the PCI Industrial Computer Manufacturers Group.

www.lxistandard.org

LAN eXtensions for Instruments puts the power of Ethernet and the Web inside your test systems. Keysight is a founding member of the LXI consortium.



www.pxisa.org

PCI eXtensions for Instrumentation (PXI) modular instrumentation delivers a rugged, PC-based high-performance measurement and automation system.



Three-Year Warranty

www.keysight.com/find/ThreeYearWarranty

Keysight's commitment to superior product quality and lower total cost of ownership. The only test and measurement company with three-year warranty standard on all instruments, worldwide.



Keysight Assurance Plans

www.keysight.com/find/AssurancePlans

Up to five years of protection and no budgetary surprises to ensure your instruments are operating to specification so you can rely on accurate measurements.



www.keysight.com/go/quality

Keysight Technologies, Inc. DEKRA Certified ISO 9001:2008 Quality Management System

Keysight Channel Partners

www.keysight.com/find/channelpartners

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

Americas

| Canada | (877) 894 4414 |
|---------------|------------------|
| Brazil | 55 11 3351 7010 |
| Mexico | 001 800 254 2440 |
| United States | (800) 829 4444 |
| | |

Asia Pacific

| Australia | 1 800 629 485 |
|--------------------|----------------|
| China | 800 810 0189 |
| Hong Kong | 800 938 693 |
| India | 1 800 112 929 |
| Japan | 0120 (421) 345 |
| Korea | 080 769 0800 |
| Malaysia | 1 800 888 848 |
| Singapore | 1 800 375 8100 |
| Taiwan | 0800 047 866 |
| Other AP Countries | (65) 6375 8100 |

Europe & Middle East

United Kingdom

For other unlisted countries: www.keysight.com/find/contactus (BP-09-23-14)



This information is subject to change without notice. © Keysight Technologies, 2014 Published in USA, November 17, 2014 5992-0284EN www.keysight.com