

# Read this first

## Notice Regarding the Model 2700 Xlinx 2.1 Start-up Software Update

Keithley is pleased to announce that the Model 2700's Xlinx 2.1 free Up & Running software has the following new features:

- Support for the Model 7708 module (40 channel Differential Multiplexer Module with Automatic CJC).
- Off-Line Data Logging – this new feature will allow Xlinx to retrieve data collected by the Model 2700 while off-line (off-line data logging supports delta and absolute time only).
- Added scan list support for a totalizer channel for the 7706 module.
- Automatic reservation of the paired channels in a 4-wire configuration for resistance or temperature measurements.

Modules supported in Xlinx 2.0 and 2.1 are listed below:

Module	Xlinx 2.0	Xlinx 2.1
7700	x	x
7702	x	x
7703	x	x
7705		
7706 *	x	x
7708		x

\* Model 7706 support includes analog inputs and totalizer inputs in a scan list only.

## Xlinx Upgrades

Any customer that wishes to upgrade their earlier version of Xlinx to version 2.1 can do so at no additional cost by downloading the latest version of Xlinx 2.1 at: [www.keithley.com/products/prod\\_pages/2700/software\\_2700.html](http://www.keithley.com/products/prod_pages/2700/software_2700.html)

**Note:** *You must completely un-install any previous versions of Xlinx on your computer by using the add/remove programs utility in Windows before installing the new version of Xlinx.*

Perform the following steps to uninstall the software:

1. Using Microsoft Start menu, go to Add/Remove Program under the Settings/ Control Panel.
2. Select XLINX 2700 Startup SOFTWARE and follow the on-screen instructions.

*Thanks again for choosing the  
Model 2700 DMM / Data Acquisition System  
and Keithley Instruments, Inc.*