

General Description

The MAX5940B evaluation kit (EV kit) is a fully assembled and tested surface-mount circuit board featuring an Ethernet port, network powered device (PD) interface controller circuit for -48V supply systems. The EV kit uses the MAX5940B IEEE 802.3af-compliant network PD interface controller in an 8-pin SO package. The MAX5940B EV kit can also evaluate the MAX5940D rated for an absolute maximum input voltage of 90V. The MAX5940B features an internal isolation switch that limits inrush current. The MAX5940B is used in powerover-LAN applications requiring DC power from an Ethernet network port for PDs such as IP phones, wireless access nodes, and security cameras.

The MAX5940B EV kit receives power from an IEEE 802.3af-compliant power sourcing equipment (PSE). See the MAX5922 and MAX5935* data sheets for PSE controllers. The PSE provides the required -44V to -57V DC power over an unshielded twisted-pair Ethernet network cable to the EV kit's RJ-45 jack. The EV kit features a 10/100BASE-TX Voice-over-IP (VoIP) magnetic module and two diode bridges for separating the DC power provided by an endspan or midspan Ethernet system.

The EV kit demonstrates the full functionality of the MAX5940B such as the PD detection signature, configurable PD classification signature, programmable inrush current, and undervoltage lockout (UVLO). All of these features are configurable on the EV kit and additional test points for voltage probing and interfacing have been provided for the PD interface.

The MAX5940B EV kit also features a galvanically isolated 6W, 275kHz switching frequency flyback DC-DC converter, which uses the MAX5014 current-mode PWM controller. The MAX5940B's -48V output provides power for the converter circuit. The DC-DC converter is configured for an output voltage of 4.25V and provides up to 1.4A at the output. High efficiency up to 82.2% is achieved using a single transistor flyback DC-DC converter topology. The surface-mount transformer provides 1500V galvanic isolation for the output. UVLO, soft-start, and thermal shutdown provide a robust 6W isolated power supply.

The EV kit can be reconfigured for interfacing to an external DC-DC converter for an additional 7W of output power.

*Future product—Contact factory for availability.

Warning: The MAX5940B EV kit operates with high voltages. Dangerous voltages are present on this EV kit and on equipment connected to it. Users who power up this EV kit or power the sources connected to it must be careful to follow safety procedures appropriate to working with high-voltage electrical equipment.

Under severe fault or failure conditions, this EV kit may dissipate large amounts of power, which could result in the mechanical ejection of a component or of component debris at high velocity. Operate this EV kit with care to avoid possible personal injury.

Features

- IEEE 802.3af-Compliant PD Interface Circuit
- PD Detection and Configurable Classification Signatures
- Programmable Inrush Current Limit
- Programmable UVLO
- Isolated 6W Flyback DC-DC Converter
- ♦ -36V to -60V Input Range
- Isolated 4.25V Output at 1.4A
- Evaluates Endspan and Midspan Ethernet Systems
- Interface to an External DC-DC Converter
- Local Power Inputs (Wall Cube)
- Also Evaluates MAX5940D (IC Replacement Required)
- Fully Assembled and Tested

Ordering Information

PART	TEMP RANGE	IC-PACKAGE
MAX5940BEVKIT	0°C to +70°C	8 SO

Maxim Integrated Products 1

For pricing, delivery, and ordering information, please contact Maxim/Dallas Direct! at 1-888-629-4642, or visit Maxim's website at www.maxim-ic.com.

DESIGNATION	QTY	DESCRIPTION	
C1	1	0.068µF ±10%, 100V X7R ceramic capacitor (1210) Murata GRM32NR72A683K	
C2	1	6800pF ±10%, 100V X7R ceramic capacitor (0805) Murata GRM219R72A682K	
C3	1	47μF ±20%, 100V electrolytic capacitor (12.5mm x 13.5mm) Sanyo 100CV47FS	
C4	1	1000pF ±10%, 250VAC X7R UL ceramic capacitor (2010) Murata GA352QR7GF102KW01L	
C5, C6	2	330µF ±10%, 10V tantalum capacitors (X) Kemet T494X337K010AS	
C7, C15	2	1.0μF ±10%, 50V X7R ceramic capacitors (1206) TDK C3216X7R1H105K	
C8, C16	2	0.1µF ±10%, 16V X7R ceramic capacitors (0603) Murata GRM188R71C104K	
C9	1	1μF ±10%, 10V X5R ceramic capacitor (0603) Murata 188R61A105K	
C10	1	0.033µF ±10%, 50V X7R ceram capacitor (0805) Murata GRM219R71H333K	
C11	1	4700pF 250VAC X7R ceramic capacitor (2220) Murata GA355DR7GC472KY02	
C12	1	22µF ±20%, 35V tantalum capacitor (D) Kemet T494D226M035AS	
C13	1	0.1µF ±10%, 50V X7R ceramic capacitor (0805) Murata GRM21BR71H104K	
C14	1	0.22µF ±10%, 10V X7R ceramic capacitor (0603) Murata GRM188R71A224K	

DESIGNATION	QTY	DESCRIPTION
C17	1	10μF ±10%, 25V tantalum capacitor (C) Vishay 293D106X9025C2
C18	1	1000pF ±10%, 50V X7R ceramic capacitor (0603) Murata GRM188R71H102K
C19, C20	2	0.01µF ±10%, 100V X7R ceramic capacitors (0805) Murata GRM21BR72A103K
C21	1	0.68µF ±20%, 100V X7R ceramic capacitor (1210) TDK C3225X7R2A684M
D1	1	56.7V 600W zener overvoltage transient suppressor (SMB) Vishay SMBJ51A
D2	1	3A 40V Schottky diode (SMC) Diodes Incorporated B340
D3, D4	2	1A 200V super-fast rectifiers (SMB) Diodes Incorporated MURS120
D5	1	51V 5% 3W zener diode (SMB) Vishay BZG05C51
D6	1	300mA 75V high-speed diode (SOD-123) Diodes Incorporated 1N4148W
D7, D8	2	1A 200V standard recovery power rectifiers (DFS case) Vishay DF02SA
D9	1	1A 100V standard recovery power rectifier (SMA) Diodes Incorporated S1B
D10	0	Not installed, 1A 100V standard recovery power rectifier (SMA) Diodes Incorporated, S1B recommended
D11	1	30V 500mW zener diode (SOD123) Diodes Incorporated BZT52C30



QTY

1

1

1

2

1

1

1

DESIGNATION

R15

R16

R17

R18, R19

R20

R21

R22

_Component List (continued)

DESCRIPTION

10Ω ±5% resistor (0805)

 $1M\Omega \pm 5\%$ resistor (0805)

 $24.3k\Omega \pm 1\%$ resistor (0805)

Not installed, resistor (0805) $2k\Omega \pm 1\%$ resistor (0805)

 $100k\Omega \pm 1\%$ resistor (0805)

 $75\Omega \pm 5\%$ resistors (0805)

DESIGNATION	QTY	DESCRIPTION
J1	1	RJ-45 black through-hole connector, 8P-8C
JU1	1	3-pin header
JU2	1	5-pin header
N1	1	150V, 4.3A n-channel MOSFET (D-PAK) Fairchild FQD5N15TM
Q1, Q2	2	60V, 200mA NPN transistors (SOT-23) Central Semiconductor CMPT3904
R1	0	Not installed, resistor (1206)
R2	0	Not installed, resistor (0805)
R3	1	25.5k Ω ±1% resistor (1206)
R4	1	$10k\Omega \pm 1\%$ 100ppm thick-film resistor (0805) Panasonic ERJ6ENF1002V
R5	1	$732\Omega \pm 1\%$ 100ppm thick-film resistor (1206) Panasonic ERJ8ENF7320V
R6	1	$392\Omega \pm 1\%$ 100ppm thick-film resistor (1206) Panasonic ERJ8ENF3920V
R7	1	$255\Omega \pm 1\%$ 100ppm thick-film resistor (1206) Panasonic ERJ8ENF2550V
R8	1	$178\Omega \pm 1\%$ 100ppm thick-film resistor (1812) Panasonic ERJ12NF1780U
R9	1	470Ω ±5% resistor (0805)
R10	1	10k Ω ±1% resistor (0805)
R11	1	2.1k Ω ±1% resistor (0805)
R12	1	221Ω ±1% resistor (0805)
R13	1	100Ω ±5% resistor (0805)
R14	1	0.68Ω ±1% resistor (1206) Panasonic ERJ8RQFR68V

R23	1	$0\Omega \pm 5\%$ resistor (0805)	
R24	1	$150\Omega \pm 5\%$ resistor (1210)	
T1	1	10/100BASE-TX voice-over-IP magnetic module Pulse Engineering H2005A	
T2	1	6W 200µH transformer (12-pin Gull Wing) Cooper-Coiltronics CTX03-16649	
TP1, TP2, TP3	3	PC test points, red	
TP0	1	PC test point, black	
U1	1	MAX5940BESA (8-pin SO)	
U2	1	Current-mode PWM controller (8-pin SO) Maxim MAX5014CSA	
U3	1	High-isolation voltage photocoupler (SOP-4) CEL/NEC PS2703-1	
U4	1	1.24V precision shunt regulator (SOT-23-5L) Texas Instruments TLV431AIDBVR	
U5	1	High-isolation voltage photocoupler (SOD-4) CEL/NEC PS2701A-1	
None	2	Shunts (JU1, JU2)	
None	4	Rubber bumpers	
None	1	MAX5940B PC board	

Quick Start

The MAX5940B EV kit is fully assembled and tested. Follow these steps to verify board operation. **Do not turn on the power supply until all connections are completed.**

Required Equipment:

An IEEE 802.3af-compliant PSE and a Category 5 or 5e Ethernet network cable or:

- One 48V, 1A-capable DC power supply
- MAX5940B EV kit
- One voltmeter

/M/IXI/M

SUPPLIER	PHONE	FAX	WEBSITE
CEL/NEC; California Eastern Laboratories	800-997-5227	408-588-2213	www.cel.com
Cooper-Coiltronics	561-752-5000	561-742-1178	www.cooperet.com
Diodes Incorporated	805-446-4800	805-446-4850	www.diodes.com
Fairchild	888-522-5372		www.fairchildsemi.com
IRC	361-992-7900	361-992-3377	www.irctt.com
Kemet	864-963-6300	864-963-6322	www.kemet.com
Murata	770-436-1300	770-436-3030	www.murata.com
Panasonic	714-373-7366	714-737-7323	www.panasonic.com
Pulse Engineering	858-674-8100	858-674-8262	www.pulseeng.com
Sanyo Electronic Device	619-661-6835	619-661-1055	www.sanyodevices.com
TDK	847-803-6100	847-390-4405	www.component.tdk.com
Vishay	_	_	www.vishay.com

Component Suppliers

Note: Indicate that you are using the MAX5940B when contacting these component suppliers.

Hardware Connections

- Verify that a shunt is installed on pins 1 and 2 of jumpers JU1 (Class 1–4) and JU2 (Class 1).
- Use one of the following methods to power the MAX5940B EV kit:

If network connectivity is required: connect a Category 5 Ethernet network cable from the MAX5940B EV kit input port RJ-45 (J1) connector to the corresponding PSE Ethernet LAN connection, which provides power to the EV kit. Test points TP4–TP9 provide the ethernet data signals.

If network connectivity is not required: connect a 48V DC power supply to the GND and -48V pads on the MAX5940B EV kit.

- 3) Activate the PSE power supply or turn on the external DC power supply.
- Using a voltmeter, verify that the EV kit provides +4.25V across the VOUT and PGND pads. PGND is galvanically isolated from the EV kit's input GND and output GND2 pads.
- Observe desired signals with an oscilloscope or voltage meter on test point TP1 (U1 PGOOD pin), TP2 (U1 PGOOD), TP3 (U1 GATE), and TP0 (-48V) pads provided on the PC board.

Detailed Description of Hardware

The MAX5940B EV kit features an Ethernet-port network PD interface controller circuit for -48V supply rail systems. The MAX5940B IEEE 802.3af-compliant network PD interface controller in an 8-pin SO package. The MAX5940B has an internal isolation switch that also limits inrush current from the PSE. The MAX5940B is used in power-over-LAN applications for powering PDs from an unshielded twisted-pair (UTP) Ethernet Category 5 or 5e network cable and PSE port using endspan or midspan Ethernet systems.

The MAX5940B EV kit receives power (12.95W, max) from an IEEE 802.3af-compliant PSE and a UTP cable connected to the EV kit's RJ-45 connector J1. It uses a 10/100BASE-TX VoIP magnetic module (T1) and two diode-bridge power rectifiers (D7, D8) to separate the -48V DC power sent by the PSE. The MAX5940B EV kit can accept power from an endspan or midspan PSE network configuration. Diode D8 provides the midspan power and diode D7 provides the endspan power. Test points TP4–TP9 pick off the Ethernet data signals from the IP magnetic module T1. Magnetic module T1 is a dual module; however, only a single module is required.



The EV kit demonstrates the full functionality of the MAX5940B such as PD detection signature, configurable PD classification signature, programmable inrush current, and programmable UVLO. Resistor R3 sets the PD detection signature. A smaller value resistor should be used to compensate for diode bridges with higher resistance. Resistors R4-R8 determine the PD classification signature and appropriately configured jumpers JU1 and JU2. A single resistor is required to determine the classification. Gate capacitor C2 sets the inrush current. To utilize the UVLO feature of the MAX5940B, PC board pads are provided to install resistors R1 and R2. Resistors R1 and R2 set the UVLO threshold voltage and also determine the PD detection signature. For reconfiguring the EV kit for UVLO operation, see the UVLO Configuration section. Also, for proper operation, set the UVLO voltage to a minimum of 12V.

Test points TP0 (-48V), TP1 (PGOOD), TP2 (PGOOD), and TP3 (GATE) provide for voltage probing and/or interfacing with an external DC-DC converter.

The MAX5940B EV kit's galvanically isolated, 6W flyback DC-DC converter uses a MAX5014 current-mode PWM controller. The MAX5940B's VOUT and GND2 pins (-32V to -60V DC) provide power for the DC-DC converter input circuit. The flyback DC-DC converter is configured for an output voltage of +4.25V and provides up to 1.4A at the output while achieving up to 82.2% efficiency. Minimal component count is obtained by using a singletransistor (N1) flyback DC-DC converter topology. The surface-mount transformer T2 provides 1500V galvanic isolation for the output. Current-sense resistor R14 limits the peak current through transistor N1 and primary of transformer T2 to 1.5A. Isolated feedback voltage is achieved by using optical coupler U3 and shunt regulator U4. Voltage feedback resistors R10 and R17 set the output voltage. Diodes D4 and D5 limit the voltage at the primary windings of T2 during switching. Resistor R15 and capacitor C18 form a snubber network that suppresses transient overvoltage ringing at diode D2 caused by transformer T2 leakage inductance and the junction capacitance of diode D2.

Soft-start capacitor C14 enables the voltage at VOUT to ramp up in a controlled manner without any voltage overshoot. Internal UVLO and thermal shutdown within the MAX5014 provide for a robust 6W isolated powersupply design. The MAX5014 PWM controller operates at 275kHz and the duty cycle is limited to 85% maximum. Refer to the MAX5014 data sheet for more information on this controller.

The EV kit can easily be reconfigured to interface with an external DC-DC converter for an additional 7W of output power using the provided -48VOUT and GND2 PC board pads and test points TP0, TP1, and TP2. Additionally, the EV kit can also be reconfigured for stand-alone operation with an external DC-DC converter rated for up to 12.95W.

The MAX5940B EV kit also provides a circuit for powering the EV kit from a wall adapter or "local input" DC power source. Apply the local DC power source (36V to 44V) to the local input power (+) and local input power (-) PC board pads. Once the local input voltage is above 36V, optical coupler U4 turns off the MAX5940B internal MOSFET by pulling the GATE voltage low. Transistor Q1 turns off transistor Q3, which enables the DC-DC converter to run. Diode D3 prevents the PSE supply from back-driving the local power source. See the *Local Input Power Source* section for more information on using a wall adapter or "local input" DC power source.

Caution: The -48VOUT is not isolated from the power coming from the RJ-45 jack J1.

Jumper Selection

The MAX5940B EV kit features several jumpers to reconfigure the EV kit's PD classification and external DC-DC converter operation.

PD Classification Signature Selection

The MAX5940B EV kit has two jumpers that set the desired PD classification signature to a PSE connected to the EV kit's input port J1 connector. The 3-pin jumper JU1 and 5-pin jumper JU2 configure the classification signature. Table 1 lists the jumper options.

Table 1. PD Classification SignatureSelection

CLASS	JU1 SHUNT	JU2 SHUNT
Class 0	2–3	Don't care
Class 1	1, 2	1, 2
Class 2	1, 2	1, 3
Class 3	1, 2	1, 4
Class 4	1, 2	1, 5

External DC-DC Converter or Stand-Alone Operation The MAX5940B EV kit features PC board pads and test points to interface directly with an external DC-DC converter. The GND2 and -48VOUT PC board pads provide power to the external -48V DC-DC converter. TP1 (PGOOD) and TP2 (PGOOD) provide interfacing with the external converter. TP0 is an additional -48V test point connection. Gate capacitor C2 must be replaced and depends on the total input capacitance of both DC-DC converters (EV kit and external).

For stand-alone operation without the EV kit's 6W flyback DC-DC converter, remove several components. Short the PC board pads across capacitor C14 to disable the EV kit's on-board 6W flyback DC-DC converter. Also remove bulk capacitor C3. Additionally, replace gate capacitor C2, which depends upon the external DC-DC converter input capacitance. See the *Gate Capacitor Selection* section for selecting capacitor C2. The maximum power available at the GND2 and -48VOUT pads depends on the classification settings of jumpers JU1 and JU2. To reconfigure the MAX5940B EV kit for either method of operation, see Table 2.

Local Input Power Source

Opticoupler U5; transistors Q1 and Q2; and resistors R21, R22, and R23 along with diodes D9, D11, and the PC board pads for diode D10 enable the MAX5940B EV kit to be configured for various configurations using a local input power source with the PSE source. Use the Local Input Power (+) and Local Input Power (-) PC board pads to connect the local input power supply. The local input power-supply operating voltage range must be within 36V to 44V for the EV kit. This voltage range can be

changed with proper selection of diode D11 and resistor R21.

When the local input power source is above 36V, it will always take precedence over the PSE source. In this case, U5 turns off the MAX5940B internal MOSFET by pulling the GATE voltage low and the local power is supplied directly to the GND2 and -48VOUT pads. Once taking over, the local power source pollutes the discovery and classification signatures of the MAX5940B EV kit and prevents the PSE from powering up the EV kit until the local power has dropped to 0V.

If the local input power source is below 32V and if the PSE power comes up first, the PSE will provide power through the MAX5940B IC VOUT pin. Diode D9 will prevent the PSE from back-driving the local input power source when it is below 32V.

As an option when configuring the MAX5940B EV kit for a local input power source, cut open the PC board trace, shorting the diode D10 PC board pads, and install the recommended diode. D10 prevents the local input power source from polluting the discovery and classification signatures of the MAX5940B EV kit. In this configuration, the PSE power source can continuously detect the EV kit and provide power right away after the local power source voltage has dropped below 32V.

UVLO Configuration, Gate Capacitor Selection, and Ethernet Data-Signal Interfacing

Programmable UVLO Configuration

The MAX5940B EV kit features a UVLO circuit that prevents operation below the programmed input-supply start voltage. Resistors R1 and R2 set the input voltage

Table 2. External Converter or Stand-Alone Operation

EV KIT OPERATION	REMOVE	EV KIT MODIFICATIONS
On-Board and External DC-DC Converters	None	 Calculate new C2 value, using C3 and external DC-DC converter total input capacitance. Use TP0, TP1, TP2 to interface with an external DC-DC converter. Use GND2 and -48VOUT pads to power an external converter.
Stand-Alone	Resistor R20 Capacitor C3	 Calculate new C2 value, using an external DC-DC converter total input capacitance. Short capacitor C14 PC board pads. Use TP0, TP1, TP2 to interface with an external DC-DC converter. Use GND2 and -48VOUT pads to power an external converter.

turn-on and UVLO of the MAX5940B. To evaluate the programmable UVLO feature, remove resistor R3 and then install surface-mount resistors R1 (1206 case) and R2 (0805 case). Using the desired startup voltage, calculate resistors R1 and R2 using the following equations:

$$R2 = \left(\frac{V_{REF}}{VIN_{STARTUP}}\right) \times 25.5k\Omega$$

R1 = 25.5k\Omega-R2

where VINSTARTUP is the desired startup voltage (\geq +12V) at which the EV kit starts and V_{REF} is typically 2.47V. Additionally, the total series resistance of R1 and R2 must equate to 25.5k Ω . Resistors R1 and R2 provide the PD detection signature's resistive component when using the UVLO feature. For proper operation, the R1/R2 divider voltage of the UVLO pin of the MAX5940B must not exceed 7.5V at the maximum input voltage.

Gate Capacitor Selection

The MAX5940B gate capacitor value depends upon the total capacitance connected to the MAX5940B IC -48VOUT and GND2 pins. Typically, this is the sum of any DC-DC converter input capacitance (including C3 and C21, if used) and any connected bulk capacitance. Gate capacitor C2 is a 0805 surface-mount PC board footprint and is chosen using the following equation:

$$C2 = \left(\frac{C_{IN} \times 10\mu A}{I_{INRUSH}}\right)$$

Where I_{INRUSH} is the desired inrush current (set to 100mA for this EV kit) and C_{IN} is the total input capacitance connected to the MAX5940B -48VOUT and GND2 pins (only C3 as configured). When reconfiguring the EV kit for powering an external DC-DC converter, see the *External DC-DC Converter or Stand-Alone Operation* section for removing certain components.

Ethernet Data Signal Interfacing

The EV kit features several test points to interface with the Ethernet data signals. Test points TP4, TP5, and TP8 provide for interfacing with the Ethernet data receive signals. Test points TP6, TP7, and TP9 provide interfacing with the Ethernet data transmit signals. All trace lengths to/from module T1 have been matched to within 3mils in length. The data sheet for module T1, a 10/100BASE-TX VoIP magnetic module, should be consulted prior to interfacing with the EV kit's test point Ethernet data signals. The 10/100BASE-TX VoIP magnetic module (T1) can be replaced with a module rated for 1000BASE-TX for evaluation on Ethernet systems operating at 1000Mbps. The MAX5940B EV kit has not been verified under actual network operating conditions. A dual magnetic module is used for T1; however, only a single module is required.



Figure 1. MAX5940B EV Kit Schematic (PD Main Circuit)



Figure 2. MAX5940B EV Kit Schematic (6W 4.25V Isolated Power-Supply Circuit)

Evaluates: MAX5940B/MAX5940D



Figure 3. MAX5940B EV Kit Component Placement Guide— Component Side



Figure 5. MAX5940B EV Kit PC Board Layout—V_{CC} Layer 2



Figure 7. MAX5940B EV Kit PC Board Layout—Solder Side



Figure 4. MAX5940B EV Kit PC Board Layout—Component Side



Figure 6. MAX5940B EV Kit PC Board Layout—GND Layer 3



Figure 8. MAX5940B EV Kit Component Placement Guide— Solder Side

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

10

_____Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600

© 2005 Maxim Integrated Products

Printed USA

MAXIM is a registered trademark of Maxim Integrated Products.