Thank you very much for your shopping on us, if you need any other manual, email me at jasonsyj@hotmail.com, I will do my best to help you.

If you find any others selling the manual made by me, please email me also.

Attention Please:

The listing of this manual is to help those who need this manual to repair and maintain their equipment.

If you want to buy this manual, you must agree that this manual is only charged for Labeling, Service (List Price), Shipping and Handling Fee; the manual itself is FREE

Thanks and enjoy reading.

Jasonsyj on Ebay

NOTE

This manual documents the Model 8810A and its assemblies at the revision levels shown in appendix 7A. If your instrument contains assemblies with different revision letters, it will be necessary for you to either update or backdate this manual. Refer to the supplemental change/errata sheet for newer assemblies, or to the backdating sheet in appendix 7A for older assemblies.

8810A Digital Multimeter

Instruction Manual

P/N 472472 February 1978



Table of Contents

Table of Contents

4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning	SECTION		ITTLE	PAGE
1-7. SPECIFICATIONS 2 OPERATING INSTRUCTIONS 2-1. INTRODUCTION 2-3. SHIPPING INFORMATION 2-6. INPUT POWER 2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 3-34. Introduction 3-45. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 3-34. Introduction 3-45. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 3-34. Introduction 3-35. Control and Display 3-36. Control and Displ	1	INTRO	DDUCTION AND SPECIFICATIONS	1-1
2 OPERATING INSTRUCTIONS 2-1. INTRODUCTION 2-3. SHIPPING INFORMATION 2-6. INPUT POWER 2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-30. Resistance Measurements 3-32. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/ Disassembly 4-9. Cleaning		1-1.	INTRODUCTION	1-1
2-1. INTRODUCTION 2-3. SHIPPING INFORMATION 2-6. INPUT POWER 2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-30. Resistance Measurements 2-32. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-30. Control and Display 4-4. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/ Disassembly 4-9. Cleaning		1-7.	SPECIFICATIONS	1-1
2-3. SHIPPING INFORMATION 2-6. INPUT POWER 2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-30. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-30. A/D Converter 3-3-31. Control and Display 3-4. Introduction 3-6. Input Signal Conditioners 3-19. A/D Converter 3-10. Control and Display 3-11. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning	2	OPER	ATING INSTRUCTIONS	2-1
2-6. INPUT POWER 2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-30. Resistance Measurements 2-31. INTRODUCTION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. A/D Converter 3-30. A/D Converter 3-31. INTRODUCTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-1.	INTRODUCTION	2-1
2-8. RACK INSTALLATION 2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-31. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-3.		2-1
2-10. OPERATING FEATURES 2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-30. Resistance Measurements 2-32. OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-6.	INPUT POWER	2-1
2-12. OPERATING NOTES 2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-8.	RACK INSTALLATION	2-1
2-14. Measurements Restrictions 2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3-1. INTRODUCTION 3-1. INTRODUCTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. C1RCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-30. Control and Display 3-31. CONTROL DESCRIPTION 3-31. INTRODUCTION 3-31. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-10.	OPERATING FEATURES	2-1
2-16. AC Line Connection 2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-31. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-12.	OPERATING NOTES	2-1
2-18. Input Voltage Limits 2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-30. A/D Converter 3-30. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-14.	Measurements Restrictions	2-3
2-20. DC Zero 2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-16.	AC Line Connection	2-3
2-22. Autorange 2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-18.	Input Voltage Limits	2-3
2-24. Guarded Measurements 2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-20.		2-3
2-30. Resistance Measurements 2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-22.	Autorange	2-4
2-32. OPERATION 3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-24.	Guarded Measurements	2-4
3 THEORY OF OPERATION 3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-30.	Resistance Measurements	2-5/2-6
3-1. INTRODUCTION 3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		2-32.	OPERATION	2-5/2-0
3-3. OVERALL FUNCTIONAL DESCRIPTION 3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning	3	THEO	RY OF OPERATION	3-1
3-4. Introduction 3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-1.	INTRODUCTION	3-1
3-6. Input Signal Conditioners 3-12. A/D Converter 3-15. Control and Display 3-18. C1RCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-3.	OVERALL FUNCTIONAL DESCRIPTION	3-1
3-12. A/D Converter 3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-4.	Introduction	3-1
3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-6.	Input Signal Conditioners	3-1
3-15. Control and Display 3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-12.	A/D Converter	3-3
3-18. CIRCUIT DESCRIPTION 3-21. Input Signal Conditioners 3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-15.		3-3
3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-18.		3-3
3-29. A/D Converter 3-33. Control and Display 4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-21.	Input Signal Conditioners	3-4
4 MAINTENANCE 4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-29.	A/D Converter	3-4
4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		3-33.	Control and Display	3-5
4-1. INTRODUCTION 4-3. SERVICE INFORMATION 4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning	4	MAIN.	TENANCE	4-1
4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning				4-1
4-6. GENERAL MAINTENANCE 4-7. Access/Disassembly 4-9. Cleaning		4-3.	SERVICE INFORMATION	4-1
4-9. Cleaning		4-6.	GENERAL MAINTENANCE	4-1
4-9. Cleaning		4-7.	Access/Disassembly	4-1
		4-9.		4-2
TAX ENDER A SEPTEMBELLE SELECTION OF SELECTI		4-11.	Fuse Replacement	4-2
4-13. LED Replacement		4-13.		4-2
4-15. PERFORMANCE TEST		4-15.		4-3

TABLE OF CONTENTS, continued


	4-17.	Initial Procedure	4-3
	4-19.	DC Volts Test	4-3
	4-21.	Autoranging Test	4-3
	4-23.	CALIBRATION ADJUSTMENTS	4-4
	4-25.	Initial Procedure	4-4
	4-27.	DC Zero	4-4
	4-29.	DC Bias	4-4
	4-31.	VDC Function and Ranges	4-4
	4-33.	Options	4-5
	4-35.	TROUBLESHOOTING	4-5
	4-39.	Power Supply Check	4-6
	4-42.	Fault Area Isolation	4-7
	4-61.	REPAIR NOTES	4-10
5	LIST (OF REPLACEABLE PARTS	5-1
	5-1.	INTRODUCTION	5-2
	5-4.	HOW TO OBTAIN PARTS	5-2
6	OPTIC	ON AND ACCESSORY INFORMATION	6-1
7	GENE	RAL INFORMATION	7-1
7A	MANU	AL CHANGE INFORMATION	7A-1
8	SCHE	MATIC DIAGRAMS	8-1

List of Illustrations

FIGURE	TITLE	PAGE
	Fontispiece	vi
1-1	Model 8810A Outline Drawing	
2-1	Controls, Indicators, and Connectors	
2-2	Input Terminal Connectors	2-4
2-3	Input Terminal Connections for Resistance Measurements	
3-1	Functional Block Diagram	3-2
3-3	VDC Buffer Simplified Circuit Diagram	
3-4	A/D Converter Simplified Circuit Diagram	3-5
4-1	Calibration Adjustment Locations	4-4
4-2	Power Supply Voltage Test Points	4-6
4-3	TP1 Waveform	4-9
4-4	TP17 Compare Signal	4-9
4-5	A/D Integrator Output	
4-6	A/D Converter Control Signal Timing	
5-1	Final Assembly	
5-2	Al Main PCB Assembly	5-9
5-3	A2 Front Panel Assembly	5-11
5-4	A2A1 Display PCB Assembly	5-13
600-1	Rackmount Installation	600-2
600-2	Deluxe Test Lead Kit (A80)	600-2
600-3	Accessory Probes	600-3
602-1	Recommended Handshaking Connections	602-2
602-2	DOU Timing Diagram	602-3
602-3	DOU PCB Assembly	602-5
607-1	Installing The Lockout Strip	607-1
607-2	Ohms Converter PCB Installation Details	
607-3	Ohms Converter Simplified Circuit Diagram	607-2
607-4	Ohms Converter PCB Assembly	607-5
608-1	Lockout Strip Installation Instructions	608-1
608-2	AC Converter Installation Details	608-2
608-3	AC Converter Simplified Circuit Diagram	608-2
608-4	AC Converter PCB Assembly	608-5
609-1	True RMS Converter PCB Installation Details	
609-3	True RMS Converter Simplified Circuit Diagram	609-2
609-4	True RMS Converter Test Point And Adjustment Locations	
609-5	True RMS Converter PCB Assembly	609-7

List of Tables

TABLE	TITLE	PAGE
1-1.	Options and Accessories	1-1
1-2.	8810A Specifications	1-2
1-3.	Option Specifications	1-4
2-1.	Controls, Indicators, and Connectors	2-2
2-2.	Maximum Input Voltage for all Functions and Ranges	2-3
2-3.	Measurement Instruction	2-5/2-6
4-1.	Required Test Equipment	4-2
4-2.	DC Voltage Test	4-3
4-3.	DC Linearity Check	4-5
4-4.	Problem Area Isolation	4- 7
4-5.	VDC Buffer Gain Control	4-8
4-6.	Resistor Selection Procedure	4-11
4-7.	Offset Voltage Correction Resistors (Coarse)	4-12
4-8.	Offset Voltage Correction Resistors (Fine)	4-12
602-1.	DOU Connector/Signal Identification	602-2
602-2.	DOU PCB Assembly	602-4
607-1.	Resistance Checks	607-3
607-2.	Ohms Converter PCB Assembly	607-4
608-1.	AC Voltage Checks	608-3
608-2.	AC Voltage Range Adjustments	608-3
608-3.	AC Converter PCB Assembly	608-4
609-1.	AC Voltage Checks	609-3
609-2.	AC Voltage Range Adjustments	609-5
609-3.	True RMS Converter PCB Assembly	609-7
8-1.	Mnemonics	8-2



8810A Digital Multimeter

Section 1

Introduction & Specifications

1-1. INTRODUCTION

- 1-2. The Model 8810A is a 5½-digit, fully guarded digital multimeter designed for use in bench-top or rack mounted applications. It features five dc voltage ranges, autoranging, dual-slope a/d conversion, auto polarity, overload protection, and an automatic display-overload indication.
- 1-3. DC voltage measurement capabilities include five ranges from 200 mV to 1200V with a maximum sensitivity of 1 μ V. Circuit loading is virtually eliminated on the 200 mV, 2V and 20V ranges by an input resistance $> 10^9$ ohms. The resistance is $10^7\Omega$ on the 200V and 1200V ranges. Each range can be manually selected by depressing an appropriate front panel range switch. Autorange can also be manually selected as a range. It offers convenient operation plus optimum accuracy and resolution when frequent range changes are required. All dc voltage ranges will withstand the continuous application of inputs up to 1000V dc or 1100V peak ac.
- 1-4. Measurement data is displayed on a $5\frac{1}{2}$ -digit LED readout. The readout is continuously updated and includes decimal point, polarity (Vdc only) and a 200 mV dc range annunciator ($20\,M\Omega$ and 200Ω annunciators are also included for use with the Ohms Converter Option). When a range overload occurs (full scale count of 199999 is exceeded) the display will flash 188888 as an overload indication.
- 1-5. Measurement capabilities of the 8810A can be increased by the addition of one or more of the available options and accessories listed in Table 1-1. All options, with the exception of the Digital Output Unit, are field installable by the user, if calibration facilities are available. Options may be ordered at time of purchase or at a later date. The basic 8810A will accommodate 1 Ohms Converter Option, 1 AC Converter Option

and/or I - Digital Output Unit. All available options and accessories are described in detail in Section 6 of this manual.

Table 1-1. Options and Accessories

DESCRIPTION				
Rack Mounting Kit				
Deluxe Test Lead Kit				
High Voltage Probe				
High Frequency Probe				
High Frequence Probe				
Temperature Probe				
Digital Output Unit 1				
Ohms Converter 2				
AC Converter 2				
True RMS Converter 2				

1 Must be installed at factory or service center.

Field installable if calibration facility is available.

1-6. The 8810A is available in two line power configurations, 115/230V ac, 50 or 60 Hz; or 100V ac, 50 Hz. A slide switch allows voltage selection for the 115/230V ac model.

1-7. SPECIFICATIONS

- 1-8. Specifications for the 8810A and its available options are given in Tables 1-2 and 1-3, respectively. Accessory specifications are included in Section 6 of this manual.
- 1-9. Accuracy specifications for the 8810A are stated as \pm (x% of input +y% digits of error), where

x is the input signal measurement accuracy and y is instrument error with no input signal. For example: assume a 10V dc input (10000 digits) on the 20V dc range. The stated accuracy is $\pm (0.005\%$ of input +2 digits).

Calculation yields an overall accuracy of $\pm (0.005\%$ of 10000 digits +2 digits) = $\pm (5 + 2) = \pm (7 \text{ digits})$. Therefore, for an absolute 10V dc input the 8810A will read between 9.9993 and 10.0007.

Table 1-2. 8810A Specifications

CVOLTAGE		
Ranges		 ±200 mV, ±2V, ±20V, ±200V, ±1200V
Accuracy		
24 Hour, 23°C ±1°C 200 mV range		 ±(0.005% of input + 2 digits)
90 days, 18°C-28°C		-
200 mV range		 ±(0.01% of input + 3 digits)
Temperature Coefficient		
0°C-18°C, 28°C -50°C 200 mV range		 ±(0.0007% of input + 1 digit) /°C ±(0.0007% of input + 1 digit) /°C
DC Input Resistance		
200 mV-20V range		
Normal Mode Noise Rejection		 ≥60 dB @ 50 Hz and 60 Hz
Common Mode Noise Rejection		 \geqslant 120 dB @ dc to 60 Hz (with 1 k Ω in either lead)
Resolution	٠	 $1\mu V$ on $200 mV$ range
Ranging		 Full autoranging or manual ranging
Polarity		 Automatic bipolar, + or — display
Overload Protection	•	 200V, 1200V range; ±1200V dc, 1700V peak ac 200 mV-20V range; ±1000V dc, 1400V peak ac
Offset Current (at 23°C)	•	 Less than 15 pA on any range. Temperature coefficier of $\pm 5 \text{ pA}/^{\circ}\text{C}$
Zero Stability		 Better than 10 μV for 90 days after 1 hour warm-up
Response Time to Rated Accuracy within Range		 1 second maximum to displayed input
Response Time to Rated Accuracy within Range		`
ENVIRONMENTAL Stores Townseture		40° C 75° C
Storage Temperature		
Operating Temperature		
Humidity Range	•	 70% R.H., + 35° C to +50° C 80% R.H., +5° C to +35° C

Table 1-2. 8810A Specifications (cont)

ENERAL	
Function	. Selected via front panel controls
Range	. Full autoranging or manually selectable via front panel controls
Autorange Rate	. 600 ms maximum per range change
Display	. 7 segment 0.3" LED display, automatic decimal location
Reading Rate	. 2.5 readings per second, within the same range
Overload Indication	. Flashing Display of +188888 (built-in segment test of LED display) for out of range indication
MTBF	. 10,000 hours calculated, minimum
Maximum Common Mode Voltage	. 1000V dc or peak ac
Maximum LO to GUARD Voltage	. 100V dc or peak ac
Power	. 110/230V ac ±10%, 50 or 60 Hz or 100 Vac ±10% 50 Hz 8 watts
Size	. Maximum dimensions (see Figure 1—1) 8,03 cm x 22,86 cm x 36,07 cm (3.16 " high x 9.0" wide x 14.2" long)
Weight	. 3.0 kg (6.5 pounds)




Figure 1-1. Model 8810A Outline Drawing

Table 1-3. Option Specifications

		-
Option –002 Data Output Unit		
Available Data	Digits, Polarity (both logic Senses), and Range.	
	Isolated BCD, with compatible TTL/DTL levels.	
	8-4-2-1 BCD positive-true parallel (negative-true easily obtained by changing output buffers).	
Logic Levels	"1" = +5V, "0" = 0V	
Drive Capability		
Flags	Busy, not Busy, and Overload	
Controls		
Option –007 Ohms Converter		
Ranges	200 Ω , 2 k Ω , 20 k Ω , 200 k Ω , 2000 k Ω , 20 M Ω	
Resolution		
Configuration	Four-terminal measurement on all ranges	
Ranging	Full autoranging or manual range	
Accuracy		
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	±(0.008% of input + 2 digits) ±(0.02% of input + 2 digits)	
$(90 \text{ day, } 18^{\circ}\text{C}-28^{\circ}\text{C})$ $200\Omega \text{ range} \qquad . \qquad . \qquad .$ $2 \text{ k}\Omega-200 \text{ k}\Omega \text{ range} \qquad . \qquad . \qquad .$ $2000 \text{ k}\Omega \text{ range} \qquad . \qquad . \qquad .$ $20 \text{ M}\Omega \text{ range} \qquad . \qquad . \qquad . \qquad .$	±(0.01% of input + 3 digits) ±(0.05% of input + 3 digits)	
Temperature Coefficient		
200 Ω range	$\pm (0.001\% \text{ of input} + 1 \text{ digit})/^{\circ} \text{ C}$ $\pm (0.005\% \text{ of input} + 1 \text{ digit})/^{\circ} \text{ C}$ $\pm (0.02\% \text{ of input} + 1 \text{ digit})/^{\circ} \text{ C}$	
Range		
Maximum Current Through Unknown	1 mA 1 mA 250 μA 25 μA 2.5 μA 0.25 μΑ	
Overvoltage Protection	300 V rms or dc, applied continuously to any range	
Maximum Open Circuit Voltage	3.3 volts	
Response Time		
200 Ω –200 k Ω range	1.0 second maximum to displayed input 3.0 seconds maximum to displayed input	

Table 1-3. Option Specifications (cont)

Option -008 AC Converter	
Ranges	2V, 20V, 200V, 750V
Accuracy 2V-200V ranges (100% to .1% of range) 24 Hour, 23°C ±1°C	
100 Hz—10 kHz	
45 Hz-100 Hz, 10 kHz-20 kHz	±(0.1% of input +20 digits)
20 kHz–100 kHz	±(1.0% of input +60 digits)
90 days, 18°C—28°C	110 40/ C' 140 divisa)
100 Hz – 10 kHz	
45 Hz—100 Hz, 10 kHz—20 kHz	and the second second
	=\(\(\text{1.0}\)\(\text{01 input 300 digital}\)
750V range (100% to .1% of range) 90 days, 18°C—28°C (1V to 500V input)	
100 Hz-10 kHz	
45 Hz-100Hz, 10 kHz-20 kHz	±(0.25% of input +40 digits)
(500V to 750V input)	
100 Hz10 kHz	±(0,3% of input +20 digits)
45 Hz-100 Hz, 10 kHz-20 kHz	±(0,5% of input +40 digits)
Temperature Coefficient (0°C-18°C, 28°C-50°C)	$\pm (0.008\% \text{ of input } + 2 \text{ digits})/^{\circ}\text{C}, 2V-200V \text{ range}$ $\pm (0.008\% \text{ of input } + 4 \text{ digits})/^{\circ}\text{C}, 750V \text{ range}$
Input Impedance	2 megohms shunted by less than 100 pF
Response Time to Rated Accuracy within Range	1,5 second maximum to displayed input
Ranging	Full autoranging or manual ranging
Overload Protection	750V dc or rms sinewave, not to exceed 2×10^7 volts hertz product.
Resolution	10 μV on 2V range
Option –009 True RMS Converter	
Ranges	2V, 20V, 200V, and 750V
Resolution	
Accuracy	
24 Hours, 23°C ±1°C, 1%-100% of range	
45 Hz—100 Hz	±(0.25% of input +100 digits)
100 Hz–20 kHz	±(0.15% of input +100 digits)
20 kHz–50 kHz	
50 kHz–100 kHz	±(0.80% of input +300 digits)
90 days, $18^{\circ}\text{C}-28^{\circ}\text{C}$, $1\%-100\%$ of range	
45 Hz—100 Hz	±(0.40% of input +100 digits)
100 Hz – 20 kHz	±(0.20% of input + 100 digits)
20 kHz – 50 kHz	
50 kHz–100 kHz	Little Other Control

Table 1-3. Option Specifications (cont)

F" = |




static awareness



A Message From

John Fluke Mfg. Co., Inc.




Some semiconductors and custom IC's can be damaged by electrostatic discharge during handling. This notice explains how you can minimize the chances of destroying such devices by:


- 1. Knowing that there is a problem.
- 2. Learning the guidelines for handling them.
- 3. Using the procedures, and packaging and bench techniques that are recommended.

The Static Sensitive (S.S.) devices are identified in the Fluke technical manual parts list with the symbol " 🚫 "


The following practices should be followed to minimize damage to S.S. devices.




1. MINIMIZE HANDLING




2. KEEP PARTS IN ORIGINAL CONTAINERS UNTIL READY FOR USE.




3. DISCHARGE PERSONAL STATIC BEFORE HANDLING DEVICES




4. HANDLE S.S. DEVICES BY THE BODY



5. USE ANTI-STATIC CONTAINERS FOR HANDLING AND TRANSPORT




6. DO NOT SLIDE S.S. DEVICES OVER ANY SURFACE




7. AVOID PLASTIC, VINYL AND STYROFOAM® IN WORK AREA

PORTIONS REPRINTED
WITH PERMISSION FROM TEKTRONIX, INC.
AND GENERAL DYNAMICS, POMONA DIV.



8. WHEN REMOVING PLUG-IN ASSEMBLIES, HANDLE ONLY BY NON-CONDUCTIVE EDGES AND NEVER TOUCH OPEN EDGE CONNECTOR EXCEPT AT STATIC-FREE WORK STATION. PLACING SHORTING STRIPS ON EDGE CONNECTOR USUALLY PROVIDES COMPLETE PROTECTION TO INSTALLED SS DEVICES.



- HANDLE S.S. DEVICES ONLY AT A STATIC-FREE WORK STATION
- ONLY ANTI-STATIC TYPE SOLDER-SUCKERS SHOULD BE USED.
- 11. ONLY GROUNDED TIP SOLDERING IRONS SHOULD BE USED.

Anti-static bags, for storing S.S. devices or pcbs with these devices on them, can be ordered from the John Fluke Mfg. Co., Inc.. See section 5 in any Fluke technical manual for ordering instructions. Use the following part numbers when ordering these special bags.

John Fluke Part No.	Description
453522	6" X 8" Bag
453530	8" X 12" Bag
453548	16'' X 24'' Bag
454025	12'' X 15'' Bag
Pink Poly Sheet	Wrist Strap
30"x60"x60 Mil	P/N TL6-60
P/N RC-AS-1200	\$7.00
\$20.00	

Section 2

Operating Instructions

2-1. INTRODUCTION

2-2. This section contains information regarding the installation and operation of the Model 8810A. The contents of this section should be read before operating the digital multimeter. Should any difficulties be encountered during operation, contact your nearest John Fluke Sales Representative or the John Fluke Mfg. Co., Inc., P.O. Box 43210, Mountlake Terrace, Washington, 98043. Telephone (206) 774-2211. A list of Sales Representatives is located in Section 7 of this manual.

2-3. SHIPPING INFORMATION

- 2-4. The Model 8810A was packaged and shipped in a foam-packed cardboard carton. After unpacking the unit, a thorough inspection should be made to reveal any damage that may have occurred in transit.
- 2-5. If reshipment becomes necessary, the instrument should be repackaged in the original container. If the original container is not available, a new one can be obtained from the John Fluke Mfg. Co., Inc. Please reference the model number (8810A) when requesting a new shipping container.

2-6. INPUT POWER

WARNING

TO AVOID ELECTRICAL SHOCK DISCONNECT THE 8810A FROM LINE POWER BEFORE REMOVING THE UNIT'S CASE. DO NOT APPLY POWER WHILE THE CASE IS REMOVED.

- 2-7. The 8810A is supplied in one-of-two line power configurations: 115/230V ac, 50 or 60 Hz; or 100V ac, 50 Hz. On the 115/230 volt units, an interior slide switch is provided for selecting the appropriate voltage. Use the following procedure to set this switch.
- 1. Remove power cord from ac line.
- 2. Remove two screws on back panel and pull the unit from its case. The line voltage switch is a slide switch located on the rear portion of the Main PCB Assembly.
- 3. Refer to the rear panel decal and set the line voltage switch to the local line voltage (115 or 230V ac).

2-8. RACK INSTALLATION

2-9. The 8810A can be mounted in a standard 19 inch equipment rack using a Fluke Model M00-200-625 rack mounting accessory kit. Installation instructions are supplied with the kit, and appear in Section 6 of this manual.

2-10. OPERATING FEATURES

2-11. The 8810A front panel controls, indicators, and connectors are shown in Figure 2-1, and described in Table 2-1.

2-12. OPERATING NOTES

2-13. The following paragraphs describe various conditions which should be considered before attempting to operate the 8810A.




Figure 2-1. Controls, Indicators, and Connectors

Table 2-1. Controls, Indicators, and Connectors

RÈF. NO.	NAME	FUNCTION
1	INPUT and Ω SENSE Terminals	Provide input connections for ac and dc voltage measurements. Also serve as sense connections for four-terminal resistance (k Ω) measurements.
2	Ω SOURCE Terminals	Provide current source connections to unknown resistor for four-terminal resistance (k Ω) measurements.
3	20 M Ω Annunciator	LED indicator lights when 20 M Ω range is selected.
4	200 mVDC, 200Ω Annunciators	LED indicator lights when 200 mVDC/200 Ω range is selected.
5	Polarity Indicator	Displays polarity (+ or —) of input signal when making dc voltage measurements.
6	Display	A 4-1/2 digit readout for displaying the value of the measured input signal.
7	POWER Switch	A press-press switch for turning the instrument ON or OFF.
8	RANGE Switch	Interlocked press-on switches that allow range selection for enabled measurement function (DCV, ACV, $k\Omega$). Autorange (AUTO) is included.
9	FUNCTION switches	Interlocked, press-on switches for selecting desired measurement function; DCV, ACV, $k\Omega$. ACV and/or $k\Omega$ switch may be mechanically locked to prevent depression if the option is not installed.
10	DC ZERO Adjustment	Screw driver adjustment for zeroing the dc input amplifier. (Short HI-LO INPUT terminals, select 200 mVDC, zero display ± 1 digit).
11	GUARD Terminal	Provides connection to internal voltmeter guard.

2-14. Measurement Restrictions

2-15. The basic 8810A is capable of making only de voltage measurements. However, its measurement capacity can be expanded through the use of field installable options to include resistance and ac voltage measurements. Operating instructions for the added functions are included in this section of the manual. Detailed installation instructions, theory, maintenance, parts list, and schematics are included in Section 6. If the VAC and/or k Ω FUNCTION switch on your instrument cannot be easily depressed, the corresponding option is not installed.

NOTE

The 8810A front panel includes all of the controls, indicators, and connectors required to accommodate the maximum legal combination of options; i.e., 1-AC Converter, 1-Ohms Converter, and/or 1-Digital Output Unit.

2-16. AC Line Connection

2-17. The line power cord is a three-prong, polarized connector which permits the 8810A to be connected to line power. The ground lead on the power cord is connected to chassis ground through the 8810A power supply and should be connected to a high quality earth ground.

2-18. Input Voltage Limits

2-19. The maximum voltage limits that may be applied between adjacent input terminals without damaging the 8810A are given in Table 2-2. These limits may change with selected function.

CAUTION

To avoid instrument damage do not exceed the input voltage limits given in Table 2-2.

2-20. DC Zero

- 2-21. Before attempting to make precise dc voltage or resistance measurements the 8810A should be energized and allowed to stabilize at the ambient temperature for at least 30 minutes. Then the DC ZERO on the 8810A front panel should be adjusted. Use the following procedure to make this adjustment:
- 1. Connect a shorting wire between the HI-LO INPUT terminals on the 8810A.
- 2. Depress both the VDC and the 200 mV switches.
- 3. Using a small screw driver or adjustment tool, adjust the front panel DC ZERO control for a display reading of 00.000 ± 1 digit.
- 4. The 8810A is now prepared to measure dc voltages and resistance within its accuracy specifications.

Table 2-2. Maximum Input Voltage for all Functions and Ranges

<u> </u>	FUNCTION/RANGES					
INPUT TERMINALS	VE	С	VAC	kΩ		
	200 mV to 20V	200V to 1200V	ALL RANGES	ALL RANGES		
INPUT HI to INPUT LO	1000V dc	1200V dc	750V ac rms*	300V dc or ac rms		
Ω SOURCE HI to Ω SOURCE LO	1200V dc	1200V dc	750V ac rms*	300V dc or ac rms		
INPUT HI to Ω SOURCE HI (Shorting link removed)	0.5V	0.5V	0.5V	0.5V		
INPUT LO to Ω SOURCE LO (Shorting link removed)	0.5V	0.5∨	0.5V	0.5V		
INPUT LO to GUARD	100V	100∨	100V	100∨		
GUARD to Earth Ground	1000∨	1000∨	1000V	1000V		

Option —008 (Avg. AC Option), 750V dc max.
Option —009 (True RMS Option), 500 V dc max.

2-22. Autorange

2-23. The 8810A is capable of autoranging in any of its available measurement functions. Up-ranging occurs when the display digits are \approx 190000 or larger (disregard decimal point). Down-ranging occurs when the display digits are \approx 18000 or smaller.

2-24. Guarded Measurements

- 2-25. The 8810A employs a system of shields and guards that function, when properly connected, to minimize common mode to normal mode signal conversion. The common mode signal, represented by Ecm in Figure 2-2 is the difference in potential between the outer case ground of the multimeter and the ground of the voltage source being measured. This common mode potential can be caused by voltage differences in the ground lines or currents induced in them.
- 2-26. The input lead and terminal-link configuration illustrated in Figure 2-2A is for unguarded measurements; the most commonly used method. In this configuration it is possible for the common mode voltage (Ecm) to supply common mode current (Icm) via the test lead on the low input terminal, the guard to low-input shorting link, through the inner guard to outer case stray leakage paths, and back to the common mode source. This common mode current flow will cause a normal mode voltage drop across the lead resistance that will add to or subtract from the input voltage being measured. When the lead resistance increases (caused by long input

leads or poor connections) or the common mode voltage increases, the resulting normal mode voltage error also increases. This can cause a noticeable error in the multimeter display.

- 2-27. The guard terminal on the 8810A front panel can be connected in a way that provides a signal path for the common mode current other than through the input leads carrying the normal mode voltage signal. These terminal connections, illustrated in Figure 2-2B, provide for a guarded measurement of the applied input.
- 2-28. Guarded measurements can be obtained when the following conditions are met:
- 1. Remove link connecting guard terminal and low input.
- Connect shield of the input leads to the guard terminal.
- 3. Connect input end of the shield to same point as the input low lead.
- 2-29. The above conditions, when met, will effectively extend the inner guard of the instrument out to the end of the input leads. The common mode current will then flow through the shield on the input leads to the guard terminal, across the inner guard to the outer case stray-leakage paths, and back to ground. Therefore, the current no longer flows through the input lead to create the normal mode error voltage.




Figure 2-2. Input Terminal Connections

2-30. Resistance Measurements

2-31. The 8810A uses a constant current source and comparison technique for converting unknown resistance values into equivalent voltages. When a $k\Omega$ function and ranges is selected, a known constant current source is developed between the HI-LO OHM SOURCE terminals. When an unknown resistance is connected between these terminals an I-R drop is created across the resistor. The current source is calibrated in terms of 1, 10, 100, etc. to ensure that the I-R (voltage) drop is equivalent to the unknown resistance value. A pair of OHMS SENSE terminals (HI and LO) are connected across the resistor and serve as voltage input connections. The sensed voltage is measured in terms of voltage, and displayed as resistance. Obviously, this technique lends itself to either two- or four-terminal measurements. See Figure 2-3 for the recommended input connections.




Figure 2-3. Input Terminal Connections for Resistance Measurements

2-32. OPERATION

- 2-33. Use the following procedure to operate the 8810A:
- 1. Connect the unit to appropriate line power (See INPUT POWER earlier in this Section).
- 2. Set the POWER switch to ON (down).
- 3. Adjust DC ZERO if required.
- 4. Select desired measurement function (within instrument capabilities) and range by depressing the appropriate FUNCTION and RANGE switches. See Table 2-3.

NOTE

If a range is not manually selected and AUTO is not depressed the highest range for the selected function is enabled.

- Check and, if necessary, reposition the OHM SENSE and GUARD terminal shortinglinks.
- 6. If test leads are to be used, connect them to the appropriate INPUT terminals.
- 7. Connect the input signal (or resistance) and read the measured value on the display.

Table 2-3. Measurement Instruction

DESIRED	8810A CONFIGURATION				
MEASUREMENT	FUNCTION	RANGE	INPUT CONNECTIONS		
DC Voltage	VDC (Standard)	200 mV, 2, 20, 200, 1200, or AUTO	See Figure 2-2		
AC Voltage	VAC (Option 008 or –009)	2, 20, 200, 1200, or AUTO			
RESISTANCE	kΩ (Option —007)	200Ω, 2, 20, 200, 2000 kΩ, 20 MΩ, or AUTO	See Figure 2-3		

, . F

. .

Section 3

Theory of Operation

3-1. INTRODUCTION

3-2. The theory of operation for the 8810A is arranged under two major headings. The first, titled OVERALL FUNCTIONAL DESCRIPTION, discusses the overall operation of the instrument in terms of the functional relationship of the major circuits. The second heading is titled, SIMPLIFIED CIRCUIT ANALYSIS and deals with the internal operation of each major circuit. Block diagrams and simplified circuit diagrams are included to supplement the text. Detailed schematic diagrams are located in Section 8 of this manual.

3-3. OVERALL FUNCTIONAL DESCRIPTION

3-4. Introduction


3-5. The 8810A circuitry can be divided into three major sections. The first of the three sections, termed input signal conditioners, (see Figure 3-1) comprises the VDC Buffer and the optional Ohms Converter (-007) and AC Converter (-008 or -009). The second section is the A/D (analog-to-digital) Converter, and the third is the Control and Display section. The basic operational relationship of these functional areas is shown in Figure 3-1 and will be discussed in following paragraphs.

3-6. Input Signal Conditioners

3-7. The term, input signal conditioner, describes the basic function of the three subsections grouped under it. The VDC Buffer, Ohms Converter, and AC Converter

provide the A/D Converter with dc input voltage that is the analog equivalent of the input signal (ac volts, dc volts, or resistance) applied to the instrument. The basic path that each input signal follows as it is conditioned for the A/D Converter is illustrated in Figure 3-1.

- 3-8. When making a dc voltage measurement the unknown voltage applied to the HI and LO INPUT terminals is directed to the VDC Buffer. The buffer either amplifies the input voltage (200 mV range), passes the entire input voltage as in (2V range), or divides the input voltage by some power of ten (20, 200 and 1200V ranges), so that a conditioned signal of 2 volts dc at the A/D Converter is representative of a full scale input for all ranges.
- 3-9. When one of the AC Converters (Option -008 or -009) is installed and an ac range is selected, voltage inputs applied to the HI and LO INPUT terminals are directed through closed switch contacts to the AC Converter. These ac input voltages are then converted to dc voltages so that a full scale ac voltage input on any range will produce an AC Converter output to the A/D Converter of 2 volts dc.
- 3-10. When an Ohms Converter (Option -007) is installed, the 8810A is capable of making two- or four-terminal resistance measurements. The unknown resistance is connected between the HI-LO OHM SOURCE terminals which, in turn, are connected to the respective HI-LO INPUT terminals. The shorting links on the front panel make the connection for two-terminal ohms measurements and the input leads attached to the terminals make the connection during four-terminal ohms measurements.



F: F

Figure 3-1. Functional Block Diagram

3-12. A/D Converter

3-13. The A/D Converter used in the 8810A employs the dual slope integration technique. It receives its input from the appropriate Input Signal Conditioners and integrates it for 100 ms. Figure 3-2 is an illustration of the output of the a/d integrator. The slope of the integrator output voltage during the integrate period is proportional to the input applied to the instrument. At the end of the integrate period the signal conditioner output is disconnected from the a/d input and a dc reference voltage, of opposite polarity, is connected to the input (start of the read period). The A/D Converter then integrates the reference voltage so that the slope of the read period is always constant. Since the read period slope is held constant, the time required for the a/d integrator output voltage to return to the zero detect point is then proportional to the input signal level.

3-14. The digital representation of the input is obtained by counting the number of cycles of a clock oscillator frequency that occur from the start of the read period to the point where the a/d integrator output voltage returns to the zero detect level. The A/D Converter supplies the Control and Display section with a compare signal at the end of the read period. The compare signal stops the counting of the clock oscillator pulses so that the analog value of the instrument input is now digitally represented by the number of oscillator pulses counted.

3-15. Control and Display

3-16. The Control and Display section provides the control signals that direct the output of the correct input

signal conditioner to the A/D Converter during the integrate period. At the end of the integrate time period the Control and Display section connects the appropriate reference supply to the A/D Converter input for the read period. The output of a 1 MHz oscillator is used to maintain the proper timing of the control signals.

3-17. The clock oscillator pulse count, accumulated during the read period, is applied to the LED display to produce the digital readout of the instrument input signal. The range information for the selected range is used to position the decimal point and illuminate the proper display annunciator.

3-18. CIRCUIT DESCRIPTION

3-19. The following paragraphs provide an analysis of the functional areas of the 8810A at a simplified circuit level. The circuits described in these paragraphs correspond to the associated detailed schematic diagrams included at the end of this manual.

3-20. Component reference designators mentioned in the text identify the component on the simplified circuit drawings and on the schematic diagrams. The reference designators for integrated circuits containing two or more gates or functions are presented in text with a numeric suffix. This suffix corresponds to an integrated circuit pin of the particular gate or function. For example, the reference designator U11-6 identifies integrated circuit number 11 and the specific gate or function associated with pin 6.




Figure 3-2. A/D Converter Timing Diagram

3-21. Input Signal Conditioners

3-22. OPTIONAL CONVERTERS

3-23. The theory of operation for the optional Ohms Converter and the AC Converters is given in the appropriate subsections of Section 6. For the Ohms Converter See Option -007. The AC Converter and the True RMS Converter are Options -008 and -009, respectively.

3-24. VDC BUFFER

3-25. DC Voltage inputs applied to the instrument are conditioned by the VDC Buffer so that an input within any dc voltage range chosen produces a buffer output of 2 volts dc or less. The simplified buffer circuit shown in Figure 3-3 will be used to illustrate how the overall gain of the buffer is changed with range selection in order to maintain the required output. The optional ohms function also uses the VDC Buffer when determining the value of an unknown resistance. As indicated by the table in Figure 3-3 the buffer gain is 1 (unity) for the 2 K Ω through 20 M Ω ranges and 10 for the 200 Ω range.

3-26. When the 200 mV DC or 200Ω range is selected FET switches Q25 and Q20 close. This configuration produces a differential amplifier circuit gain of ten by returning only one-tenth of the amplifier output back to the inverting input. The VDC Buffer output through Q25 to the A/D Converter will be 2 volts for a full scale instrument input of 200 mV or 200Ω .

3-27. A differential amplifier circuit gain of one is obtained when the 2 or 200 VDC range, or $2 k\Omega$ through 20 M Ω range is selected. Range control signals from the Control and Display circuits close switches Q18 and Q25. Direct feedback through Q18 causes the differential amplifier to operate at unity gain. This amplifier circuit configuration produces the required 2 volt full scale input to the A/D Converter. Selecting the 200 volt range in the VDC function, in addition to configuring the differential amplifier circuit for unity gain, closes relay K5 to provide a 100:1 voltage divider (RN5-B, R21, and RN5-A) to reduce a full scale 200 volt instrument input to 2 volts at the amplifier input.

Ī

3-29. A/D Converter

3-30. The A/D Converter uses a dual-slope conversion technique. The dc voltage input to the A/D Converter, representing an unknown value of instrument input, is integrated (charges a capacitor) for a controlled length of time (100 ms). The level to which the capacitor is charged is directly proportional to the level of the dc voltage at the input. The capacitor is then discharged at a controlled rate so that the discharge time is proportional to the level of charge on the capacitor. A digital representation of the discharge time is obtained by counting the number of cycles of a reference frequency that occur from the start of discharge to the point where the capacitor charge reaches a selected zero detect level. Figure 3-4 is a basic illustration of the A/D Converter circuit.




Figure 3-3. VDC Buffer Simplified Circuit Diagram




Figure 3-4. A/D Converter Simplified Circuit Diagram

3-31. The input to the A/D Converter is selected from one of the three input signal conditioners. The selected input is applied to U3, a unity gain input buffer, during the integrate time period. The buffer output passes through Q39 to an integrator, the output of which is determined by the level of input applied. The integrator output charges capacitor C9 at a rate determined by the input signal level so that at the end of 100 ms the charge on the capacitor is directly proportional to the input signal applied. At the end of the integrate time period the integrator is isolated from the buffer when control signal △ 2 opens Q39 for 1 ms. This allows the input to U3 to be changed from the dc voltage representing the unknown input to the appropriate reference input without affecting the charge stored on C9.

3-32. The reference voltage passes through U3 and Q39 to the input of the integrator. Because the polarity of the reference voltage is opposite that of the unknown; the integrator starts to discharge capacitor C9. The rate of discharge is determined by the value of the reference voltage. The charge on C9 is applied to the input of amplifier U5. The amplified output is applied to one input of comparator U6. A dc voltage level, determined by the differential offset adjustment R88, is connected to the other comparator input. When the decreasing charge on C9 reaches the same level as that provided by the differential offset adjust, U6 will produce a compare (CM) output signal to stop the digital count in the Control and Display circuit.

3-33. Control and Display

3-34. The discussion of the Control and Display circuit operation that follows is referenced to the schematic diagrams in Section 8 of this manual. Operation in the VAC FUNCTION will be used as an example of circuit operation.

3-35. Selecting the VAC FUNCTION (switch S2 depressed) provided the AC Control command output at J2-2 and connects the INPUT HI terminal to the AC Converter (Option -008) input. The AC signal is applied to NAND gate in U15 and to switch U20 where it selects the ST2 (strobe 2) signal output for P2-14. With the proper gates enabled by the AC command, the outputs from U11, derived from the 1 MHz oscillator signal, provide timing commands to control the multimeter circuits during the ac volts measurement.

The measurement cycle starts with the INT (integrate) signal output at U11 pin 40. This signal is inverted by U15-5 to produce the INT command which, when combined with the AC command at U15-9, results in the INT-AC signal used to gate the AC Converter output into the A/D Converter during the integrate time period. As the INT signal U11-40 goes high, indicating the end of the 100 ms integrate time period, the \triangle 2 signal at U11-3 goes high for 1 ms while the input to the A/D Converter is switched from the unknown to the reference voltage. The reference supply signal comes from U11-39, DE (-R) (read period, negative reference). This signal is inverted by U13-14 and applied to U14-3. Since U14-5 is held high, unless the K Ω function is called, the DE (-R) • Ω command will gate the negative 1 volt reference to the A/D Converter input for the read time period.

3-37. At the end of the \triangle 2 signal, decade counters within U11 start to count the cycles of the 1 MHz oscillator input at U11-6. The count accumulation continues unit1 a compare (CM) signal from the A/D Converter is received at U11-5. The total in each decade counter is converted to a bcd format, identified as signals W, X, Y, and Z with corresponding bit weights of 8, 4, 2, and 1. The digit information is strobed out to the display from pins 34, 33, 32, and 31 of U11, one significant digit at a time.

Eight strobe signals numbered ST0 through ST7, are created within U11 to properly time the transfer of data from U11 to the display. Six strobe signals (ST0, ST1, ST2, ST3, ST4, and ST6) are used to transfer digit information and the remaining two (ST5 and ST7) transfer range, polarity and overland data. The most significant digit of the display is the first to be strobed out of U11. Strobe signal ST0 from U11-15 passes through switch U20-13 to U20-14 (VDC function causes the switch to shift to pin 12) to the display strobe driver O44 and Q45. The DS1 (display digit 1) output signal on P1-3 is applied to pins 1 and 14 of the most significant digit LED (DS1), enabling only that LED to display the incoming digit information. The same ST0 strobe signal is used within U11 to cause the bcd information for the most significant digit to be applied, via U11 pins 34, 33, 32, and 31, to the seven-segment decoder U16. The bcd code input causes the decoder to illuminate segments of the LED to display the corresponding number. Each LED is individually strobed to display the corresponding significant digit output from U11.

rs F

Section 4

Maintenance

WARNING

THESE SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

4-1. INTRODUCTION

4-2. This section of the manual contains information concerning maintenance and servicing of the Model 8810A Digital Multimeter. A calibration interval of 90 days is recommended to insure instrument operation within the 90 day specifications. Test equipment recommended for performance test, calibration adjustments and troubleshooting is listed in Table 4-1. If the recommended equipment is not available, equipment of equivalent specifications may be used.

4-3. SERVICE INFORMATION

- 4-4. Each instrument manufactured by the John Fluke Mfg. Co., Inc. is warranted for a period of 1-year upon delivery to the original purchaser. The WARRANTY is printed on the back of the title page located at the front of the manual.
- 4-5. Factory authorized calibration and service for each Fluke produce is available at various world wide locations. A complete list of these service centers is included with the WARRANTY. Shipping information is given in Section 2 of this manual. If requested, an estimate will be provided to the customer before any repair work is begun on instruments that are beyond the warranty period.

4-6. GENERAL MAINTENANCE

4-7. Access/Disassembly

- 4-8. The following procedure is used to gain access to the interior of the 8810A:
- I. Remove the line-power cord from the unit.
- 2. Remove the molded plastic outer cover; two screws at the rear of the unit hold it in place. This provides access to the calibration adjustments
- 3. Remove the top and bottom guard covers by sliding the covers one-half the distance to the rear of the unit, and then lift them free. This allows access to the components on the various printed circuit boards.

CAUTION

The area on the Display PCB Assembly where the input terminals extend through, must not be contaminated in any way. The inter terminal leakage caused by contamination will result in calibration errors.

4. Remove the optional AC Converter PCB (-008, -009) or Ohms Converter PCB (-007) by disconnecting the associated wires and pulling the pcb straight away from the Main PCB.

Table 4-1. Required Test Equipment

INSTRUMENT TYPE	REQUIRED CHARACTERISTICS	RECOMMENDED MODEL	
AC Calibrator	Voltage Range: 0 to 1000V ac Frequency Range: 50 Hz to 100 kHz Voltage Accuracy: 50 Hz to 20 kHz 0.03% 20 kHz to 100 kHz 0.05%	John Fluke Model 5200A and 5205A	
DC Calibrator	Voltage Range: 0 to 1000V dc Accuracy: 0.003%	John Fluke Model 332B	
Voltage Divider	Ratio Range: 0 to 1.0 Absolute Linearity: ±1 ppm of input at dial setting	John Fluke Model 720A	
Resistor Decade	Resistance Accuracy: 0.005%	ESI 1063B	
Oscilloscope	General Purpose with 10M Ω Probe	Tektronics Model 453	
Digital Multimeter	Voltage Accuracy: 0.1% Input Impedance: $10M\Omega$	*John Fluke Model 8000A	

If the selectable offset voltage correction resistor procedures are performed a DVM with a $1\mu V$ resolution is required; recommend a John Fluke 8400A or 8800A.

NOTE

When reinstalling the AC/RMS Converter and Ohms Converter PCB's, insure that all connector pins are properly aligned before seating the board.

4-9. Cleaning

- 4-10. Clean the instrument periodically to remove dust, grease and other contamination. Use the following procedure:
- 1. Clean the front panel and exterior surfaces with anhydrous ethyl alcohol or a soft cloth dampened with a mild solution of detergent and water.
- 2. If cleaning of the interior is necessary, use clean, dry air at low pressure (< 20 psi). If contaminants remain, individual pcbs can be cleaned using warm water. However, any items likely to be affected by the water (relays, meters, etc.) shoud be removed first. To remove excess water use clean, dry air followed by oven drying at ≤ 50°C. If any solvent is used, such as freon, it should be kept clear of any switches or potentiomenters since it removes lubrication and shortens their life span dramatically.

4-11. Fuse Replacement

WARNING!

AC LINE VOLTAGE IS PRESENT AT THE FUSE HOLDER WHENEVER THE POWER CORD IS CONNECTED. REMOVE THE POWER CORD BEFORE SERVICING THE FUSE.

4-12. The power fuse (F1) is located in the right rear corner of the instrument, and can be reached by performing the Access/Disassembly procedure. If replacement is necessary, use an AGC ¼ ampere fuse for either 115 or 230V ac line power.

4-13. LED Replacement

- 4-14. The following procedure is used to replace the Display or indicator LEDs:
- 1. Perform steps 1 through 3 of the Access/ Disassembly procedure.
- Disconnect the two flat cables at the Main PCB connectors.
- 3. Disconnect the wires from the connector posts on the Display PCB.
- 4. Remove the four side screws connecting the Front Panel to the side chassis. Lift the Front Panel away from the main portion of the instrument.
- 5. Remove the binding-post nuts and the two phillips screws, and lift the Display PCB away from the Front Panel.
- Unsolder and replace the defective LED.
- To reassemble logically reverse this procedure. Make sure that the switch lever fingers mesh between the crossbar and the lower retaining ring on each switch plunger.

4-15. PERFORMANCE TEST

4-16. The performance test is designed to compare the 8810A performance with the accuracy specifications given in Section 1 of this manual. It is recommended as an acceptance test when the unit is first received and later as a 90 day calibration procedure. If the instrument fails any part of the test, calibration adjustment and/or repair is indicated.

4-17. Initial Procedure

- 4-18. Each of the procedures that comprise the performance test assume that the following initial conditions exist:
- 1. The unit has stabilized and will be tested at an ambient temperature of $23 \pm 5^{\circ}$ C, and a relative humidity of less than 70%.
- 2. The unit has been connected to line power and the POWER switch is set to ON.
- 3. Set dc calibrator output to 0V dc and connect its output to the input of the resistive divider.

NOTE

The divider should be set to X1 for all specified voltages $\geq 2.0V$ dc. Maximum calibrator accuracy is attained by using the divider for lower voltage requirements.

4-19. DC Volts Test

- 4-20. Use the following procedure to test the operation and accuracy of the dc voltage function and its ranges:
- 1. Connect a shorting wire between the HI-LO INPUT terminals on the 8810A.
- 2. Depress both the VDC and the 200 mV switches on the 8810A.
- 3. Using a small screw driver or adjustment tool, adjust the front panel DC ZERO control for a display reading of 00.000 ± 1 digit.
- 4. Select the 2 VDC range on the 8810A. The display should read within the first display limits listed in Table 4-2 (.0000 ±1 digit).
- 5. Remove the shorting wire from the 8810A and connect the divider output to the HI-LO INPUT terminals.

6. Refer to Table 4-2 and sequentially set the de calibrator/divider output to each of the input voltages listed. At each voltage, select appropriate RANGE switch setting. Then compare the display reading with the appropriate limits and annunciator indications listed in the table.

Table 4-2. DC Voltage Test

RANGE	INPUT	DISPLAY LIMITS			ANNUNCIATOR
2 VDC	Shorted	00001	-	+.00001	
	+1.00000	+.99987	_	+1.00013	
	-1.00000	-1.00013	_	99987	Į
	+1.90000	+1.89978	_	+1.90022	İ
	1.90000	-1.90022	_	-1.89978	
20 VDC	+19.0000	+18.9978	_	+19.0022	
	-19.0000	-19.0022	_	-18.9978	
200 VDC	+190.000	+189.978	_	+190.022	
	-190.000	-190.022	_	-189.978	
1200 VDC	+1000.00	+999.87	_	+1000.13	:
	-1000.00	-1000.13	_	-999.87	
200 mV	+.10000	+99.980		+100.020	200m VDC
	10000	- 100.020		-99.980	200m VDC
AUTO	+.10000	+99.980	_	+100.020	200m VDC
	+1.00000	+.99987	_	+1.00013	
	+10.0000	+9.9987	_	+10.0013	
	+100.000	+99.987	_	+100.013	
	+1000.00	+999.87	_	+1000.13	

4-21. Autoranging Test

- 4-22. The following procedure verifies the accuracy of the range change voltage points for the autorange circuit:
- Connect the divider output to the 8810A HI-LO INPUT terminals.
- 2. Depress the VDC FUNCTION switch.
- 3. Depress the AUTO RANGE switch.
- 4. Adjust the dc calibrator/divider for a +200 mV dc output. The display should read +.19995 to +.20005.
- 5. Decrease the dc calibrator/divider output to 183 mV. The 8810A display should read +.18295 to +.18305.
- 6. Decrease the divider output in 1 mV steps until the 8810A autoranges. The meter should revert to the 200 mV range and the display should read between +177.500 and +182.500 mV.
- 7. Increase the divider output in 1 mV steps until the 8810A autoranges. The meter should step to the 2 VDC range and the display should read slightly more than +.19000.

4-23. CALIBRATION ADJUSTMENTS

4-24. Calibration adjustments are required after repair or whenever the 8810A fails the Performance Test. Equipment required is listed in Table 4-1. Perform the procedure at an ambient temperature of 23 +1°C and a relative humidity of 80% or less. Complete all adjustment procedures in the order given. See Figure 4-1 for adjustment locations.




Figure 4-1. Calibration Adjustment Locations

4-25. Initial Procedure

- 4-26. Each of the following calibration adjustment procedures assume that the following initial conditions have been met. Perform the following steps:
- 1. Remove the 8810A from its plastic outer case.
- 2. Do not remove the top inner guard cover.
- 3. Connect the 8810A to line power and set the POWER switch to ON.
- 4. Allow the 8810A to stabilize at ambient temperature for at least one-half of an hour.

5. Set the dc calibrator output to 0V dc and connect its output to the input of the resistive divider.

NOTE

The divider should be set to 1 for all specified voltages ≥ 2.0V dc. Maximum calibrator accuracy is attained by using the divider for lower voltage requirements.

4-27. DC Zero

- 4-28. Adjust the front panel DC ZERO pot (R37) as follows:
- 1. Connect a shorting wire between the HI-LO INPUT terminals.
- 2. Select the VDC function and the 200 mV range.
- 3. Adjust the DC ZERO pot for a display of 00.000 ± 1 digit.
- 4. Remove the short from the INPUT terminals.

4-29. DC Bias

- 4-30. Use the following procedure to adjust the DC Bias Resistor (R30):
- 1. Connect a 1 megohm resistor and a 0.1 μF capacitor in parallel between the HI-LO INPUT terminals.
- 2. Select the VDC function and the 200 mV range.
- 3. Adjust the Bias resistor, R30, for a display of 00.000 ± 3 digits.
- 4. Repeat the DC ZERO procedure and this procedure until no further adjustment of DC ZERO is required.
- 5. Remove the resistor and capacitor from the INPUT terminals.

4-31. VDC Function and Ranges

- 4-32. The following procedure is used to calibrate the VDC Function and Ranges:
- 1. Select the VDC function and the 2V range.
- 2. Connect the dc calibrator/divider output to the HI-LO INPUT terminals on the 8810A.

- 3. Adjust the dc calibrator divider for a + 1.0 mV input to the 8810A.
- 4. Alternately reverse the INPUT terminal connections (+1.0 mV and -1.0 mV) and adjust the MASTER OFFSET resistor (R78) for the same absolute number with either polarity as an input.
- 5. Apply +1 mV to the INPUT terminals and adjust DIFF OFFSET resistor (R88) for exactly +.00100 on the 8810A display. Occational flashing of +.00101 or +.00099 is acceptable.
- 6. Disconnect the dc calibrator/divider output from the 8810A and connect a short across the HI-LO INPUT terminals.
- 7. Select the 200 mV range and, if necessary, zero the display by adjusting the front panel DC ZERO pot.
- 8. Remove the short from the INPUT terminals and repeat steps I through 5 of this procedure. Adjust as required.
- 9. Select the 2V range and connect the dc calibrator/divider to the HI-LO INPUT terminals.
- 10. Adjust the dc calibrator/divider for a +1.00000V input to the 8810A.
- 11. Adjust the +1V CAL resistor (R99) for a display of +1.00000 ±1 digit.
- 12. Increase the input voltage to +1.90000V. The display must read 1.90000 ± 3 digits.
- 13. Reverse the 8810A INPUT terminal connections and adjust the dc calibrator/divider for a -1.00000V input.
- 14. Adjust the -IV CAL resistor (R97) for a display of -1.00000 ±1 digit.
- 15. Increase the input voltage to -1.90000V. The display must read -1.90000 ± 3 digits.
- 16. Refer to Table 4-3 and apply each of the positive and negative input levels shown. The display should read within ± 1 digit of the applied voltage.
- 17. Select the 20V range.
- 18. Apply a $\pm 10.0000V$ input to the 8810A and adjust the 10 VDC resistor (R47) for a display of $\pm 10.0000 \pm 1$ digit.
- 19. Decrease the 8810A input to ± 100.000 mV.

- 20. Select the 200 mV range. The display should read $\pm 100.000 \pm 4$ digits.
- 21. Reverse the 8810A INPUT connections. The display should read -100.000 mV ±4 digits.
- 22. Select the 200V range.
- 23. Adjust the dc calibrator/divider for a +100.000V input to the 8810A.
- 24. Adjust the 100 VDC resistor (R21) for an 8810A display of 100.000 ± 1 digit.
- 25. Select the 1200V range and increase the input signal to ± 1000.00 V. The display should read $\pm 1000.00 \pm 3$ digits.
- 26. Decrease the calibrator output to a safe level and disconnect it from the 8810A INPUT terminals.

Table 4-3. DC Linearity Check

Tubic 4-5. Do Linearity Oneck					
INPUT	DISPLAY				
± .00100 V	± .00100 ± 1 digit				
± .01000 V	± .01000 ± 1 digit				
± .10000 V	<u>±</u> .10000 <u>±</u> 1 digit				
± .20000 V	<u>±</u> .20000 <u>±</u> 1 digit				
<u>+</u> .30000 V	± .30000 ± 1 digit				
± .40000 V	<u>+</u> .40000 <u>+</u> 1 digit				
<u>+</u> .50000 V	<u>+</u> .50000 <u>+</u> 1 digit				
± .60000 V	<u>±</u> .60000 <u>+</u> 1 digit				
± .70000 V	± .70000 ± 1 digit				
± .80000 V	± .80000 ± 1 digit				
<u>+</u> .90000 V	± .90000 ± 1 digit				
<u>+</u> 1.00000 V	±1.00000 ± 1 digit				

4-33. Options

4-34. Calibration adjustments for each of the available options are included in Section 6 of this manual. If your instrument contains one or more of these options they may be calibrated in any sequence following the previous Calibration Adjustments procedure.

4-35. TROUBLESHOOTING



Static discharge can damage MOS components contained in the 8810A. To prevent this possibility use the following precautions when troubleshooting and/or repairing the unit.

- 1. Never remove, install or otherwise connect or disconnect pcb's and/or components without first setting the POWER switch to OFF.
- 2. Perform all repairs at a static free work station.
- Do not handle IC's or pcb's by their connectors.
- 4. Use static ground straps to discharge repair personnel.
- 5. Use conductive foam to store replacement or removed IC's.
- 6. Remove all plastic, vinyl and styrafoam products from the work area.
- 7. Use a grounded soldering iron.
- 4-36. The information given in the following paragraphs is provided to assist in isolating malfunctions in the 8810A. Before troubleshooting the instrument, however, it should be verified that the cause for the malfunction is actually in the instrument and not caused by faulty external equipment or improper control settings. For this reason, the performance test (given earlier in this section) is suggested as the first step in troubleshooting. The performance test may also help to localize the trouble to a particular section of the instrument.
- 4-37. The following reminders of basic fault isolation will help determine if the cause if the result of an internal malfunction or faulty external connection.
- 1. Carefully check the 8810A control settings: some false indications may be caused by an incorrect or overlooked control setting.
- 2. Check associated equipment: insure the associated equipment control settings and connections are correct.
- 3. Carefully inspect the interior of the instrument: check for physically damaged parts, loose or broken wires and improperly seated plug-in assemblies.
- 4-38. When it is determined, by the above checks, that the malfunction is within the 8810A the following procedure can be used to isolate the problem area. The recommended test equipment for troubleshooting is listed in Table 4-1.

4-39. Power Supply Check

4-40. Incorrect output voltages from any of the power supplies may cause the multimeter to exhibit various improper indications. The power supply voltages should be checked in the event of any instrument malfunction. Use the following procedure to check the

voltage output of each power supply. Figure 4-2 illustrates where the connections are to be made for checking each supply.

- 1. Connect the test equipment voltmeter common lead to INPUT LO terminal.
- 2. Connect the test equipment voltmeter high input lead to TP7 (\pm 18 volt supply). The supply output should be \pm 18.02 \pm 0.10 volts.
- 3. Connect the test equipment voltmeter high input lead to TP8 (-18 volt supply). The supply output should be -18.02 ± 0.10 volts.
- 4. Connect the test equipment voltmeter high input lead to the positive end of C18 (+35 volt supply). The supply output should be +35.0 ±5.0 volts (at 115V ac line voltage).
- 5. Connect the test equipment voltmeter high input lead to the negative end of C19 (-35 volt supply). The supply output should be -35.0 ±5.0 volts (at 115V ac line voltage).
- 6. Connect the test equipment voltmeter high input lead to TP9 and low input to TP8. The voltmeter should indicate $\pm 5.0 \pm 0.2$ volts.




Figure 4-2. Power Supply Voltage Test Points

- 4-41. The +18 volt, +7 volt supplies all share a common reference provided by U9. The -18 volt supply receives operating dc voltage from the +18 volt supply. Problems occurring in one supply may cause improper operation of the others. The following procedure provides for open loop operation of the supplies to aid in localizing the defective supply.
- 1. Unsolder and lift one end of R120.
- 2. Short pins 3 and 4 of U17 together. This will utilize the internal reference of U17 for control.
- 3. Check the voltage outputs of the +18 volt supply, TP7 (this supply may be out of prescribed tolerance limits because of the change to the U17 internal reference, +7 volt supply TP11. -7 volt supply TP11, -7 volt supply TP10 and -18 volt supply TP8).
- 4. Repair the faulty supply.
- 5. When all supplies are operating properly, remove the short from U17 pins 3 and 4, reconnect R120 an check the supplies for proper operation.

4-42. Fault Area Isolation

INDICATED

4-43. A malfunction in the 8810A may be isolated to a particular section of circuitry by observing the displayed symptoms during the multimeter operation in each function. The results of the Performance Tests will indicate the multimeter functions affected by the malfunction. The problem areas, indicated by the various improper functional displays, are presented in Table 4-4. Four vertical columns, describing the 8810A operational status in each of the three functions as being either proper or improper, indicate the functional area of the multimeter where the problem is most likely to be found.

Close observation of the symptoms displayed on the front panel coupled with a knowledge of the theory of operation (Section 3) may further define the problem area.

4-44. Troubleshooting information for each functional area is presented in the following paragraphs. Proceed to the paragraphs that provide the troubleshooting information for the problem area indicated by the fault area isolation procedure. Keep in mind, however, that a malfunction within one functional area may affect the operation of another.

4-45. AC CONVERTER (OPTION -008, -009)

do one of two things: create a dc voltage output without an ac input signal applied or, not produce the proper dc voltage for the A/D Converter when an ac input signal is applied. A dc output generated by the AC Converter will cause the multimeter display to indicate some value of ac voltage, in the two highest ranges, when a short is placed across the input terminals. When an ac signal is applied to the input, and the display remains at zero, the ac converter is not producing the proper dc output voltage to the A/D Converter.

4-47. VDC BUFFER

4-48. The 8810A front panel display will generally indicate a buffer malfunction in one of three ways. First, the display presents an overrange indication (flashing +188888) for all inputs applied to the instrument. Second, the display will not indicate any applied dc input; producing a displayed readout of 000000 plus two or three digits of noise. Third, the display indicates that some value of offset is being added to all inputs. This offset malfunction will usually produce a display indication even without an input applied to the instrument.

8810A FUNCTION	8810A OPERATION IN EACH FUNCTION IS				
DC V	PROPER	IMPROPER	PROPER	IMPROPER	
AC V	IMPROPER	PROPER	PROPER	IMPROPER	
OHMS	PROPER	IMPROPER	IMPROPER	IMPROPER	
PROBLEM AREA	AC CONVERTER	VDC BUFFER	OHM CONVERTER	A/D CONVERTER	

Table 4-4. Problem Area Isolation

OR

CONTROL AND DISPLAY 4-49. Malfunctions within the VDC Buffer may cause the display to be improper on one or two ranges and correct on the others. The overall gain of the buffer is changed for each range. Table 4-5 lists the five dc voltage ranges and the components that control the circuit configuration to produce the proper gain for each range. Noting the range or ranges affected by the malfunction may point to the gain control component or associated circuitry causing the problem.

4-50. OHMS CONVERTER (OPTION -007)

- 4-51. Use the following procedure when trouble-shooting malfunctions within the Ohms Converter. Remove the 8810A from the outer case. Remove the top inner guard cover. Select the $k\Omega$ function and the 200Ω range.
- 1. Connect a 1 OHM resistor across the Ω SOURCE terminals.
- 2. Measure the voltage drop across the 1 OHM resistor. The ohms converter should supply enough current to develop 1 ±0.3 mV across the resistor.
- 3. If the voltage across the resistor is less than 0.8 mV, short across Q2 emitter to collector. The voltage across the resistor should now be 0.8 mV or greater. If it is; Q21, Q1, Q2 or CR12 is causing the malfunction.
- 4. Overrange indications in the ohms function can be caused by a failure of Q6 to turn-on and apply the reference voltage to the A/D Converter. Q6 may be open or the gate signal may not be present during the read period.

- 5. Select the 20 k Ω range.
- 6. Measure the voltage drop across R29. The inverter should supply enough current to develop $-6.7V \pm 0.2V$ across R29.

, , E

- 7. If the voltage is less than -6.5V the problem is contained within the inverter, Q24, A25, or the clock input, which should be 1 MHz.
- 8. If the inverter checks out, test the voltage dropped across R26. It should be -2.5V ±0.5. If the voltage does not meet this specification, then the trouble is contained within the regulator, (Q22, Q23) and their associated components, or Q8, Q6, and Q4.

4-52. A/D CONVERTER OR CONTROL AND DISPLAY

- 4-53. If the display symptoms observed during the fault area isolation procedure indicate that the problem is either in the A/D Converter or Control and Display, the following procedure should aid in locating the faulty component. Because the timing of the control signals used to process the input signal through the A/D Converter and display circuits is critical to the proper operation of these sections, an oscilloscope should be used to make the voltage and signal checks.
- 4-54. The A/D Converter operation can be checked using the following procedure.
- 1. Select the VDC function and 2 volt range.
- 2. Apply ± 1 volt dc to the 8810A input terminals.
- 3. Measure the input to the A/D Converter at TP13. The voltage, TP13 high to the INPUT LO terminal, should be +1 volt dc.

RANGE	Q18	Ω25	Q23	020	K5	TOTAL BUFFER GAIN
200 mV	open	closed	open	closed	open	10
2 V	closed	closed	open	open	open	1
20 V	closed	open	closed	ореп	open	.1
200 V	closed	closed	open	open	closed	.01
1200V	closed	open	closed	open	closed	.001
	Q18, closes to provide a gain of one across Q14,Q15 & U1	Q25, closes to present full buffer output to A/D	Q23, closes to divide the buffer out- put by 10	Q20, closes to increase the gain of Q14,Q15 & U1 by 10	K5, closes to divide the buffer input by 100	

NOTE

Connect the oscilloscope external sync input via a X10 probe to TP16 during the remainder of this procedure. The scope control settings are provided on the wave shape illustration.

4. Connect the scope between TP1 (high) and the LO INPUT terminal. The scope should display the waveform shown in Figure 4-3.




Figure 4-3. TP1 Waveform

- 4-55. The waveform at TP1 can indicate several possible problems in the circuitry. The 100 ms period designated A is the integrate period during which the unknown 8810A input (in this case, 1 volt) is applied to the integrator (Q40 and U4). The 100 ms time designated B is the read period when the reference (in this case, -1 volt) is applied to the integrator. The length of period B (read) will change with a change in voltage level applied to the 8810A input within the range selected. The section designated C is the auto-zero period during which the A/D Converter input is shorted to ground, via Q38, to insure that the A/D starts from zero for each new integrate period.
- 4-56. If the 1 volt input during period A is not present, Q38 may be shorting the input to ground or Q31 may not be closing to apply the buffer output to the A/D. Time period B may indicate that the reference is low by not going to -1 volt. A low reference supply would also cause period B to lengthen. If the voltage level during time period B is unstable, the reference supply input FET Q35 or control Q34 may be faulty.
- 4-57. If the waveform at TP1 presents the proper 100 ms +1 volt indication during A then drops to -1 volt at the start of B but remains at -1 volt through C, the A/D Converter may not be supplying the control IC (U11) with the compare signal (CM). The compare signal can be checked at TP17 using the following procedure.

- 1. Connect the oscilloscope input to TP17.
- 2. The scope presentation shown in Figure 4-4 represents the proper compare signal for an 8810A input of +1 volt dc.
- 3. If this signal is present at TP17 proceed to control signal troubleshooting, in the following paragraphs.
- 4. If the compare pulse is not present or incorrect, either in amplitude or timing of the leading edge make the following check.
- 5. Move the oscilloscope input to TP2. The scope presentation should be as shown in Figure 4-5.




Figure 4-4. TP17 Compare Signal




Figure 4-5. A/D Integrator Output

4-58. The probable cause for an improper signal at TP2 would be a failure in Q40 or U4. If the voltage level remains at zero volts, the protection transistor, Q59, may be shorted or input FET Q39 open.

4-59. The timing signals that control the processing of inputs applied to the 8810A are developed within the custom IC, U11. A 1 MHz crystal (Y1) provides the base frequency from which the timing control signals are produced. Figure 4-6 illustrates the timing relationship between the control signals (INT., DE (+R), AZ, and \triangle 2), as they appear at RN3, and the integrator signal at TP2. An incorrect or missing control signal at RN3 may be caused by a failure in the logic control gates U13, U14, or U15.




Figure 4-6. A/D Converter Control Signal Timing

4-60. The logic control gates (U13, U14, and U15) and the custom integrated circuit U11 use the 5 volt difference in potential between the -18 volt supply and -13 volt supply for the logic control signal levels. The recommended method for observing the logic signals in this area is to attach the oscilloscope return to the INPUT LO terminal and watch the logic signals for level changes between -18 volt and -13 volt levels.

CAUTION

The oscilloscope return has been connected to the INPUT LO terminal for the waveform checks. For observation of the control signals on the pins of U11 or logic control gates (U13, U14, and U15) the oscilloscope return can be connected to TP8, the -18 volt supply. If this connection is made, insure that the oscilloscope return will not ground the -18 volt power supply. Damage to the 8810A circuitry WILL result from grounding TP8.

4-61. REPAIR NOTES

CAUTION

Static discharge can damage MOS components contained in the 8810A. To prevent this possibility during repair use the precautions given earlier under Troubleshooting.

į

- 4-62. If, during the course of repair, VDC Buffer components, Q14, Q15 and/or U1, are replaced, it will be necessary to also select and replace resistors R34 and R38. These resistors, when properly selected, allow the DC ZERO pot to rest at approximately mid-range after adjustment. Use the following procedure to select R34 and R38.
- Using a digital voltmeter (DVM) capable of reading IV dc with I μV resolution (Fluke Model 8400A, 8800A or equivalent) connect this low input lead to the 8810A LO INPUT terminal. Connect its high input to TP13 as shown in Figure 4-2.
- 2. Mechanically center the 8810A front panel DC ZERO pot (R37).
- 3. Energize the 8810A and select the VDC function, 200 mV range.
- 4. Connect a short between the 8810A HI-LO INPUT terminals.
- 5. Connect a shorting jumper across R34 and R38. See Figure 5-2. The digital voltmeter should read between -0.05000 to +0.05000V dc. Record the reading.
- 6. Replace the short between the HI-LO INPUT terminals with a 1 megohm $\pm 5\%$ resistor and a 0.1 μ F $\pm 10\%$ capacitor connected in parallel.
- 7. Adjust the BIAS ADJ pot (R30) for a display reading equal to the digital voltmeter reading recorded in step 5 (±5 digits).
- 8. Replace the resistor/capacitor at the INPUT terminals with a short circuit.
- 9. Observe the current digital voltmeter reading and complete the resistor selection procedure given in Table 4-6.
- 4-63. Use the following procedure to check the common mode rejection ratio of the repaired VDC Buffer:

- 1. Select the 20 VDC range on the 8810A.
- 2. . Connect a digital voltmeter (1 μ V resolution) between the 8810A's HI INPUT (DVM low input) and TP6 (DVM high input).
- 3. Connect a short between the 8810A HI-LO INPUT terminals and record the reading on the DVM.
- 4. Remove the short and apply +21V dc to the 8810A HI-LO INPUT terminals. The display on the 8810A should flash 18.888.
- 5. Compare the current DVM reading with that recorded in step 3. The difference should be less than 40 μ V.
- 6. Reverse the input connections to the 8810A. The display should now flash -18.888.
- 7. Compare the current DVM reading with that taken in step 3. The difference should be less than 40 μ V.

Table 4-6. Resistor Selection Procedure

STEP NO.	INSTRUCTION	YES	NO	GO ТО
1	Is the absolute reading taken from the digital voltmeter in step 9 of paragraph 4-62 equal to or greater than .002100?	8	2	
2	Is the offset voltage positive?	3	4	
3	Select resistor value from Table 4-8 and install resistor in position A (R38) on the Main PCB Assembly (remove short).			5
4	Select resistor value from Table 4-8 and install resistor in position B (R34) on the Main PCB Assembly (remove short).			5
5	Set the DC ZERO pot (R37) to both the cw and ccw extremes. Note the digital voltmeter reading at both settings.	ļ		6
6	Is the smallest digital voltmeter reading equal to or less than .000100?	15	7	
7	Mechanically center the DC ZERO pot (R37).			2
8	Is offset voltage positive?	9	14	
9	Select resistor value from Table 4-7 and install resistor in position A (R38) on the Main PCB Assembly (remove short).			10
10	Complete the DC Bias adjustment procedure as given earlier under Calibration Adjustments.			11
11	Is the digital voltmeter reading between .000000 and —.002100?	3	9	
12	Select resistor value from Table 4-7 and install resistor in position B (R34) on the Main PCB Assembly (remove short).			13
13	Complete the DC Bias adjustment procedure as given earlier under Calibration Adjustments.			14
14	Is the digital voltmeter reading between .000000 and +.002100?	4	12	
15	Adjust DC ZERO pot for an 8810A display of 00.000 ± 1 digit.			16
16	Test the CMRR characteristics of the repaired VDC Buffer using the procedure given under VDC Buffer CMRR.			_

Table 4-7. Offset Voltage Correction Resistors (Coarse)

OFFSET VOLTAGE	COARSE RESISTOR	J.F. P/N	TOL.%	TEMPERATURE COEFFICIENT
0.00000 - 0.00200	None			
0.00201 - 0.00400	31.6k	261610	1%	то
0.00401 - 0.00600	47.5k	289546	1%	то
0.00601 - 0.00800	63.4k	235382	1%	то
0.00801 - 0.01000	80.6k	281121	1%	то
0.01001 - 0.01200	95.3k	289561	1%	то
0.01201 - 0.01400	113 k	379065	1%	T2
0.01401 - 0.01600	130 k	379073	1%	T2
0.01601 - 0.01800	147 k	379081	1%	T2
0.01801 - 0.02000	162 k	379099	1%	T2
0.02001 - 0.02200	178 k	379107	1%	T2
0.02201 - 0.02400	196 k	379115	1%	T2
0.02401 - 0.02600	215 k	379123	1%	T9
0.02601 - 0.02800	232 k	257527	1%	Т9
0.02801 - 0.03000	249 k	379131	1%	Т9
0.03001 - 0.03200	267 k	379149	1%	Т9
0.03201 - 0.03400	287 k	257543	1%	Т9
0.03401 - 0.03600	301 k	379156	1%	Т9
0.03601 - 0.03800	316 k	379164	1%	Т9
0.03801 - 0.04000	340 k	379172	1%	Т9
0.04001 - 0.04200	357 k	312793	1%	Т9
0,04201 - 0.04400	374 k	379180	1%	Т9
0.04401 - 0.04600	392 k	260455	1%	Т9
0.04601 - 0.04800	412 k	379198	1%	Т9
0.04801 - 0.05000	432 k	379206	1%	Т9
	İ			

Table 4-8. Offset Voltage Correction Resistors (Fine)

OFFSET VOLTAGE	FINE RESISTOR	J.F. P/N	TOL%	TEMPERATURE COEFFICIENT
0.00000 - 0.00010	None			
0.00011 - 0.00030	1.54k	289066	1%	то
0.00031 - 0.00051	3.09k	235150	1%	то
0.00051 - 0.00071	4.75k	260679	1%	TO
0.00071 - 0.00091	6.19k	283911	1%	то
0.00091 - 0.00110	7.68k	370999	1%	то
0.00110 - 0.00130	9.31k	379040	1%	ТО
0.00131 - 0.00150	10.7k	293613	1%	то
0.00151 - 0.00170	12.4k	261644	1%	то
0.00171 - 0.00191	14.0k	379057	1%	TO
0.00191 - 0.00210	16.9k	267146	1%	ТО
		•		

Section 5 List of Replaceable Parts

TABLE OF CONTENTS

TABLE	TITLE	PART NO.	PAG
5-1	Final Assembly	8800A	5-3
5-2	Al Main PCB Assembly	366245	5-5
5-3	A2 Front Panel Assembly	372391	5-10
5-4	A2A1 Display PCB Assembly	366278	5-12

5-1. INTRODUCTION

- 5-2. This section contains an illustrated parts breakdown of the instrument. Components are listed alpha-numerically by assembly. Electrical components are listed by reference designation and mechanical components are listed by item number. Each listed part is shown in accompanying illustration.
- 5-3. Parts lists include the following information:
- a. Reference Designation or Item Number.
- b. Description of each part.
- c. Fluke Stock Number.
- d. Federal Supply Code for Manufacturers. (See Section 7 for Code-to-Names list.)
- e. Manufacturer's part Number or Type.
- f. Total Quantity per assembly or component.
- g. Recommended Quantity: This entry indicates the recommended number of spare parts necessary to support one to five instruments for a period of two years. This list presumes an availability of common electronic parts at the maintenance site. For maintenance for one year or more at an isolated site, it is recommended that at least one in each assembly in the instrument be stocked. In the case of optional subassemblies, plug-ins, etc, that are

not always part of the instrument, or are deviations from the basic instrument mode, the REC QTY column lists the recommended quantity of the item in that particular assembly.

. .

h. Use Code is provided to identify certain parts that have been added, deleted or modified during production of the instrument.

5-4. HOW TO OBTAIN PARTS

- 5-5. Components may be ordered directly from the manufacturer by using the manufacturer's part number, or from the John Fluke Mfg. Co., Inc. factory or authorized representative by using the FLUKE STOCK NUMBER. In the event the part you order has been replaced by a new or improved part, the replacement will be accompanied by an explanatory note and installation instructions, if necessary.
- 5-6. To ensure prompt and efficient handling of your order, include the following information.
- a. Quantity
- b. FLUKE Stock Number
- c. Description
- d. Reference Designation or Item Number
- e. Printed Circuit Board Part Number and Revision Letter
- f. Instrument Model and Serial Number

Table 5-1. Final Assembly

		iai Assemb	- 7				
ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC QTY	
	FINAL ASSEMBLY, 8810A					·	
	FIGURE 5-1						
A1	MAIN PCB ASSEMBLY (8800A-4001T)		89536	366245	1		
A2	FRONT PANEL ASSEMBLY (8810A-4201)	472407	89536	472407	1		
F1	FUSE, 1/4 AMP, 250V (INCLUDES SPARE F1)		71400	AGC1-4	2	10	
MP1	BRACKET, REAR SUPPORT CASE, MOLDED CHASSIS, SIDE ASSEMBLY CHASSIS, SIDE CRANK AND ROD ASSEMBLY BEARING, CRANK DECAL, HANDLE DECAL, GEN, SPEC	384297	89536	384297	1		
MP2	CASE, MOLDED	363655	89536	363655	1		
MP3	CHASSIS, SIDE ASSEMBLY	372227	89536	372227	1		
MP4	CHASSIS, SIDE	388264	89536	388264	1		
MP5	CRANK AND ROD ASSEMBLY	378968	89536	378968	1		
	BEARING, CRANK	376996	89536	376996	1		
MP6	DECAL, HANDLE	347401	89536	347401	2		
MP7	DECAL, GEN. SPEC	477505	89536	477505	1		
MP8	E RESMINING RING (NOS ILLUSTRHIED)	100314	79136	5133-15 -MDR	1		
MP9	GUARD, BOTTOM	364901	89536	364901	1		
MP10	GUARD, INSULATOR		89536	384289	2		
MP11	GUARD. TOP		89536	462812	1		
MP12	GUARD. BOTTOM GUARD. INSULATOR GUARD. TOP GUARD. XFMR HANDLE. MOLDED LENS	365114		365114	1		
MP13	HANDLE, MOLDED	414581	89536		1		
MP14	LENS	401604		401604	1		
MP15	LINE CORD (NOT ILLUSTRATED)	343723		343723	1	1	
MP16	LENS LINE CORD (NOT ILLUSTRATED) LINE SWITCH PAD. FOOT SCREW. 6-20 X 3/8 WASHER. FLAT. HANDLE LOCKOUT, FUNCTION SWITCH	380121	89536	380121	1		
MP17	PAD, FOOT	338632		338632	2		
MP18	SCREW, 6-20 X 3/8	288266	89536		2 2 2		
MP19	WASHER, FLAT, HANDLE	340505		340505	2		
MP20	LOCKOUT, FUNCTION SWITCH	480384	89536	480384	1		
Τi	XFMR. POWER				1		
	115/230V AC	373977		373977			
	100V AC	395194					
Ull	XFMR. POWER 115/230V AC 100V AC ØIC. PMOS. UNIVERSAL DVM FUSEHOLDER	407734			1	1	
XFi	FUSEHOLDER	103283	71400	4405	1		




Figure 5-1. Final Assembly

Table 5-2. A1 Main PCB Assembly

	Table 5-2. A1 Main PCB Assembly						
ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC USE QTY CDI	
A1	MAIN PCB ASSEMBLY (8800A-4001T) FIGURE 5-2	366245	89536	366245	REF		
NO. A1 C23 C44 C55 C67 C89 C111 C112 C113 C115 C116 C117 C118 C120 C221 C221 C221 C222 C223 C226 C227 C228 C221 C220 C221 C221 C221 C221 C222 C222	MAIN PCB ASSEMBLY (8800A-4001T) FIGURE 5-2 CAP. PLSTC, 0.022 UF +/-10x, 100V CAP. CER. 0.0005 UF +/-20x, 50V CAP. MICA, 150 PF +/-5x, 500V CAP. MICA, 150 PF +/-5x, 500V CAP. CER. 33 PF +/-2x, 100V CAP. POLY CAR. 0.10 UF +/-10x, 100V CAP. POLY PROP. 0.47 UF +/-5x, 50V CAP. MICA, 150 PF +/-5x, 500V CAP. MICA, 150 PF +/-5x, 500V CAP. CER. 33 PF +/-2x, 100V CAP. MICA, 150 PF +/-5x, 500V CAP. CER. 33 PF +/-2x, 100V CAP. CER. 3012 UF +/-10x, 250V CAP. CER. 0.012 UF +/-10x, 50V CAP. CER. 0.22 UF +/-20x, 50V CAP. CER. 0.22 UF +/-20x, 50V CAP. CER. 0.22 UF +/-20x, 50V CAP. ELECT, 50 UF +75/-10x, 50V CAP. ELECT, 50 UF +75/-10x, 50V CAP. ELECT, 200 UF +50/-10x, 40V CAP. ELECT, 200 UF +50/-10x, 40V CAP. ELECT, 200 UF +50/-10x, 10V CAP. ELECT, 200 UF +50/-10x, 10V CAP. TA, 4.7 UF +/-20x, 20V CAP. MICA, 100 PF +/-5x, 500V CAP. TA, 4.7 UF +/-20x, 20V CAP. TA, 4.7 UF +/-20x, 20V CAP. MICA, 100 PF +/-5x, 500V CAP. MICA, 270 PF +/-5x, 500V CAP. MINI CER. 60 PF +/-2x, 100V CAP. MINI CER. 60 PF +/-2x, 100V CAP. MINI CER. 60 PF +/-2x, 100V CAP. CER. 33 PF +/-2x, 100V CAP. MINI CER. 60 PF +/-2x, 100V CAP. CER. 33 PF +/-2x, 100V CAP. CER. 33 PF +/-2x, 100V CAP. CER. 33 PF +/-2x, 100V CAP. SI DIODE, BRIDGE DIODE, BRIDGE	366245 333823 175232 148478 148478 354852 45990 364042 148478 354852 148478 306522 106732 309849 105122 178616 178616 330761 161943 148494 161943 161943 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 369074 354852 148452 362756 3630323 363323 263323 263323	\$\frac{\frac	OR TYPE	REF 12F4F511 REFF111 REFF111		
CR33 CR34 CR35 CR36 CR36 CR37	DIODE, SI DIODE, SI DIODE, ZENER, 10V DIODE, ZENER, 6.2V DIODE, ZENER, 6.2V DIODE, 2 PELLET DIODE, ZENER, 10V DIODE, SI	203323 113324 325811 325811 375477 113324	07910 07919 07910 07910 09213	1N4148 1N961A 1N735A 1N735A MPD200 1N961A	REF 2 REF REF 1 REF	1	
CF39 K5 MP1 MF2 MP3 MP4 MP5	DIODE, SI RELAY, TELEPHONE TYPE, 2-POLE CONN, POST HEAT SINK, XSTR HEAT SINK, XSTR SOCKET, 40-PIN SOCKET, 16-PIN SOCKET, 14-PIN	203323 357707 376574 370155 418384 376244 276535	07910 26806 00779 05820 13103 23880 23830	1N4148 AZ42012 201	REF 1 16 1 2 1 3		
					7		

Table 5-2. A1 Main PCB Assembly (cont)

_	Table 5-2. A1 N	nami CD Assen	1017 100.			
		FLUKE	MFG		_	
ITEM	DESCRIPTION	STOCK	SPLY	MFG PART N		REC USE
NO.	DESCRIPTION	NO.	CODE	OR TYPE	QTY	QTY CDE
_		NO.	CODL			<u> </u>
	TOWNS OF THE THE	201065	12615	SL841-777	2	
MP7	TERMINAL, FEED TAKE	20100J	07047	10123-DAP	2 5 3 2	
MP8	TRANSIPAD, XSTR	150716	12040	ST07154	3	1
Q10	XSTR NPN	100110	04713	2N4890	2	i
Q11	XSTR PNP	<u> </u>	00004	2N3053	1	î
012	XSTR. NPN	150359	86684	ST07154	REF	•
Q13	XSTR. NPN	168716	12040		1	1
Q14	XSTR, SI, NPN	295/1/	24355	AD81100-17	1	1
Q15	XSTR, DUAL, NPN	284075	32293	1T1099	20	5
Q16	XSTR, SI, NPN	218396	04713	2N3904		1
Q18	XSTR, FET, N-CHANNEL	370072	12040	KE4393	4	1
Q19	XSTR, SI, NPN	218396	04713	2N3904	REF	
020	XSTR, FET, N-CHANNEL	370072	12040	KE4393	REF	
021	XSTR, SI, NPN	218396	04713	2N3904	REF	
022	XSTR, SI, PNP	195974	04713	2N3906	4	1
Q23	XSTR, FET, N-CHANNEL	370072	12040	KE4393	REF	
024	XSTR. SI. NPN	218396	04713	2N3904	REF	
025	XSTR. FET. N-CHANNEL	370072	12040	KE4393	REF	
026	XSTR. SI. NPN	218396	04713	2N3904	REF	
026	XSTR. SI. PNP	195974	04713	2N3906	REF	
Q28	XSTR. SI. NPN	218396	04713	2N3904	REF	
029	YSTR, FET, N-CHANNE!	343839	89536	343830	6	2
Q30	YOTE OIL NEW	218396	04713	2N3904	REF	
021	VOTE EET NICHANNEL	343830	89536	343830	REF	
Q31	ASIK, FEI, HECHMINEL	218396	04713	2N3904	REF	
032	ASIK, SI, HEN WOLD SET NICHONNEL	343830	89536	343830	REF	
033	XSIR, FEI, N-CHHNINEL	218796	04713	2N3904	REF	
034	XSIR, SI, NEN	210000	89536	343830	REF	
Q35	XSIR, FEI, N-CHHNINEL	243036	04713	2N3984	REF	
Q36	XSIR, SI, NPN	210330	04713	2N3984	REF	
037	XSTR. SI, NPN	Z 10070	89536	343830	REF	
Q38	XSTR, FET, N-CHANNEL	343830	00530	386730	1	1
Q39	XSTR, FET	385730	89536		1	i
Q40	XSTR, FET, DUAL	257501	89536	257501	REF	•
Q41	XSTR, FET, N-CHANNEL	343830	89536	343830	REF	
042	XSTR, SI, PNP	195974	04713	2N3906		
Q43	XSTR, SI, NPN	218396	04713	2N3904	REF	
044	XSTR, SI, NPN	218396	04713	2N3904	REF	_
Q45	XSTR, SI, PNP	340026	04713	MPS6563	6	2
Q46	XSTR, SI, NPN	218396	04713	2N3904	REF	
047	XSTR, SI, PNP	340026	04713	MPS6563	REF	
048	XSTR, SI, NPN	218396	04713	2N3904	REF	
Q49	XSTR, SI, PNP	340026	04713	MPS6563	REF	
Q50	XSTR. SI. NPN	218396	04713	2N3904	REF	
Q51	XSTR. SI, PNP	340026	04713	MP\$6563	REF	
Q52	XSTR. SI. NPN	218396	04713	2N3904	REF	
Q53	TERMINAL, FEED THRU TRANSIPAD, XSTR XSTR, NPN XSTR, NPN XSTR, NPN XSTR, NPN XSTR, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, FET, N-CHANNEL XSTR, SI, NPN XSTR, S	340026	94713		REF	
Q54	XSTR, SI, NPN	218396	04713	2N3904	REF	
Q55	XSTR, SI, PNP	340026	04713		REF	
ردیا ا	XSTR. SI. NPN	218396			REF	
Q56		218396		2N3904	REF	
Q57	XSTR, SI, NPN	195974			REF	
Q58	XSTR, SI, PNP	168716			REF	
059	XSTR, NPN				2	1
060	XSTR, SI, PNP	203364			REF	•
Q61	XSTR, SI, PNP	203364			1	1
Q62	XSTR, SI, NPN	218081	04713		REF	•
Q63	XSIR, PNP	269076			KET 1	1
R21	RES, VAR, 200 +/-10%, 1/2W	275743			1	1
R23	RES. COMP. 100K +/-5%. 2W	285056			1	
R25	RES, MF, 383 +/-1%, 1/8W	375899			_	
R26	RES. CAR. 62K +/-5%. 1/4W	348904			_	
R27	RES, MF, 205 +/-1%, 1/8W	325647			1	
R28	RES, CAR, 220 +/-5%. 1/4W	342626				
R29	RES, COMP, 100M +/−10%, 1/2W	190520			1	
R39	RES, VAR, 100K +/-10%, 1/2W	369520		369520	1	1
R31	RES, MF, 499K +/-1%, 1/8W	268813	91637	MFF1-84993F	1	
R32	RES. CAR. 220 +/-5%. 1/4W	342526			REF	
R33	RES, MF, 309K +/-1%, 1/8W	235283	91637	NFF 1-83093F	2	
R35	XSTR, S1, NFN XSTR, PNP RES, VAR, 200 +/-10%, 1/2W RES, COMP, 100K +/-5%, 2W RES, MF, 383 +/-1%, 1/8W RES, CAR, 62K +/-5%, 1/4W RES, MF, 205 +/-1%, 1/8W RES, CAR, 220 +/-5%, 1/4W RES, COMP, 100M +/-10%, 1/2W RES, VAR, 100K +/-10%, 1/2W RES, MF, 499K +/-1%, 1/8W RES, CAR, 220 +/-5%, 1/4W RES, MF, 309K +/-1%, 1/8W RES, SET 2 PC	290320		290320	1	1
R36	RES. MF, 309K +/-1%, 1/8W	235283	91637		REF	
I						

Table 5-2. A1 Main PCB Assembly (cont)

	Table 5-2. A1 Main	PCB Assem	bly (con:	t)		
ITEM NO.	DESCRIPTION	FLUKE STOCK NO.	MFG SPLY Code	MFG PART NO. OR TYPE	l ntv	REC USE QTY CDE
	RES. VAR, 2K +/-10x, 1/2W RES. SET 2 PC RES. MF.2.8M +/-5x, 1/4W RES. CAR, 10K +/-5x, 1/4W RES. CAR, 10K +/-5x, 1/4W RES. CAR, 10K +/-5x, 1/4W RES. CAR, 10K +/-5x, 1/4W RES. CAR, 10K +/-5x, 1/4W RES. CAR, 10K +/-1x, 1/8W RES. SET, 2 PC RES. SET, 2 PC RES. MF, 100K +/-1x, 1/8W RES. COMP, 1.5K +/-5x, 1/4W RES. CAR, 1M +/-5x, 1/4W RES. CAR, 1M +/-5x, 1/4W RES. CAR, 4.7K +/-5x, 1/4W RES. CAR, 4.7K +/-5x, 1/4W RES. MF, 30.9K +/-1x, 1/8W RES. MF, 64.9K +/-1x, 1/8W RES. MF, 64.9K +/-1x, 1/8W RES. MF, 46.4K +/-1x, 1/8W RES. MF, 46.4K +/-1x, 1/8W RES. MF, 64.9K +/-1x, 1/8W RES. MF, 64.9K +/-1x, 1/8W RES. MF, 65.9K +/-1x, 1/8W RES. CAR, 51K +/-5x, 1/4W RES. MF, 65.9K +/-1x, 1/8W RES. CAR, 52K +/-5x, 1/4W RES. CAR, 3.3K +/-5x, 1/4W RES. CAR, 106 +/-5x, 1/4W RES. CAR, 106 +/-5x, 1/4W RES. SET 6 PC RES					•
R37	RES. VAR. 2K +/-10%. 1/2W	285163	89536	285163	1	1
R39 R40	RES, SET 2 Pt.	290320	89536	290320 MEE 1-33904E	REF	
R41	RES. CAR. 10K +/-5%, 1/46	236763 348839	80031	CR251-45P19KT-S	1 7	
R42	RES. CAR. 150 +/-5%, 1/4W	343442	80031	CR251-4-5P150ETS	1	
R43	RES. CAR. 10K +/-5%, 1/4W	348839	80031	CR251-45P10KT-S	REF	
R45 R47	RES. CAR. IM +/-5%, 1/4W	348987	80031	CR251-4-5P1MTS	3	
R48	RES, VHR, 20 77-20%, 172W	263788	69536	363788	1	1
R52	RES. SET. 2 PC	363788	89536	363788	REF	
R53	RES, MF, 100K +/-1%, 1/8W	248807	91637	MFF1-81003F	1	
R54	RES, MF, 9.76K +/-1%, 1/8W	241489	91637	MFF1-89761F	1	
R55 R56	RES, LUMP, 1.5K +/-5%, 1/4W PEC COD 1M +/-5% 1/4W	148031	90031	UB1525 CP351_4_501MTG	l DEE	
R74	RES. CAR. 4.7K +/-5%, [/4W	348821	80031	CR251-45P4K7TS	1	
R75	RES. MF. 30.9K +/-1%. 1/8W	235275	91637	MFF1-83092F	ī	
R76	RES, COMP, 10M +/-5%, 1/4W	194944	01121	CB1065	1	
R77	RES. MF. 64.9K +/-1%, 1/8W	288530	91637	MFF1-86492F	2	4
R78	RES. MF. 46.4K +/-1%. 1/AU	200148 188375	91637	3003201H MFF1-84642F	1	1
R80	RES. MF. 64.9K +/-1%, 1/8W	288530	91637	MFF 1-86492F	REF	
R83	RES, CAR, 51K +/-5%, 1/4W	376434	80031	CR251-4-5P51KTS	1	
R84	RES, MF, 4.99K +/-1%, 1/8W	168252	91637	MFF1-84991F	1	
R85 R86	RES, MF, 200K +/-1%, 1/8W RES, CAR, 3 3K +/-5%, 1/4W	261701 349913	91637	MFF 1-82003F CP251-45P3K3TS	1	
R87	RES, CAR, DEP, 2.7K +/-5%, 1/4W	386490	80031	CR251-45P2K7TS	1	
R88	RES, VAR, 5K +/-10%, 1/2W	288282	89536	288282	ī	
R89	RES. CAR. 100 +/-5%, 1/4W	348771	80031	CR251-4-5P100-ETS	<u>i</u>	
R90 R91	RES. UAR, 2.2K +/-5%, 1/4U	343400	80031	CR251-45P2K-2T5	2	
R92	RES. SET 6 PC	363804	89536	363894	REF	
R93	RES. SET 6 PC	363804	89536	363804	REF	
R94	RES, SET 6 PC	363804	89536	363884	REF	
R95	RES. SET 6 PC	363804	89536	353804	REF	-
R96 R97	REF HMP, SET (INCLUDES RIBZ & US)	450080	89536 71450	450080	1	1
RS8	RES, SET 6 PC	363804	89536	363804	REF	1
R99	RES, VAR, 20 +/-20%, 1/2W	285114	71450	36052008	REF	
R100	RES, SUB MINI, UW, 14K +/-0.1%, .1W	363770	54294	SP21D22-14KB	1	1
R101 R102	RES, MF, 3.74K +/-1%, 1/8W	272096	91637	MFF1-83741F	1 055	
R103	RES. MF. 6.34K +/-1%, 1/8W	267344	91637	450000 MEF 1-86341F	KET 1	
R113	RES, MF, 5.49K +/-0.1%, 1/8W	375873	91637	MFF1-85491-BS	1	
R114	RES. MF. 3.48K +/-0.1%, 1/8W	375881	91673	MFF1-83481BS	1	
R115 R116	RES, MF, 5.49K +/-0.1%, 1/8W RES, MF, 5.49K +/-0.1%, 1/8W RES, MF, 10K +/-1%, 1/8W RES, CAR, 10K +/-5%, 1/4W RES, CAR, 11M +/-5%, 1/4W RES, MF, 10.08K +/-0.1%, 1/8W RES, MF, 10.08K +/-0.1%, 1/8W RES, CAR, 2.2K +/-5%, 1/4W RES, COMP, 6.8K +/-5%, 1/4W RES, NETWORK	168260	91637	MFF1-81102F	1	
R117	RES. CAR. 1M +/-5%, 1/4W	348839 348987			REF REF	
R118	RES. MF. 10.08K +/-0.1%, 1/8W	346908	91637	MFF1-810R8-R1PCT	2	
R119	RES, MF, 10.08K +/-0.1%, 1/8W	346908	91637	MFF1-810R8-R1PCT	REF	
R120	RES, CAR, 2.2K +/-5%, 1/4W	343400	80031			
R121 RN1	RES. NETWORK	148098 379248	01121 89536	CB6825 379248	1	1
RN3	RES, NETWORK	379255	89536	379255	:	1
RN4	RES, NETWORK	379230	89536	379230	ī	ī
RN5	RES, NETWORK RES, NETWORK RES, NETWORK SWITCH, SLIDE, 115/230V	358002		FN260	1	1
S12 TP1	CONN' BORT	376798 379438	82389 ØØ779	11A437 8619405	1 17	1
TP2	CONN, POST	379438	00779	8619405	REF	
TP3	CONN. POST	379438	00779	8619405	REF	
TP4	CONN. POST	379438	00779	8619405	REF	
1'P5 TP6	CONN, POST CONN, POST	379438 379438	00779 00773	8619405 8619405	REF REF	
TP7	CONN, POST	379438	00779	8619405	REF	
TP8	CONN. POST	379438	00779	8519405	REF	
TF9	CONN. POST	379438	00779		REF	
TP10 TP11	CONN, POST CONN, POST	379438	00779 00779		REF REF	
TP12	CONN, POST	379438 379438		8619405 8619405	REF	
<u>.</u>		3.2430	23112	23.3 400	15-1	

Table 5-2. A1 Main PCB Assembly (cont)

	Table 5-2. AT IVIDIT	1 0 0 7 0 3 0 1	11017 (001	101			
FTÉM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC QTY	
TP13	CONN, POST	379438	00779	8619405	REF		
TP14	CONN. POST	379438	00779	8619405	REF		
TP16	CONN. POST	379438	00779	8619405	REF		
TP17	CONN, POST	379438	00779	8619405	REF		
Uı	IC. OP AMP	284760	12049	LM308H	2	1	
U2	IC, OP AMP, J-FET INPUT	448985	89536	448985	1	1	
U3	IC, OP AMP, J-FET INPUT	381962	12040	SH61140	1	1	
U4	IC, OP AMP	363515	24355	AD301AN	2	1	
U5	IC. OP AMP	329912	12040	LM318H	1	1	
U6	IC, LINEAR, COMPARATOR	352195	32293	LM311PA	1	1	
U7	IC. OP AMP	284760	12040	LM308H	RÉF		
U8	IC, OP AMP	2259 6 1	34333	SG8023	1	1	
U9	REF AMP, SET (INCLUDES R96 & R102)	450080	89536	450080	REF		
U11	SEE FINAL ASSEMBLY						
U12	IC. BCD-TO-DECIMAL DECODER	293142	01295	SN7442N	1	1	
U13	Ø IC. C-MOS. HEX	355214	95303	CD4009AE	1	1	
U14	Ø IC, C-MOS, NAND	375147	95303	CD4023AE	1	1	
U15	Ø IC. C-MOS. NAND	355198	95303	CD4011AE	1	1	
U16	IC. TTL, BCD DECODER/DRIVER	340109	01295	SN7447AN	1	1	
U17	IC, LINEAR, VOL REG	313106	07263	U5R7723393	1	1	
U18	IC, OP AMP	363515	24355	AD301AN	REF	^	
U19	IC, LINEAR, VOL REG	355107	07263	F7805UC	1	1	
U20	ØIC. C-MOS, MULTIPLEXER	375808	95303	CD4053AE	1	1	
W2	WIRE ASSY, BLACK	373779	89536	373779	1		
W3	WIRE ASSY, BLUE	378307	89536	378307	1		
いヨ	WIRE ASSY. RED	378299	89536	378233	1		
XK5	SOUKET RELAY	376665	12300	27E501	1		
Υ	SEE FINAL ASSEMBLY IC. BCD-TO-DECIMAL DECODER © IC. C-MOS. HEX © IC. C-MOS. NAND © IC. C-MOS. NAND IC. TTL. BCD DECODER/DRIVER IC. LINEAR. VOL REG IC. OP AMP IC. LINEAR. VOL REG © IC. C-MOS. MULTIPLEXER WIRE ASSY. BLACK WIRE ASSY. BLUE WIRE ASSY. BED SOLKET RELAY CONN. POST CRYSTAL. QUARTZ. 1 MHZ	379438	00773	8619405	REF		
Y1	CRYSTAL, QUARTZ, 1 MHZ	375493	89536	375493	1		




Figure 5-2. A1 Main PCB Assembly

Table 5-3. A2 Front Panel Assembly

ITEM NO.	DESCRIPTION	FLUKE STOCK NO.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC QTY	
	EDOUT DALIEL ACCEMBLY (COLOR 4201)	470 407	00576	477.407	DCC		
A2	FRONT PANEL ASSEMBLY (8810A-4201) FIGURE 5-3	472407	89536	472407	REF		
A2A1	DISPLAY PCB ASSEMBLY	366278	89536	366278	1		
MP1	ACTUATOR, SWITCH, GREEN	420604	89536	420604	1		
MP2	ACTUATOR, SWITCH, GREY	420596	89536	420596	10		
MP3	BINDING POST, BLACK	275560	32767	825-45	2		
MP4	BINDING POST, BLUE	275578	32767	825-55	1		
MP5	BINDING POST, RED	275552	32767	825-65	2		
MP6	CONNECTOR TAB	267609	00779	60837-1	1		
MP7	DECAL 1, FRONT PANEL	477513	89536	477513	1		
MP8	DECAL 2. FRONT PANEL	477521	89536	477521	1		
MP9	LINK, SHORTING	101220	24655	0938-9712	1		
MP10	NUT, NYLON, 6-32	111013	89 536	89536	4		
MP 1 1	PANEL, FRONT, MOLDED	477489	89536	477499	10		
MP12	RETAINING RING	355586	89536	355586	10		
MP13	SLUG, ACTUATOR	364745	89536	364745	11		
MP14	SPACER, NYLON	102665	89536	102665	8		




Figure 5-3. A2 Front Panel Assembly

Table 5-4. A2A1 Display PCB Assembly

	Table 54. AZA I	Display I OL	7 743001110	· · ·			,
ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY Code	MFG PART NO. OR TYPE		REC QTY	
A2A1	DISPLAY PCB ASSEMBLY (8800A-4002) FIGURE 5-4	366278	89536	366278	REF		
C1	CAP, CER, 47 PF +/-10%, 2 KV/3.5 KV	282145	00656	HVD347P10PCT	1		
CR2	DIODE, LED	385914	89536	385914	2	1	
CR3	DIODE, LED	385914	89536	385914	ref		
DS1	DISPLAY, LED	472951	89536	472951		1	
DS2	DISPLAY, LED	429985	89536	429985	5	1	
DS3	DISPLAY, LED	429985	89536	429985	REF		
DS4	DISPLAY, LED	429985	89536	429985	REF		
DS5	DISPLAY, LED	429985	89536	429985	REF		
DS6	DISPLAY, LED	429985	89536	429985	REF		
MP1	CONN, POST	379438	00779	86144-5	9		
P1	CABLE ASSY, 16P	380576	89536	380576	1		
P2	CABLE ASSY, 14P	380568	89536	380568	1		
RN1	RES. NETWORK	381376	89536	381376	1	1	
S1	SWITCH ASSY	390500	89536	390500	1		
S2	SWITCH ASSY	390500	89536	390500	ref		
\$3	SWITCH ASSY	390500	89536	390500	REF		
S4	SWITCH ASSY	390500	89536	390500	REF		
S5	SWITCH ASSY	390500	89536	390500	REF		
S6	SWITCH ASSY	390500	89536	390500	REF		
S7	SWITCH ASSY	390500	89536	390500	REF		
\$8	SWITCH ASSY	390500	89536	390500	ŔĔF		
\$9	SWITCH ASSY	390500	89536	390500	REF		
S10	SWITCH ASSY	390500	89536	390500	REF		




Figure 5-4. A2A1 Display PCB Assembly

rs T

Section 6

Option & Accessory Information

6-1. INTRODUCTION

- 6-2. This section of the manual contains information concerning the options and accessories available for use with the Model 8810A. It consists of a series of subsections that include; introduction, accessories, and options. Each option and accessory is listed by Model or Option number in the table of contents on page 6-2.
- 6-3. Accessories include a rack mounting kit and several specialized probes. The probes are designed to extend the measurement characteristics of the 8810A to include temperature, high voltage, high current, and/or high frequency.
- 6-4. Each option for the 8810A is documented as an individual subsection. All of the information necessary to install, operate, and maintain an option is included in its subsection. This includes a list of replaceable parts and a schematic.
- 6-5. Each subsection is uniquely identified by page and paragraph numbering that relates to the accessories or a particular option. For example, a 600-X series identifies the general accessories subsection, and a 602-X series identifies the subsection for the -002 Option (where X is a sequential page or paragraph number).

TABLE OF CONTENTS

OPTION/MODEL	DESCRIPTION	PAGE
M00-200-625	Rack Mounting Kit	600-1
A80	Deluxe Testing Lead Kit	600-1
80T-150	Temperature Probe	600-1
80K-40	High Voltage Probe	600-2
81RF	High Frequency Probe	600-3
82RF	High Frequency Probe	600-3
-002	Digital Output Unit	602-1
-007	Ohms Converter	607-1
-008	AC Converter	608-1
-009	True RMS Converter	609-1

ACCESSORIES

600-1. RACK MOUNTING KIT

600-2. The 8810A can be rack-mounted in a standard 19-inch equipment rack using Rack Mounting Kit, M00-200-625. With reference to Figure 600-1, use the following procedure to install the Rack Mounting Kit.

- a. Remove the handle disc decal and handle from the 8810A. Save the handle mounting screws for use later in this procedure.
- b. Remove the case retaining screws from the 8810A (rear of the case) and remove the instrument from the case.
- c. Insert the open end of the case into the rear opening on the center rack mount plate. Stop when the case is flush with the front surface of the plate. Fasten the rack mount brackets and retainers to the case as shown.
- d. Secure the brackets and retainers to the handle mounting bosses using the handle mounting screws. Take care to avoid stripping the threads.
- e. Position the instrument case on the center rack mount plate and fasten the brackets using the 6-32 nuts.
- f. Re-install the instrument in the case and replace the case retaining screws.

600-3. DELUXE TEST LEAD KIT (A80)

600-4. The deluxe test lead kit, shown in Figure 600-2, contains two test leads with probes (red and black) and five pairs of universal probe tips. The probe tips

include: alligator clips, test prod tips, pin tips, banana plug tips, and binding post lugs. A convenient plastic pouch is provided for storing the contents of the test lead kit.

600-5. TEMPERATURE PROBE (80T-150)

600-6. Introduction

600-7. The 80T-150 Temperature Probe (Figure 600-3) converts the 8810A into a direct-reading (1 mV dc/°) °C or °F thermometer. It is ideally suited for surface, ambient, liquid measurements, and lends itself easily to a wide range of design, troubleshooting, and evaluation applications. A rugged, fast-responding probe-tip with a 350V dc standoff makes the 80T-150 one of the most versatile and easy-to-use temperature probes available.

600-8. Specifications

Range (°C/°F field selectable by internal jumpers)	-50°C to +150°C or -58°F to 302°F
Accuracy	±1°C (1.8°F) from 0°C to 100°C, decreasing linearity to ±3°C (5.4°F) at -50°C and +150°C
Resolution	0.1°C on 200 mV range.
Voltage Standoff	350V dc or peak ac
Power	Internal disposable battery;

use.

600 - 1

1,000 hours of continuous




Figure 600-1. Rack Mount Installation




Figure 600-2. Deluxe Test Lead Kit (A80)

600-10. HIGH VOLTAGE PROBE (80K-40)

600-11. Introduction

The Model 80K-40 (Figure 600-3) extends the voltage measurement capability of the 8810A up to 40 kV. Internally, the probe contains a special 1000:1 resistive divider. Metal-film resistors with matched temperature coefficients comprise the divider, and provide the probe with its excellent accuracy and stability characteristics. Also, an unusually high input impedance (1000 $M\Omega$) minimizes circuit loading, and thereby contributes to measurement accuracy.

600-13. Specifications

Voltage Range 1 kV to 40 kV dc or peak ac, 28 kV rms ac

Input Resistance 1000 $M\Omega$

Division Ratio 10000:1

Accuracy DC

Overall Accuracy 20 kV to 30 kV \pm 2% (cali-

brated 1% at 25 kV).

Upper Limit Changes linearly from 2% at 30 kV to 4% at 40 kV

Lower Limit Changes Linearly from 2%

at 20 kV to 4% at 1 kV

Accuracy AC \pm 5% at 60 Hz (overall)

600-14. HIGH FREQUENCY PROBE (81RF)

600-15. Introduction

600-16. The 81RF Probe (Figure 600-3) extends the frequency range of the 8810A voltage measurements capability to include 100 kHz to 100 MHz input from 0.25 to 30V rms. It operates in conjunction with the 8810A dc voltage ranges, and provides a dc output that is calibrated to be equivalent to the rms value of a sinewave input.




Figure 600-3. Accessory Probes

600-17. Specifications

AC-DC Transfer ± 1 dB @ 30V, ± 3 dB @ 2V,

 ± 2 dB @ 0.25 to 0.5V.

Frequency Response ±1 dB from 100 kHz to

100 MHz

Extended Frequency

Response Useful for relative readings

from 20 kHz to 250 MHz.

Response Responds to peak value of input; calibrated to read rms

value of a sinewave.

Voltage Range 0.25 to 30V rms

Maximum DC Input ... 350V dc

Input Impedance 12 M Ω shunted by 15 pF

600-18. HIGH FREQUENCY PROBE (82RF)

600-19. Introduction

600-20. The Model 82RF High Frequency Probe, Figure 600-3, allows measurements over a frequency range of 100 kHz to 500 MHz from 0.25 to 30V rms. It is designed to be used with voltmeters having an input impedance of 10 megohms $\pm 10\%$. It may be used with a voltmeter having an input impedance higher than 10 megohms provided the input is externally shunted to make the equivalent input impedance equal to 10 megohms.

600-21. Circuitry within the 82RF consists of a capacitor-coupled rectifier circuit which responds to the peak value of the input waveform. The output is positive polarity dc which is calibrated to be equivalent to the rms value of a sinewave.

600-22. Specifications

Frequency Response ±1 dB from 100 kHz to

200 MHz; ±3 dB from 200

MHz to 500 MHz

Extended Frequency

Response Useful for relative readings

from 20 kHz to 700 MHz

Response Responds to peak value of

input; calibrated to read rms

value of a sinewave.

Voltage Range 0.25 to 30V rms

Maximum DC Input ... 200V dc

Input Impedance 2 M Ω shunted by 4 pF

, F

Option -002 Digital Output Unit

602-1. INTRODUCTION

602-2. The Digital Output Unit (DOU), Option-002, is a factory installed pcb assembly designed to transfer bit-parallel measurement data (i.e., polarity, range, and magnitude) from the 8810A to an external hard-copy recorder. Along with the measurement data, appropriate handshaking I/O lines are included to insure accurate and expeditious data transfer. These include; Arm Enable, Arm Input, Busy, and Free Run. Output data is compatible with the Fluke Model 2010A Digital Printer. All input/output (I/O) data is electrically isolated from the 8810A measurement common.

602-3. SPECIFICATIONS

602-4. Specifications for the DOU are presented in Section 1 of this manual.

602-5. OPERATION

602-6. Once installed in the 8810A, the DOU requires no operator attention. However, certain considerations are necessary to properly interface the DOU with the external recorder. These are discussed in the following paragraphs.

602-7. Input/Output Connector

602-8. The DOU is supplied with a mating I/O connector for use in fabricating a DOU/recorder interface cable. The connector is a keyed, 44-pin, cardedge type and comes complete with a protective hood. A replacement connector is available from Fluke as Part No. 388983

NOTE

If the DOU is being interfaced with a Fluke Model 2010A Printer, use of the Model 2010A-7015K interface kit is recommended. Contact your nearest Sales Representative for additional information.

602-9. Interface Information

602-10. The pin assignments for the DOU's I/O connector are shown in Table 602-1. Signal requirements and characteristics are defined in the following descriptions.

602-11. LOGIC LEVELS

602-12. All I/O data at the DOU connector is positive-true and TTL compatible. It is also electrically isolated from the 8810A measurement common. This allows the I/O Logic Common to be referenced directly to that of the external recorder.

600-13. CONTROL DATA

602-14. The DOU is equipped with four separate control lines for the solicitation, acquisition, and transfer of measurement data. These are: Arm Enable, Arm Input, Free Run and Busy. Under ideal interface conditions these lines are used to establish a handshaking arrangement between the DOU and the external recorder (see Figure 602-1). This controlled interaction between the two units ensures an accurate and expeditious transfer of data.

602-15. Arm Enable and Arm Input operate as a signal pair for use in remotely commanding a DOU update.

Table 602-1. DOU Connector/Signal Identification

DOU DATA NAME	DOU PIN NO.	DOU DATA NAME REMARKS				
+5V BUSY FLAG POL FLAG BUSY FLAG POL FLAG OVERLOAD Q RANGE CODE b W6 Y6 W5 Y5 W4 Y4 W3 Y3 W2 Y2 (GND) W1 (GND) Y1	1 A 2 B 3 C 4 D 5 E 6 F 7 H 8 J 9 K 10 L 11 M 12 N 13 P 14 R 15 S 16 T 17 U 18 V 19 W 20 X 21 Y 22 Z	LOGIC RETURN ARM ENABLE ARM INPUT FREE RUN NOT USED a RANGE CODE c RANGE CODE X6	RANGE CODE			

They are effective only when the Free Run line is held low. Arm Enable is usually generated by the external recording device, and is held low while the device is redording the DOU's output. It returns high to indicate that the recorder is no longer busy. While Arm Enable is high (recorder is not busy) a low-to-high (positive) transition on the Arm Input line will initiate the DOU update sequence. The Arm Input must remain high for at least 375 nanoseconds to be effective. The Arm Input transition will be ignored if Arm Enable is low or if the transition is from high-to-low.

602-16. The Free Run input is independent of, and overrides the effect of, both the Arm Input and the Arm Enable commands. When enabled (high), Free Run allows the DOU output to be automatically updated at the end of each measurement cycle. When Free Run is disabled (low), DOU updating must be controlled by the Arm Enable and Arm Input commands.

602-17. The Busy output is generated whenever the DOU output registers are being updated. Its function is to inhibit the external recorder from recording incorrect data. Therefore, its trailing edge is recommended for use as a print command to the recorder. Busy is available at the DOU output as both Busy and Busy.

602-18. POLARITY FLAG

602-19. The polarity of the dc voltage input to the A/D Converter determines which polarity sign will be presented at DOU output pin 3; pin 5 provides POL only. A positive dc level at the converter will cause DOU output pin 3 to go to logic 1 and pin 5 to go to logic 0. A




Figure 602-1. Recommended Handshaking Connections

negative converter input will cause the opposite logic level output from each pin.

602-20. OVERLOAD PROTECTION

602-21. The DOU provides a single-bit output indication of a display overload condition. When the digit count exceeds the display capacity, pin-6 of the DOU output connector changes from a low to a high output level.

602-22. RANGE CODE

602-23. The instrument range is presented in a three-bit octal format at DOU output connector pins H, 7, and F. The output code representing each range is presented in Table 602-1.

602-24. DISPLAY DIGITS

602-25. The numeric value of each digit of the instrument display is presented in a four-bit bcd format (W-X-Y-Z) at the DOU output connector. The connector pin assignments for each significant digit of the display are provided in Table 602-1. The most significant digit (DOU connector pins 18, 19, V, and W) needs only one active bit to represent the two display digits, 1 or 0. The three remaining bits are connected to ground on the DOU PCB.

602-26. Theory of Operation

602-27. The 8810A transmits measurement data to the DOU in bcd character-serial format over four data

lines designated W, X, Y, and Z. Eight characters are transmitted for a complete measurement update. As each character is transmitted its four bits are sequentially scanned on the DOU by four successive strobe 5 (ST5) signals. The scanned bits are serially transmitted across an isolation circuit and presented as the input to a series of shift registers. The shift register outputs are inverted and buffered to provide character-parallel measurement data at the DOU output connector. Typical DOU timing is shown in Figure 602-2.

602-28. The DOU output can be updated by an external command (Arm Enable, Arm Input) or allowed to update automatically (Free Run) at the end of each new instrument measurement. A logic I high applied to Arm Enable (pin B) and logic 0 (low) applied to Free Run will prevent acquisition of new data by the DOU. A positive going trigger applied to Arm Input (pin C) will enable the DOU to acquire data.

after the next measurement is complete. BZ (busy from the instrument to the DOU) occurs in synchronous with the second ST0 signal after a measurement is complete and lasts for one strobe cycle. BZ is presented to U10 as a data input. ST5 clocks the data into U10. At this time the Busy flags are applied to the DOU output signifying that data is being changed. U10 enables the data on W to be serially loaded into the bottom of U4 during the first strobe cycle. When ST5 occurs again, the data in U10 is shifted to enable the data on X to be loaded into U4. Four strobe cycles are required to load the new data. When the




Figure 602-2. DOU Timing Diagram

fifth ST5 signal occurs, U10 is emptied of data and all its outputs are 0. RG is then inhibited by U11 and the clocking of data ceases. The Busy flags are cleared from the DOU output and the data can be read.

602-30. Arm Input may go to 0 at any time in the cycle, but it must go to 0 before a data update can be externally commanded. if desired, the DOU will automatically update at the end of each instrument measurement. If Free Run is allowed to go high, the DOU will automatically update the data after each measurement.

602-31. LIST OF REPLACEABLE PARTS

602-32. A list of replaceable parts for the DOU PCB Assembly is given in Table 602-2. Refer to Section 5 of this manual for ordering information.



Indicated devices are subject to damage by static discharge.

Table 602-2. DOU PCB Assembly

ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY Code	MFG PART NO. OR TYPE		REC QTY	
	DOU PCB ASSEMBLY, (8800A-4005)	•					
	FIGURE 602-3	226275	77445	ETOOLVOLOOF	2		
CI	CAP, ELECT, 220 UF +50/-10%, 10V CAP, PLSTC, 0.022 UF +/-10%, 50V CAP, ELECT, 220 UF +50/-10%, 10V	236935 271577	73445 06001	ET221X010A5	2 1	1	
C2	CAR FLECT 230 NE +50 /- 104 104	236935	73445	75F1R5A222 ET221X010A5	REF		
C3	CAP, ELECT, 220 UF +50/-10%, 10V CAP, FXD, CER, 0.05 UF +80/-10%, 25V RECTIFIER, BRIDGE DIODE, ZENER, 5.6V CABLE, FLAT SOCKET, IC, 14 PIN SOCKET, IC, 16 PIN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, NPN XSTR, SI, PNP XSTR, SI, PNP XSTR, SI, PNP XSTR, SI, NPN RES, CAR DEP, 1K +/-5%, 1/4W RES, COMP, 4.7M +/-5%, 1/4W RES, COMP, 4.7M +/-5%, 1/4W RES, NETWORK XFMR, POWER ØIC,C-MOS, DUAL, 4-BIT STATIC SHFT RGSTR	148924	32897	5855Y5U503Z	KET 1		
£4	CHP, FXD, CER, 0.00 OF TOUZ-10%, 20V	296509	51605	FB100	1	1	
CR1	NEUTIFIER, BRIDGE	277236	07910	FB100 1N752A 5112-007.25X TSA2900-14W TSA2900-16W 2N3904 2N3906 2N3906 2N3906 2N3904 R251025 R251025 CB4755 CB4755 CB4755 CB4755 MC14015CP MC14015CP MC14015CP MC14013CL MC140801CL	1	1	
CR2	NIUNE, ZENEK, 3.6V	205000	08261	INCOZH	1	1	
MP 1	COCKET IC 14 DIN	385922 276527		3112-601.23A	4		
MP2	SUCKET, IC, 14 PIN	276535	23880	15H2900-14W	11		
MP3	SULKET, IL, IB FIN	218396	23880	12H2988-16W	3		
Q1	XSIR, SI, NPN	218336	04713	283904	2	1	
02	ADIKA DIA MEN	218396	04713	2113904	REF		
Q3	X51K, 51, PNP	195974	04713	2N3905	2	1	
04	X51R, SI, PNP	195974	04713	2N3906	REF		
Q5 R15	X51K, 51, HPN	218396	Ø4713	203904	REF		
KID	RES, CHR DEF, IK +7-5%, 174W	343426	TOYO	K201020	2		
R16	RES, UHK DEP, IK +7-3%, 174W	343426	TOYO	K201020	REF		
R17	RES, LUMP, 4.78 +7-3%, 1/4W	220046	01121	684733 684733	2 REF		
R18	RES, EUTH, 4.711 +7-3%, 1/4W	220046 385930	01121	184733 305030	KEF		
RN1	KES, NETWORK	383930 374652	89536 89536	383730	1 1	1	
T1	AFRIKA MUMEK	340125		3/463Z	5 5		
U1	ØIC.C-MOS, DUAL, 4-BIT STATIC SHFT RGSTR	340125	04713	MC14015UF	REF	1	
	ØIC.C-MOS, DUAL, 4-BIT STATIC SHFT RGSTR	340125	04713	MC14015CD	KEF		
	ØIC.C-MOS, DUAL, 4-BIT STATIC SHET RGSTR ØIC.C-MOS, DUAL, 4-BIT STATIC SHET RGSTR	340125	04713	MC 140 IDUF	REF REF		
U5	GIO C MOC DUOL TUDE WIN ELID ELOR	340125	04713	MC14015UF	KEF	4	
US	OIL, L-MUS, DUHL, TYPE "D" FLIP-FLUP	340117	04713	MC 14013UL	1	1	
U6	With Charles New Preses Throughten	355172	04713	MC14801CL	1	1	
U7	WILL CHIUS, MEX, BUFFER/INVERTER	331848	49671	CD4049AE	6 REF	1	
US US	ØIC, C-MOS, DUAL, TYPE "D" FLIP-FLOP ØIC, COS-MOS, NOR GATES ØIC, C-MOS, HEX, BUFFER/INVERTER ØIC, C-MOS, HEX, BUFFER/INVERTER ØIC, DTL, C-MOS, QUAD, BILATERAL SU	381848	49671	DU4049AE	KEF.	4	
U9	ØIC.C-MOS, DUAL, 4-BIT STATIC SHFT RGSTR	363838	49671	LU4015HE	1 REF	1	
U10	OIL, L-MUS, DUHL, 4-BIT STHILL SHET RUSTR	340125	04713	UC 140 100F	KET		
U11	ØIC, C-MOS, DUAL, 4-INPUT, NOR GATES ØIC, C-MOS, HEX, BUFFER∕INVERTER	363820	49671	C04049AS DC4049AE CD4016AE MC14015CP CD4002AE DC4049AE DC4049AE DC4049AE	1 REF	1	
U12	WIL, LTUD, HEA, BUFFER/INVERIER	381848	49671	DC 40 45 45	KET		
U13	WILL U-MUS, MEX, BUFFER/INVERIER	381848	49671	DC 40 49 AE	REF		
U14	ØIC, C-MOS, HEX, BUFFER/INVERTER ØIC, C-MOS, HEX, BUFFER/INVERTER ØIC, C-MOS, HEX, BUFFER/INVERTER OP TO ISOLATOR, PHOTO XSTR OP TO ISOLATOR, PHOTO XSTR	381848	49671	DC4049AE	REF		
U15	WILL C-MUS. HEX. BUFFER/INVERTER	381848	49671	DC4049RE	REF		
U16	UP TO ISOLATOR PHOTO XSTR	380014	86539	MCT2	2	1	
U17	UP TO ISOLATOR, PHOTO XSTR	380014	86539	MCT2	REF		




Figure 602-3. DOU PCB Assembly

	•
	· .
	· ····································
	-
	5
	· ·
	-

Option -007 Ohms Converter

607-1. INTRODUCTION

607-2. The Ohms Converter, Option -007, is a field installable pcb assembly designed to extend the measurement capability of the 8810A to include resistance. It contributes six ranges (200 Ω , 2 k Ω , 20 k Ω , 200 k Ω , 2000 k Ω , and 20 M Ω), and employs a constant current conversion technique to provide a voltage reading equivalent to the measured resistance. Both two- and four-wire measurements can be made on all ranges. Maximum resolution on the 200 ohm range is 1 milliohm.

607-3. SPECIFICATIONS

607-4. Specifications for the Ohms Converter are given in Section 1 of this manual.

607-5. INSTALLATION

607-6. Use the following procedure to install the Ohms Converter:


- 1. Remove the 8810A from its case, then remove the top guard cover.
- 2. Determine the measurement functions that will be available when the Ohms Converter is installed; i.e., DCV and kΩ or DCV, ACV and kΩ. If ACV is not available, prepare and install the Lockout Assembly as shown in Figure 607-1. If the True RMS/AC Converter (Options -009/-008) is installed, the Lockout Assembly is not required. In this case, complete only steps 1, 2, and 3 of Figure 607-1.
- Position and install the Ohms Converter PCB
 Assembly on the Main PCB Assembly as shown in Figure 607-2. The Ohms Converter

PCB mates with pins on the Main PCB. Press the pcb into place.

- 4. Connect the five loose wires on the Ohms Converter PCB to the pins indicated in Figure 607-2.
- 5. Install the top guard cover on the 8810A and perform the Calibration adjustments procedure given later in this subsection.

607-7. OPERATION

607-8. Once installed the Ohms Converter requires no operator attention. Instructions for making resistance measurements are included in Section 2 of this manual.



- Straighten both ends of the currently installed Lockout Strip.
- Release all three FUNCTION switches by positioning the strip so that one of the released switches can be operated, then partially depress the released switch.
- Remove the Lockout Strip by sliding it sideways under the FUNCTION switch frame.
- Position and insert the new Lockout Strip as shown above. Adjust the strip so that the DCV and KΩ switches are free to operate, and the ACV switch is locked out.
- 5. When the Lockout Strip is properly positioned bend both end tabs up to secure its position.

Figure 607-1. Installing the Lockout Strip




Figure 607-2. Ohms Converter PCB Installation Details

607-9. THEORY OF OPERATION

607-10. The Ohms Converter determines the value of an unknown resistance by comparison. When the same current is applied to a resistance of known value and a resistance of unknown value the voltage level developed across each is directly proportional to the value of each resistance. A comparison of the two voltage levels will indicate the value of the unknown resistance relative to the value of the known resistance. The simplified circuit diagram, in Figure 607-3 shows how the Ohms Converter produces the two voltages to be compared by the A/D Converter.

607-11. The current to be applied to the known and unknown resistance is supplied by a constant current source consisting of a voltage regulator, (Q21 and Q1), and a current regulator, Q2 and CR2). The voltage regulator is designed such that any change in input or output voltages will proportionally change Q2's impedance thus drawing the output voltage back to the desired value. This output voltage controls the bias on

Q2's base, and with a constant emitter bias, (supplied by CR2) Q2's collector current will remain very stable over wide variances in supply voltage or load conditions. This current is then applied to the known and unknown values of resistance so that a comparison can be obtained.

F

607-12. The Ohms Converter employs an overvoltage protection circuit consisting of Q2, Q22, and Q23 that enables it to withstand input transients up to 1 kV dc or peak ac. High voltage applied to the protection circuit is enough to make appreciable reverse current to flow through Q23. This will effectivly connect Q23 and Q22 in series for a total standoff voltage of 700V. If the voltage continues to rise, Q2 will also be connected in the series and the total standoff will then be 1 kV. The current in this case is dissipated by resistors R35, R36, and R37.

CAUTION

It should be noted that the protection scheme used in the Ohms Converter is designed primarily for protection against voltages below 300V dc and ac, but can withstand transients of up to 1 kV.




Figure 607-3. Ohms Converter Simplified Circuit Diagram

607-13. During the integrate time period the DE (-R). Ω control signal closes switch Q8. The positive voltage developed by the current flow across Rx is applied through the INPUT. Ω SENSE HI terminal to the DC Buffer and A/D Controller. At the end of the integrate period Q8 opens and Q4 and Q6 close. The negative voltage developed across the known resistance, termed ohms output, passes through Q6 to the A/D Converter.

607-14. PERFORMANCE TEST

607-15. Using the resistor decade (specified in Table 4-1), apply the resistance values indicated in Table 607-1, to the 8810A input terminals. Select the specified range and observe the 8810A for the proper results.

NOTE

Use four-terminal ohms measurement method.

607-16. CALIBRATION ADJUSTMENTS

607-17. Use the following procedure to calibrate the Ohms Converter. See Section 4 for the list of recommended equipment.

NOTE

Remove the shorting links that connect the two HI terminals together and the two LO terminals together. Use the four-terminal measurement technique for this procedure.

- 1. Select the $k\Omega$ function.
- 2. Connect a 10 M Ω standard resistance (ESI 1063B resistor decade) to the INPUT terminals.
- 3. Select the 20 M Ω range.
- 4. Adjust the 10 M Ω cal (R5) for an 8810A display of 10.0000 ± 3 digits.
- 5. Apply a 100 k Ω standard resistance to the input. The display should indicate 0.1000 ± 1 digit.
- 6. Apply a 1 M Ω standard resistance to the input. The display should indicate 1.0000 ± 4 digits.
- 7. Select the 2000 k Ω range and adjust the 1 M Ω cal (R6) for an 8810A display of 1000.00 ± 1 digit.

Table 607-1. Resistance Checks

RANGE	INPUT	DISPLAY LIMITS	LED ANNUN CIATOR
20ΜΩ	10ΜΩ	9.9797 10.0203	20 ΜΩ
2000ΚΩ	1000ΚΩ	999.47 — 1000.53	į
	(1MΩ)	ľ	
200ΚΩ	100KΩ	99.987 - 100.013	
20ΚΩ	10ΚΩ	9.9987 - 10.0013	
2ΚΩ	1ΚΩ	.99987 — 1.00013	
200Ω	100Ω	99.970 - 100.030	200Ω
200Ω	10Ω	09.988 - 010.012	200Ω
AUTO	10Ω	09.988 - 010.012	200Ω
AUTO	100Ω	99.970 100.030	200Ω
AUTO	1ΚΩ	.99987 1.00013	
AUTO	10ΚΩ	9.9987 - 10.0013	
AUTO	100ΚΩ	99.9987 - 100.013	
AUTO	1000ΚΩ	999.47 1000.53	
1	$(1M\Omega)$		
AUTO	10ΜΩ	9,9797 — 10,0203	20ΜΩ

- 8. Apply a 100 k Ω standard resistance to the input. The display should indicate 100.00 ± 1 digit.
- 9. Select the 200 k Ω range.
- 10. Adjust the 100 k Ω cal (R8) for an 8810A display of 100.000 \pm 1 digit.
- 11. Apply a 10 k Ω standard resistance to the input. The display should indicate 10.000 ± 1 digit.
- 12. Select the 20 k Ω range.
- 13. Adjust the 10 k Ω cal (R10) for an 8810A display of 10.000 ± 1 digit.
- 14. Apply a 1 k Ω standard resistance to the input. The display should be 1.0000 ± 1 digit.
- 15. Select the $2 k\Omega$ range.
- 16. Adjust the 1 k Ω cal (R13) for an 8810A display of 1.00000 ± 1 digit.
- 17. Apply a 100Ω standard resistance to the input. The display should be .10000 ± 1 digit.
- 18. Select the 200Ω range.
- 19. Verify that the 8810A display is 100.000 ±6 digits.
- 20. Select the AUTO pushbutton. The unit should remain in the 200Ω range.
- 21. Remove the 100Ω input resistor. The unit should step to the 20 M Ω range.

22. Connect the shorting links for two-terminal operation.

verter PCB Assembly is given in Table 607-2. Refer to Section 4 of this manual for ordering information.

CAUTION

607-18. LIST OF REPLACEABLE PARTS

607-19. A list of replaceable parts for the Ohms Con-

Indicated devices are subject to damage by static discharge.

Table 607-2. Ohms Converter PCB Assembly

ITEM NO.	DESCRIPTION	FLUKE STOCK NO.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC USE
	OHMS CONVERTER PCB ASSY (8800A-4010T) FIGURE 607-4					
C1	CAP, POLYSTYRENE, 0.022 UF +/-10%, 100V	333823			1	
C5	CAP, TA, 100 PF +/-10%, 1 KV	105593			1	
C6	CAP, TA, 10 UF +/- 20\$, 15V	193623		-	1	
C8	CAP, MICA, 33 PF +/-5%, 500V	160317	_		1	
C9	CAP, MICA, 10 PF +/-5%, 500V	105536 309849			1	
C10 C11	CAP, CER, 0.22 UF +/-20%, 50V CAP. TA. 4.7 UF +/-20%, 25V	161943			i	
C12	CAP, TA, 0.22 UF +/-20\$, 25V	161331			1	
C13	CAP, CER, 0.05 UF +/-20%, 100V	149161			1	
CR2	DIODE, LIGHT EMITTING, RED	385898		59NSL-5046	1	1
CR4	DIODE, SI		07263	FD7223	5	1
CR5	DIODE, SI	348177	07263	FD7223	REF	
CR8	DIODE, SI	348177	07263	FD7223	REF	
CR9	DIODE, SI	348177	07263	FD7223	REF	
CR10	DIODE, SI	453399	0 1295	1N4007	3	1
CR11	DIODE, SI	453399			REF	
CR12	DIODE, SI		01295		REF	
CR13	DIODE, SI	348177	07263	FD7223	REF	
14	CONNECTOR, FEMALE			0-06-0	0	
İ	PIN, SMALL	375329		85863-3	8	
	PIN, LARGE		74970		3	
K1	RELAY, DRY REED, SPST		71707		14 14	
K2	RELAY, DRY REED, SPST		71707		ref ref	
К3	RELAY, DRY REED, SPST	357582			REF	
K4	RELAY, DRY REED, SPST	357582			1	
L1	CHOKE, RF, 4.7 UH	174722 225599			2	1
Q1	XSTR, SI, PNP	370684			3	1
Q2	XSTR, SI, NPN	168716		4	3	•
Q3 Q4	XSTR, SI, NPN XSTR, SI, NPN	261578			2	1
Q5	XSTR, SI, NPN	218396			4	1
Q6	XSTR, FET, N-CHANNEL	343830			1	1
Q7	XSTR, SI, NPN	168716			REF	
Q8	XSTR, SI, NPN	261578			REF	
Q9	XSTR, SI, NPN	218396		2N3904	REF	
Q17	XSTR, SI, NPN	168716	12040	ST07154	REF	
021	XSTR, SI, PNP	225599		PN4250	REF	
022	XSTR, SI, NPN	370684			REF	
Q23	XSTR, SI, NPN	370684	04713		REF	
Q24	XSTR, SI, NPN	218396			REF	
Q25	XSTR, SI, NPN	218396		- -	REF	
R1	RES, DEP CAR, 22K +/-5%, 1/4W	348870	_		2	
R3	RES, DEP CAR, 750 +/-5%, 1/4W	441659		2.2	1	_
R5	RES, VAR, CERMET, 50K +/-10%, 1/2W	288290			1	1
R6	RES, VAR, CEMMET, 2K +/-10%, 1/2W	403428			1	1
R8	RES, VAR, 100 +/-10%, 1/2W	326116			1	1
R10	RES, VAR, 100K +/-10%, 1/2W	288308	_		1	1
R11	RES, MF, 1M +/-1%, 1/8W	268797			1	
R12	RES, DEP CAR, 30K +/-5\$, 1/4W	368753	_	_	5 1	1
R13	RES, VAR, 10K +/-10%, 1/2W	285171	89536	11103111		<u> </u>

ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY Code	MFG PART NO. OR TYPE		REC QTY	
R14	RES, MF, 95.3K +/-1%, 1/8%	289561	91637	MFF1-81002F	1	L	l
R16	RES, DEP CAR, 1M +/-5%, 1/4W	348987	80031	CR251-4-5P-1MT	3		
Ř17	RES, DEP CAR, 1M +/-5%, 1/4W	348987	80031	CR251-4-5P-1MT	REF		
R18	RES, DEP CAR, 1M +/-5%, 1/4W	348987	80031	CR251-4-5P-1MT	REF		
R19	RES, DEP CAR 150K +/-5%, 1/4W	348938	80031	CR251-4-5P-150KT	1		
R20	RES, DEP CAR 330K +/-5%, 1/4W	376640	80031	CR251-4-5P-330KT	1		
R25	RES, DEP CAR, 120K +/-5%, 1/4W	441386	80031	CR251-4-5P-120KT	1		
R26	RES, COMP, 470K +/-5%, 2W	147710	01121		1		
R27	RES, DEP CAR, 100K +/-5%, 1/4W	348920	_		1		
R29	RES, DEP CAR, 22K +/-5%, 1/4W	348870	_		REF		
R31	RES, DEP CAR, 10K +/-5%, 1/4W	348839	80031	CR251-4-5P-10KT	4		
R32	RES, DEP CAR, 10K +/-5%, 1/4W	348839	80031		REF		
R33	RES, DEP CAR, 10K +/-5%, 1/4W	348839	80031	CR251-4-5P-10KT	REF		
R34	RES, DEP CAR, 10K +/-5%, 1/4W	348839	80031	CR251-4-5P-10KT	REF		
R35	RES, COMP, 390K +/-5%, 1/2W	222190		•	2		
R36	RES, COMP, 390K +/-5%, 1W	453472	01121	GB3945	1		
R37	RES, COMP, 390K +/-5%, 1/2W	222190		** *	REF		
R38	RES, DEP CAR, 30K +/-5%, 1/4W	368753	80031	CR251-4-5P-30KT	REF		
R39	RES, DEP CAR, 30K +/-5%, 1/4W			CR251-4-5P-30KT	REF		
R40	RES, DEP CAR, 30K +/-5%, 1/4W	368753	-		REF		
R4 1	RES, DEP CAR, 30K +/-5%, 1/4W	368753	80031		REF		
R42	RES, DEP CAR, 120 +/-5%, 1/4W	442293	80031		1		
R43	RES, DEP CAR, 220 +/-5%, 1/4W	342626	80031		2		
R44	RES, DEP CAR, 220 +/-5%, 1/4W	342626	80031	CR251-4-5P-220ET	REF		
RN6	RESISTOR NETWORK	363796	01121		1	1	
T1	XFMR	457168	89536	457168	1		
W3	WIRE ASSY, SHIELDED	457077	89536	45707 <u>7</u>	1		
n 4	WIRE ASSY, BRN	373738	89536	373738	1		
* 5	WIRE ASSY, YEL	457069	89536	457069	1		
W6	WIRE ASSY, BLK/WHT	•	89536	378281	1		
w7	WIRE ASSY, ORN	457051	89536	457051	1		
	(2) (2) (2) (2) (3) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	\$\frac{20}{100}\$	<u>ا ـــــــا</u> ا	R I E R A			




Figure 607-4. Ohms Converter PCB Assembly

r- F

.

Option -008 AC Converter

608-1. INTRODUCTION

608-2. The AC Converter, Option -008, is a field installable pcb assembly designed to extend the measurement capability of the 8810A to include ac voltages, it contributes four ranges (2, 20, 200, and 750V ac) and employs average ac conversion techniques to provide an rms indication with a maximum sensitivity of $10~\mu V$. Circuit loading is minimized by a $2~M\Omega$ input resistance shunted by less than 100~pF. Response time is 1.5~seconds to achieve rated accuracy of the selected range.

608-3. SPECIFICATIONS

608-4. Specifications for the AC Converter are presented in Section 1 of this manual.


608-5. INSTALLATION

608-6. Use the following procedure to install the AC Converter:

- 1. Remove the 8810A from its case, then remove the top guard cover.
- 2. Determine the measurement functions that will be available when the AC Converter is installed, i.e., DCV and ACV or DCV, ACV, and $k\Omega$. If $k\Omega$ is not available, prepare and install the Lockout Assembly as shown in Figure 608-1. If the Ohms Converter (Option -007) is installed, the Lockout Assembly is not required. In this case, complete only steps 1, 2, and 3 of Figure 608-1.
- 3. Position and install the AC Converter PCB Assembly on the Main PCB Assembly as

shown in Figure 608-2. The AC Converter PCB mates with pins provided on the Main PCB. Press the pcb into place.

- 4. Connect the red/white wire on the AC Converter PCB to the pin marked RD/W (See Figure 608-2) on the rear of the Display PCB Assembly.
- 5. Install the top guard cover on the 8810A and perform the Calibration Adjustments procedure given later in this subsection.



- Straighten both ends of the currently installed Lockout Strip.
- Release all three FUNCTION switches by positioning the strip so that one of the released switches can be operated, then partially depress the released switch.
- Remove the Lockout Strip by stiding it sideways under the FUNCTION switch frame.
- 4. Position and insert the new Lockout Strip as shown above. Adjust the strip so that the DCV and ACV switches are free to operate, and the $K\Omega$ switch is locked out.
- 5. When the Lockout Strip is properly positioned bend both end tabs up to secure its position.

Figure 608-1. Lockout Strip Installation Instructions




Figure 608-2. AC Converter PCB Installation Details

608-7. OPERATION

608-8. Once installed the AC Converter requires no operator attention. Instructions for making ac voltage measurements are included in Section 2 of this manual.

608-9. THEORY OF OPERATION

608-10. The AC Converter produces a dc output voltage proportional to the ac input voltage. The simplified circuit diagram of the AC Converter, presented in Figure 608-3, should be referred to when reading the following description of the circuit operation.

608-11. The ac voltage input is capacitively coupled across C1 through input Resistor R1 to the inverting input of amplifier Q1, U1. The gain of the amplifier is determined by the ratio of the feed-back resistance, as selected by range relay K6, K7, and K8, to the input resistor R1. The amount of alternating current at the junction point of CR4 and CR5 is therefore proportional to the level of the ac voltage input. One-half of the alternating current passes through CR5 to develop a dc voltage level at the input of the Low Pass (L.P.) Filter. The L.P. Filter then filters the ac signal superimposed on the dc voltage to produce a dc output voltage directly proportional to the ac voltage input.




Figure 608-3. AC Converter Simplified Circuit Diagram

608-12. The AC Converter circuitry creates an offset voltage that, if not compensated for, would create an error in the displayed value of the ac input voltage. The offset voltage, sensed at the junction point of R17, C13, and C14, is applied to C18 when FET switches Q6 and Q9 are turned on; these switches are turned off by an integrate (INT) signal applied to Q8. When the AC GATE command (coincidental with the INT command) turns on Q7, the dc output voltage of the L.P. Filter will be reduced by the value of the feed-back voltage stored in C18. The dc voltage output to the A/D Converter is therefore representative of the level of ac input voltage.

608-13. PERFORMANCE TEST

608-14. Sequentially select the ac voltage ranges shown in Table 608-1 and apply the indicated voltage/frequency for each range setting (use the ac calibrator specified in Table 4-1). The 8810A display should read

Table 608-1. AC Voltage Checks

VAC RANGE	AC INPUT VOLTAGE	FREQUENCY IN H2	DISPLAY LIMITS
2 VAC 2 VAC 20 VAC 200 VAC 200 VAC 750 VAC 750 VAC AUTO AUTO AUTO	1.00000 1.0000 10.0000 10.0000 50.000 50.000 100.000 100.000 1.0000 10.0000	400 Hz 100 kHz 400 Hz 100 kHz 400 Hz 100 kHz 400 Hz 20 kHz 10 kHz 10 kHz 10 kHz	.99890 — 1.00110 .98940 — 1.01060 9.9890 — 10.0110 9.8940 — 10.1060 49.940 — 50.060 49.440 — 50.560 99.830 — 100.170 99.710 — 100.290 .09955 — .10045 .99730 — 1.00270 .99730 — 1.00270
AUTO	750.00	10 kHz	997.75 — 1002.25

within the limits shown. Complete the calibration adjustments procedure if the AC Converter fails any part of this test. Otherwise the calibration adjustments will not be required.

608-15. CALIBRATION ADJUSTMENTS

608-16. The following procedure is used to adjust the accuracy of each of the ac voltage ranges. All adjustments are made with the AC Converter's shield in place and the 8810A's top guard in place. Adjustment names given in this procedure agree with those silk-screened onto the top guard cover. The reference designator for each adjustment is given in parenthesis.

608-17. Sequentially select the ac voltage ranges shown in Table 608-2 and use an ac calibrator to apply the indicated voltage/frequency for each range setting. As each input signal is applied, adjust the specified adjustment for an 8810A display reading within the limits shown.

608-18. LIST OF REPLACEABLE PARTS

608-19. A list of replaceable parts for the AC Converter PCB Assembly is given in Table 608-3. Refer to Section 5 of this manual for ordering information.



Indicated devices are subject to damage by static discharge.

Table 608-2. AC Voltage Range Adjustments

VAC RANGE	AC INPUT VOLTAGE (RMS)	FREQUENCY IN Hz	ADJUSTMENT	DISPLAY LIMITS
750	500	500	500V/500 Hz (R20)	499.97 to 500.03
750	500	10k	100V/50 kHz (C2)	499.97 to 500.03
2	1.0	500	1.0V/500 Hz (R6)	.99995 to 1.00005
2	1.0	50k	1.0V/50 kHz (C7)	.99980 to 1.00020
750	500	10k	100V/50 kHz (C2)	499.50 to 500.50
2	1.0	50k	1.0V/50 kHz (C7)	.99950 to 1.00050
200	100	500	100V/500 Hz (R10)	99.995 to 100.005
200	100	50k	500V/10 kHz(C23)	99.950 to 100.050
20	10	500	10V/500 Hz (R8)	9.9995 to 10.0005
20	10	50k	10V/50 kHz (C9)	9.9950 to 10.0050

Table 608-3, AC Converter PCB Assembly

	Table 608-3. AC Converter PCB Assembly						
ITEM NO.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC QTY	
	AC CONVERTER PCB ASSY. (8800A-4014)						
	FIGURE 608-3	407004		70 (OTO)			
C1	CAP JOB TECHON TRIMMED & 25 1 F BE 1880	423004	2000	75-12395H	1 2		
C2 C3	CAP CEP 0 22 NE +/-20% 50V	Z09849	71590	536-661	2		
C4	CAP, CER, 50,000 PF +/-GMV, 1 KV CAP, VAR, TEFLON, TRIMMER, 0.25-1.5 PF, 100V CAP, CER, 0.22 UF +/-20%, 50V CAP, CER, 15 PF +/-2%, 100V CAP, CER, 0.22 UF +/-20%, 50V CAP, CER, 2.2. PF +/-0.25 PF, 100V CAP, VAR, TEFLON, TRIMMER, 0.25-1.5 PF, 100V CAP, CER, 27 PF +/-2%, 100V	369074	72982	8111-A100-C0G-150G	_		
C5	CAP, CER, 0.22 UF +/-20%, 50V	309849	71590	CW30C224K	REF		
C6	CAP, CER, 2.2. PF +/-0.25 PF, 100V	362731	72982	8101-A100-C0G-229G	1		
C7	CAP, VAR, TEFLON, TRIMMER, 0.25-1.5 PF, 100V CAP, CER, 27 PF +/-2%, 100V CAP, VAR, CER, 1.7-10 PF, 250V CAP, MICA, 390 PF +/-1%, 500V CAP, POLYSTYRENE, 9100 PF +/-2.5%, 160V	273151	72982	530-001	REF		
CB							
C9	CAP, VAR, LER, 1.7-10 PF, 200V	3/5/38 755770	72176	PW1ED201E	1		
C10 C11	CAP POLYSTYPENE, 9100 PF +/-2 5%, 160V	355327 355321	71590	2009331F 2009001-912000	1		
C12	CAP. TA. 10 UE +/-20%, 15V	193623	56289	196D106X-0015KA1	1		
C13	CAP, TA, 220 UF +/-20%, 6V	408682	56289	196D227X-0006TE4	3		
C14	CAP, TA, 220 UF +/-20%, 6V	408682	56289	196D227X-0006TE4	REF		
C15	CAP, TA, 5.6 UF +/-20%, 25V	368969	56289	196D565X-0025KA1	1		
C16	CAP, PLYESTER, FILM, 0.47 UF +/-10%, 100V	369124	73445	C280MAH/A470K	2		
C17	CAP, PLYESTER, FILM, 0.47 UF +/-10%, 100V	369124	73445	1280MAHZH4ZUK	KEF.		
C18 C19	COD CED 100 DE 1/-100 500U	105000	56289	1207220V-8880A	1		
C20	CAP. CER. 0.01 HE +/-20%, 100V	149153	56289	C023B101F-103M	3		
C21	CAP, CER, 0.01 UF +/-20%, 100V	149153	56289	C023B10:F-103M	REF		
C22	CAP, CER, 0.01 UF +/-20%, 100V	149153	56289	C023B101F-103M	REF		
C23	CAP, VAR, CER, 5-50 PF, 250V	404301	52769	GKC50000	1		
C26	CAP, TA, 220 UF +/-20%, 6V	408682	56289	196D227X-0006TE4	REF		
CR1	DIODE, SI	3/550/ 775007	07263	F97222	DEE	1	
CR2 CR3	DIODE 81	373307 375907	07263 07263	FD7222	REE		
CR4	DIODE, SI	375907	07263	FD7222	REF		
CR5	DIODE, SI	375907	07263	FD7222	REF		
CR6	DIODE, FET, CURRENT REG	334714	07910	TCR5315	1	1	
К6	CAP. VAR. CER. 1.7-10 PF. 250V CAP. MICA, 390 PF +/-1%, 500V CAP. MICA, 390 PF +/-1%, 500V CAP. POLYSTYRENE, 9100 PF +/-2.5%, 160V CAP. TA, 10 UF +/-20%, 15V CAP. TA, 120 UF +/-20%, 6V CAP. TA, 220 UF +/-20%, 6V CAP. TA, 5.6 UF +/-20%, 25V CAP. TA, 5.6 UF +/-20%, 25V CAP. PLYESTER, FILM, 0.47 UF +/-10%, 100V CAP. PLYESTER, FILM, 0.47 UF +/-10%, 100V CAP. CAP. CER. 180 PF +/-10%, 500V CAP. CER. 180 PF +/-10%, 500V CAP. CER. 0.01 UF +/-20%, 100V CAP. CER. 0.01 UF +/-20%, 100V CAP. CER. 0.01 UF +/-20%, 6V DIODE, SI DIODE, S	357566	71707	UF 40069	3		
K7	RELAY, REED, SPST	357566	71707	UF40069	REF		
K8 MP1	FONN. PERSIONS DET	170490	74970	105-752	7		
MP2	CONN. RECEPTACLE, BD-MOD2	375329	00779	85863-3	8		
MP3	HEATSINK, XSTR	370155	05820	204-CB	1		
MP4	SCREW, PHP, 4-40 X 1/4	129890	73734	19022	3		
MP5	SHIELD	406280	89536	406280	1		
MP6	SPACER, XSIR MTG	175125	07047	10172-DAP	1		
MP7 MP8	SPACED DED HOTED SOUTHERE THEE HY CO CZY	334/9/ 700700	32559	10-35-15 T9-31-19	1		
Q1	XSTR. DIAL FET	300130 379321	32JJ3 89536	379321	1	1	
Q2	XSTR, SI, NPN	218396	04713	2N3904	2	i	
Q4	XSTR, SI, PNP, SELECTED	352146	89536	352146	1	1	
Q5	XSTR, SI, NPN	330803	04713	MPS6560	1	1	
Q6	XSTR, FET, N-CHANNEL	343830		343830	3	1	
Q7	XSTR, FET, N-CHANNEL	343830	89536		REF		
Q8 Q9	XSTR, SI, NPN XSTR, FET, N-CHANNEL	218396 343830	04713 89536	2N3904 343830	REF REF		
R1	RES, MF, 2M +/-0.5%, 1W (RED COATING)	354894	89536		KET 1		
R2	RES, MF, 71,5K +/-1%, 1/8W	291435		MFF1-87152F	1		
R3	RES. MF, 158K +/-1%, 1/8W			MFF1-81583F	į		
R4	RES. DEP CAR, 240 +/-5%. 1/4W RES. MF. 498.89K +/-0.1%.1/4W	376624		CR251-4-5P-240ET	1		
R5	RES. MF. 498.89K +/-0.1%.1/4W	357632			1		
₹6	RES, VAR, CERMET, 2K +/-10%, 1/2W	285163	89536	285163	1	1	

Table 608-3. AC Converter PCB Assembly (cont)

ITEM NO.	DESCRIPTION	FLUKE STOCK NO.	MFG SPLY CODE	MFG PART NO. OR TYPE		REC QTY	
R7	RES. MF. 55.151 +/-0.1%, 1/8W	357624	89536	357624	1		
R8	RES, VAR, CERMET, 200 +/-10%, 1/2W	285148	89536	285148	ī	1	
R9	RES, MF, 4787.4 +/-0.1%, 1/8W	357616	89536	357616	1	_	
R10	RES, VAR, CERMET, 20 +/-20%, 1/2W	285114	11236	369TS200B	ī	1	
R11	RES. MF. 258 +/-0.1%. 1/8W	357608	91637	MFF1-825108	2	•	
R12	RES. DEP CAR. 1 +/-5%. 1/4W	357665	80031	CR251-4-5P-1ET	1		
R13	RES, MF, 9.09K +/−1%, 1/8W	221663	91637	MFF1-89091F	i		
R14	RES. MF. 33.2K +/-1%, 1/8W	291393	91637	MFF1-83322F	1		
Ř15	RES, DEP CAR, 220 +/-5%, 1/4W	342626	80031	CR251-4-5P-220ET	ī		
R17	RES, MF, 250 +/-0.1%, 1/8W	357608	91637	MFF1-82519B	REF		
R18	RES. DEP CAR. 3.3K +/-5%, 1/4W	348813	80031	CR251-4-5P-3K3T	1		
R19	RES. DEP CAR. 10K +/-5%, 1/4W	348839	80031	CR251-4-5P-10KT	ī		
R20	RES, VAR, CERMET, 50 +/-10%, 1/2W	285122	89536	285122	ī	1	
R21	RES, MF, 2194 +/-0.1%, 1/8W	375345	89536	375345	ĩ	-	
R22	RES. MF. 68.1K +/-1%. 1/8W	236828	91637	MFF1-86812F	i		
R23	RES. DEP CAR. 150K +/-5%. 1/4W	348938	80031	CR251-4-5P-100KT	1		
R24	RES. DEP CAR. 220K +/-5%. 1/4W	348953	80031	CR251-4-5P-220KT	1		
R25	RES, DEP CAR, 47K +/-5%, 1/4W	348896	80031	CR251-4-5P-47KT	ī		
R26	RES, DEP CAR, 22 +/-5%, 1/4W	381145	80031	CR251-4-5P-22ET	1		
R27	RES, DEP CAR, 75K +/-5%, 1/4W	394130	80031	CR251-4-5P-75KT	1		
R28	RES, DEP CAR, 12K +/-5%, 1/4W	348847	80031	CR251-4-5P-12KT	1		
R29	RES, COMP. 47K +/-5%, 1/4W	148163	01121	CB4735	1		
R30	RES. VAR. CERMET. 14 +/-10%, 1/2W	275750	89536	275750	ī	1	
R31	RES, MF, 48.7K +/-1%, 1/8W	267385	91637		ī	-	
U1	IC, OP AMP	329912	12040	LM318H	ī	1	
W8	WIRE ASSEMBLY	373688	89536	373688	ī	-	




Figure 608-3. AC Converter PCB Assembly

• · · · • •

Option -009 True RMS Converter

609-1. INTRODUCTION

609-2. The True RMS Converter, Option -009, is a field installable pcb assembly designed to extend the measurement capability of the 8810A to include true rms voltage measurements. It contributes four ac voltage ranges (2, 20, 200, and 750V ac) and employs a true rms conversion technique to provide true rms measurements with a maximum sensitivity of 10 μ V. Circuit loading is minimized by a 1 M Ω input resistance shunted by 100 pF. Response time is 1.5 seconds to achieve rated accuracy of the selected range. Crest factor is 3.

609-3. SPECIFICATIONS

609-4. Specifications for the True RMS Converter are given in Section 1 of this manual.

609-5. INSTALLATION


609-6. Use the following procedure to install the True RMS Converter:

- 1. Remove the 8810A from its case; then remove the top guard cover.
- 2. Determine the measurement functions that will be available when the True RMS Converter is installed; i.e., DCV and ACV or DCV, ACV, and $k\Omega$. If $k\Omega$ is not available, prepare and install the Lockout Assembly as shown in Figure 609-1. If the Ohms Converter (Option -007) is installed, the Lockout Assembly is not required. In this case, complete only steps 1, 2, and 3 of Figure 609-1.
- 3. Position and install the True RMS Converter PCB Assembly on the Main PCB Assembly as shown in Figure 609-2. The True RMS Converter mates with pins provided on the Main PCB. Press the pcb into place.

- 4. Connect the red/white wire on the True RMS
 Converter PCB to the pin marked RD/W
 (See Figure 609-2) on the rear of the Display
 PCB Assembly.
- 5. Install the new top-guard cover on the 8810A and perform the Range Adjustments portion of the Calibration Adjustments procedure.

609-7. OPERATION

609-8. Once installed the True RMS Converter requires no operator attention. Instructions for making ac voltage measurements are included in Section 2 of this manual.



- Straighten both ends of the currently installed Lockout Strip.
- Release all three FUNCTION switches by positioning the strip so that one of the released switches can be operated, then partially depress the released switch.
- Remove the Lockout Strip by sliding it sideways under the FUNCTION switch frame.
- 4. Position and insert the new Lockout Strip as shown above. Adjust the strip so that the DCV and ACV switches are free to operate, and the $K\Omega$ switch is locked out.
- When the Lockout Strip is properly positioned bend both end tabs up to secure its position.

Figure 609-1. Installing the Lockout Strip




Figure 609-2. True RMS Converter PCB Installation Details

609-9. THEORY OF OPERATION

609-10. The True RMS Converter operates as the 8810A input signal conditioner when the ACV measurement function is selected. Its function is to accept ac input signals, scale them to the selected range, and convert them to a dc level proportional to the true rms value of the input signal. The conversion is mathematically obtained by electroncially squaring and averaging the value of the ac input signal, then taking the square root of that value (Vrms $= \sqrt[4]{\mathrm{Vin}^2}$). The resultant dc level is used as the input to the A/D Converter.

Operation of the True RMS Converter can be 609-11. divided into five functional groups as shown in Figure 609-3. They include a range amplifier, an absolute value amplifier, a squaring amplifier, a square root amplifier, and an integrator amplifier. The input signal is introduced at the range amplifier where it is scaled to the selected range and buffered. It is then passed on to the absolute value amplifier. This amplifier operates as a full wave rectifier. It converts the ac input voltage into an equivalent positive dc current. The squaring amplifier converts the current into a voltage equal to two times the log of the input, and thus effectively squares the signal. At the square root amplifier the logarithmic voltage is divided in half and converted back into a current. The process effectively takes the square root of the squared input signal and presents it to the input of the integrator amplifier. A current-to-voltage network filters this




Figure 609-3. True RMS Converter Simplified Circuit Diagram

voltage and presents it as the dc output of the True RMS Converter. This dc level is proportional to the true rms value of the ac intput signal and is used as a direct input to the 8810A's A/D Converter.

609-12. PERFORMANCE TEST

609-13. Sequentially select the ac voltage ranges shown in Table 609-1 and apply the indicated voltage/frequency for reach range setting (use the ac calibrator specified in Table 4-1). The 8810A display should read within the limits shown. Complete the calibration adjustments procedure if the True RMS Converter fails any part of this test. Otherwise the calibration adjustment will not be required.

609-14. CALIBRATION ADJUSTMENTS

609-15. Calibration adjustments for the True RMS Converter are divided into two procedures; Amplifier Bias and Offset Adjustments, and Range Adjustments. The bias and offset adjustment procedure is devoted to zeroing the linear components on the True RMS Converter. The range adjustment procedure ensures the ac measurement accuracy of each available range. Required equipment is listed earlier in Section 4, Table 4-1.

NOTE

These procedures assume that the basic 8810A has met the performance test requirements given in Section 4 of this manual.

609-16. Amplifier Bias and Offset Adjustments

609-17. The following procedure is used to initially zero the linear components on the True RMS Converter PCB. All adjustments are made with the 8810A's top guard cover removed. Adjustment locations are shown in Figure 609-4. If the 8810A is equipped with an Ohms Converter (Option -007), it should also be removed

Table 609-1. AC Voltage Checks

VAC RANGE	AC INPUT VOLTAGE	FREQ IN Hz	DISPLAY LIMITS
2	0.10000	500	0.09880 to 0.10120
2	1.00000	500	0.99700 to 1.00300
2	1.00000	50k	0.99450 to 1.00550
20	10.0000	500	9.9700 to 10.0300
20	10.0000	50k	9.9450 to 10.0550
200	100.000	500	99.700 to 100.300
200	100.000	50k	99.450 to 100.550
750	500.00	500	498.00 to 502.00
750	500.00	50k	496.50 to 503.50

during this procedure and replaced after the procedure is compelte.

NOTE

Do not perform this procedure as part of the normal calibration routine. The adjustments given herein are one-time adjustments and will not have to be performed unless the True RMS Converter has undergone repair, or one or more of the following adjustments have been moved; R3, R28, R35, R36, and/or R41. See Figure 609-4.

- 1. Energize the 8810A and select the ACV function.
- 2. Depress the 20V range switch.
- 3. Connect a short circuit between the HI-LO INPUT terminals.
- 4. Connect dc voltmeter between TP1 and the LO INPUT terminal.
- 5. Adjust R3 for a dc voltmeter reading of 0.0 ±0.1 mV dc.
- 6. Connect the dc voltmeter between TP6 and the LO INPUT terminal.
- 7. Adjust R23 for a dc voltmeter reading of 0.00 ±0.05 mV dc.
- 8. Connect the dc voltmeter between TP5 and the LO INPUT terminal.
- Adjust R28 for a dc voltmeter reading of 0.0 ±0.1 mV dc.
- 10. Connect a dc voltmeter between TP4 and the LO INPUT terminal.
- 11. Connect a jumper wire between TP3 and the LO INPUT terminal.
- 12. Connect an X1 oscilloscope probe to TP2. Use the LO INPUT terminal for the ground connection.
- Set the scope for 200 mV/division sensitivity,
 1 ms/division horizontal sweep, and dc coupling on the input amplifier.
- 14. Zero the scope and then adjust R35 on the True RMS Converter PCB for a 0V dc trace on the scope.




Figure 609-4. True RMS Converter Test Point and Adjustment Locations

- 15. Adjust R36 for a dc voltmeter reading between -0.82 and -0.87V dc.
- 16. Repeat steps 14 and 15 of this procedure until further adjustment is not required.
- 17. Remove the jumper wire connecting TP3 and the LO INPUT terminal.
- 18. Adjust R35 for a scope trace of 0V dc.
- 19. Note the reading on the dc voltmeter. Then adjust R36 clockwise until the reading is increased by 25 mV; e.g., if reading is -.943V adjust R34 for reading of -.968V.

- 20. Repeat steps 18 and 19 of this procedure until the dc voltmeter reading is between -.82 and -.87V dc at the end of step 19.
- 21. Disconnect the scope and dc voltmeter input connections at the 8810A. Also remove the short circuit between the HI-LO INPUT terminals.
- 22. Using an ac calibrator apply a 10V, 500 Hz signal to the 8810A HI-LO INPUT terminals.
- 23. Adjust R41 for an 8810A display reading between 9.9900 and 10.0100. Then adjust R40 for a reading of 10.0000 ±3 digits.
- 24. Reduce the calibrator output to IV, 500 Hz.
- 25. Adjust R42 for a display reading of 1.0000 ±2 digits.
- 26. Repeat steps 22 through 25 of this procedure. However, adjust only R40 and R42. Do not adjust R41.
- 27. Perform the Range Adjustments procedure.

609-18. Range Adjustments

609-19. The following procedure is used to adjust the accuracy of each of the ac voltage ranges. All adjustments are made with the True RMS Converter's shield in place and with the 8810A top guard in place. Adjustment names given in this procedure agree with those silk-screened onto the top guard cover. The reference designator for each adjustment is given in parenthesis.

609-20. Sequentially, select the ac voltage ranges shown in Table 609-2 and use an ac calibrator to apply the indicated voltage/frequency for each range setting. As each input signal is applied, adjust the specified adjustment for an 8810A display reading within the limits shown.

609-21. LIST OF REPLACEABLE PARTS

609-22. A list of replaceable parts for the True RMS Converter PCB Assembly is given in Table 609-3. Refer to Section 5 of this manual for ordering information.



Indicated devices are subject to damage by static discharge.

Table 609-2. AC Voltage Range Adjustments

VAC RANGE	AC INPUT VOLTAGE (RMS)	FREQUENCY IN Hz	ADJUSTMENT	DISPLAY LIMITS
2	1.00000	500	500V/500 Hz (R40)	.99997 to 1.00003
2	.10000	500	.1V/500 Hz (R42)	.09998 to .10002
2	1.00000	5000	500V/500 Hz (R40)	.99997 to 1.00003
2	.10000	500	.1V/500 Hz (R42)	.09998 to .10002
750	500.00	500	500V/500 Hz (R40)	499.98 to 500.02
750	500.00	50k	500V/50 Hz (C2)	499.70 to 500.30
2	1.00000	500	1V/500 Hz (R7)	.99997 to 1.00003
2	1.00000	50k	1V/50 kHz (C3)	.99970 to 1.00030
20	10.0000	500	10V/500 Hz (R10)	9.9997 to 10.0003
20	10.0000	50k	10V/50 kHz (C6)	9.9950 to 10.0050
200	100.000	500	100V/500 Hz (R12)	99.997 to 100.003
200	100.000	50k	100 V/50 kHz (C10)	99.950 to 100.050

Table 609-3. True RMS Converter PCB Assembly

	Table 609-3. True Rivis	<u> </u>			,		
ITEM No.	DESCRIPTION	FLUKE STOCK No.	MFG SPLY Code	MFG PART NO. OR TYPE	TOT QTY	REC QTY	
	TRUE RMS CONVERTER PCB ASSEMBLY (8810A-4024) FIGURE 609-4 CAP, CER, 0.1 UF -20/80%,500V CAP, VAR, 0.25 TO .15 PF, 2000V CAP, VAR, 0.25 TO .15 PF, 2000V CAP, CER, 4.7 PF +/-0.25 PF, 100V CAP, CER, 0.01 +/-20%, 100V CAP, CER, 0.01 +/-20%, 100V CAP, CER, 0.01 +/-20%, 100V CAP, CER, 0.01 +/-20%, 100V CAP, MICA, 120 PF +/-5%, 500V CAP, CER, 0.01 +/-20%, 100V CAP, MICA, 1500 PF, 250V CAP, TA, 10 UF, +/-20%, 20V CAP, TA, 10 UF, +/-20%, 20V CAP, TA, 10 UF, +/-20%, 20V CAP, CER, 4.7 PF +/-0.25 PF, 100V CAP, CER, 4.7 PF +/-0.25 PF, 100V CAP, CER, 0.22 UF +/-5%, 500V CAP, CER, 0.22 UF +/-5%, 50V CAP, POLYCARB, 1 UF, +/-10%, 50V CAP, POLYCARB, 1 UF, +/-10%, 50V CAP, CER, 100 PF, +/-2%, 100V CAP, CER, 0.22 UF +/-5%, 50V DIODE DIOTE DIO						
C1 C2	CAP, CER, 0.1 UF -20/80%,500V CAP, VAR, 0.25 TD .15 PF, 2000V	105684 273151	56289 72982	41C92 530-001	1 2	1	
C3 C4 C5	CAP, VAR, 0.25 IU .15 FF, 2000V CAP, CER, 4.7 PF +/-0.25 PF, 100V	273151 36772	72982	530-001 8101-A100-C0G479G	8EF 3		
C6 C7	CAP, CER, 0.01 +/-20%, 100V CAP, VAR, 1.7 TO 10 PF, 250V CAP, CER, 0.01 +/-20%, 100V	375238 149153	52769 56289	GKC 10000 C023B101F103M	1 REF	1	
C8 C9	CAP, MICA, 120 PF +/-5%, 500V CAP, CER, 0.01 +/-20%, 100V	148486 149153	72136 56289	DM15F121J C023B101F103M	1 REF		
C10 C11	CAP, VAR, 5 TO 50 PF, 250V CAP, MICA, 1500 PF +/-5%, 500V	404301 148361	52769 72136	GKC50000 DM19F152J	1	1	
C12 C13 C14	CAP, TA, 10 UF, +/-20%, 20V CAP, TA, 10 UF, +/-20%, 20V CAP, CFR, 4.7 PF +/-9, 25 PF, 100V	330662 36772	56289 72982	196D106X0020KH1 196D106X0020KA1 8101-A100-C0G479G	REF REF		
C15 C16	CAP, MICA, 390 PF +/-5%, 500V CAP, CER, 4.7 PF +/-0.25 PF, 100V	148437 36772	72136 72982	DM15F391J 8101-A100-C0G479G	1 REF		
C17 C18	CAP, CER, 0.22 UF +/-20%, 50V CAP, TA, 10 UF, +/-20%, 20V	309849 330662	71590 56289	CW30C224K 196D106X0020KA1	REF		
C19 C20 C21	CAP, POLYCHRB, 1 OF +/-10%, 50V CAP, POLYESTER, 0.22 UF +/-5%, 100V CAP, FFR, 100 PF +/-2%, 100V	436113 369173	73445 72982	C280MAH/A220K 8141-A100-G0G-101G	1 1		
C22 CR1	CAP, CER, 0.22 UF +/-20%, 50V DIODE	309849 375907	71590 07263	CW30C224K FD7222	REF 5	1	
CR2 CR3	DIODE DIODE	375907 375907	07263 07263	FD7222 FD7222	REF REF		
CR4 CR5 CR7	DIODE DIODE, ZËNER	375907 246611	07263 07910	FD7222 FD7222 1N961B	REF 2	1	
CR8 J5	DIODE, ZENER CONNECTOR, FEMALE	246611	07910	1N961B	REF		
¥ 1	PIN, LARGE PIN, SMALL	170480 375329	74970 00779	105-752 85863-3	2 6		
K1 K2 K3	RELAY, REED, FORM A RELAY, REED, FORM A	357566 357566	71707 71707	UF 40069 UF 40069 UF 40069	REF REF		
MP 1 MP 2	SCREW, PH, SHIELD, 4-40 X 14 SHIELD	129890 406280	73734 89536	19022 406280	1		
Q 1 R 1	XSTR, SI, PNP RES, MF, 1M +/-0.1%, 1W	195974 340265	04713 03888	2N3906 PME75	1 1	1	

Table 609-3, True BMS Converter PCB Assembly (cont)

		FLUKE	MFG					
ITEM No.	DESCRIPTION	STOCK	SPLY	MFG PART OR TYPE				USE
		NO.	CODE					
R2	RES. COMP. 2.7M +/-5%. 1/4W RES. VAR. 100K +/-10%. 1/2W RES. COMP. 56K +/-5%. 1/4W RES. COMP. 56K +/-5%. 1/4W RES. COMP. 2.4K +/-5%. 1/4W RES. MF. 995K +/-0.1%. 1/4W RES. VAR. 10K +/-10%. 1/2W RES. COMP. 47K +/-5%. 1/4W RES. MF. 110.6K +/-0.1%. 1/8W RES. MF. 10.6K +/-0.1%. 1/8W RES. MF. 10.05K +/-0.1%. 1/8W RES. MF. 10.05K +/-0.1%. 1/8W RES. VAR. 100 +/-10%. 1/2W RES. MF. 1.001K +/-0.1%. 1/8W RES. COMP. 33 +/-5%. 1/4W RES. COMP. 22 +/-5%. 1/4W RES. MF. 20K +/-0.1%. 1/8W RES. MF. 20K +/-0.1%. 1/8W RES. MF. 40K +/-0.1%. 1/8W RES. MF. 19.9K +/-0.1%. 1/4W RES. COMP. 2.4K +/-5%. 1/4W RES. COMP. 2.5K +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W	193490	01121	CB2755 369520 CB5635 CB2425 MFF1-49953B 285171 CB4735 MFF1-8110R6B 285155 MFF1-81001B CB3305 CB2205 MFF1-82002B MFF1-82002B MFF1-82002B MFF1-84002B MFF1-82002C CB2425 CB2425 CB2425 CB2425 CB2425 CB2425 CB2425 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB2035 CB2755 CB1525 CB1525 CB1525 CB1525 CB1525	,	5	_	
R3	RES. VAR. 100K +/-10%, 1/2W	369520	89536	369520		1	1	
R4	RES. COMP. 56K +/-5%. 1/4W	170738	01121	CB5635		1		
R5	RES, COMP, 2.4K +/-5%. 1/4W	193433	01121	CB2425		3		
R6	RES. MF, 995K +/-0.1%.1/4W	340158	91637	MFF1-49953B		1		
R7	RES. VAR. 10K +/-10%. 1/2W	285171	89536	285171		1	1	
R8	RES. COMP. 47K +/-5%. 1/4W	148163	01121	CB4735		1		
R9	RES, MF, 110.6K +/-0.1%, 1/8W	340224	91637	MFF1-8110R6B		! 2		
R10	RES, VAR, 1K +/-10%, 1/2W	285155	89536	285155	;	2	1	
R11	RES. MF. 10.05K +/-0.1%. 1/8W	340216	91637	MFF1-810R05B		i		
R12	RES, VAR, 100 +/-10%, 1/2W	285130	89536	285130		1	i	
R13	RES, MF, 1.001K +/-0.1%, 1/8W	340208	91637	MFF1-810018		1		
R14	RES, COMP, 33 +/-5%, 1/4W	175034	01121	C93305		2		
R15	RES. COMP. 22 +/-5%. 1/4W	147884	01121	CB2205		1		
R16	RES, MF, 20K +/-0.1%, 1/8W	340620	91637	MFF1-82002B		3		
R17	RES, MF, 20K +/-0.1%, 1/8W	340620	91637	MFF1-82002B	RE	=		
R18	RES, MF, 40K +/-0.1%, 1/8W	321489	91637	MFF1-84002B		1		
R13	RES, MF, 19.9K +/-0.1%, 1/8W	386334	91637	MFF1-81992B		1		
R20	RES. COMP. 100 +/-5%. 1/4W	147926	01121	CB1015		1		
R21	RES. COMP. 2.4K +/-5%. 1/4U	193433	01121	CB2425	RE	F		
R22	RES. COMP. 2.4K +/-5%. 1/4W	193433	01121	CB2425	RE	F		
R24	RES. COMP. 1.5K +Z-5%.1Z4W	148031	01121	CB1525				
R25	RES. COMP. 20K +/-5%. 1/4U	221614	01121	CB2035		3		
R26	RES. COMP. 2.7M +/-5%, 1/4W	193498	01121	CB2755	RE	=		
R27	RES. COMP. 20K ±2-5% 1/4H	221614	01121	CB2035	RE			
R28	RES. VAR. 100K +/-10%, 1/2W	288308	89536	288308			1	
R29	DEC COMP 3 7M 17 59 1741	107400	01121	CD2755	RE		-	
	RES. CUMP. 1 EV. 17 EM 1740	133430	01121	CB1525	RE			
R30	RES, LUMM, 1.3K 1/13%,1/4W	140031	01121	CB152 5	RE			
R31	RES, CUMP, 1.3K T/T3%,1/4W	140031	01121	-	RE			
R32	RES, LUMP, 20K T/TJ%, 1/4W	221014	01121			-		
R33	RES. CUMP. Z.M. TZTJA. 174W	749608	01771	CB2755	DE	-		
R34	RES, MF, 20K +/-6.1%, 1/8W	340620	21031	200700	RE RE	=		
R35	RES, VHR, 100K +/-10%, 1/2W	200300	00576	200300	RE RE	_		
R36	RES, VHR, 100K +/-10%, 1/2W	200300 220525	01121	200300 CD7575	KE.	1		
R37	RES, CUMP, 75K +7-3%, 174W	228023	01121	CD204E		1		
R38	RES, LUMP, 220K +7-3%, 174W	160937	01/21	UB2240		1		
R39	RES, MF, 71.5K +/-0.25%, 1/8W	461467	91637	7FF1-87132L	05	_		
R40	RES, VHR, 1K +/-10%, 1/2W	285155	89536	283133	RE			
R41	RES, VHR, ZUK +/-1U%, 1/ZW	291609	00576 00576	231603 200760	وسروم	1	1	
R42	RES. VAR. 100K +/-10%, 1/2W	288308	89536	∠88308 CB3345	RE	_		
R43	RES. VAR. 100K +/-10%. 1/2W RES. COMP. 2.7M +/-5%. 1/4W RES. COMP. 1.5K +/-5%.1/4W RES. COMP. 1.5K +/-5%.1/4W RES. COMP. 20K +/-5%. 1/4W RES. COMP. 20K +/-5%. 1/4W RES. COMP. 2.7M +/-5%. 1/4W RES. WAR. 100K +/-10%. 1/2W RES. VAR. 100K +/-10%. 1/2W RES. VAR. 100K +/-10%. 1/2W RES. COMP. 75K +/-5%. 1/4W RES. COMP. 75K +/-5%. 1/4W RES. VAR. 1K +/-10%. 1/2W RES. VAR. 1K +/-10%. 1/2W RES. VAR. 20K +/-10%. 1/2W RES. VAR. 100K +/-10%. 1/2W RES. VAR. 100K +/-10%. 1/2W RES. VAR. 100K +/-5%. 1/4W RES. COMP. 220K +/-5%. 1/4W RES. COMP. 43K +/-5%. 1/4W RES. COMP. 43K +/-5%. 1/4W RES. COMP. 43K +/-5%. 1/4W RES. COMP. 43K +/-5%. 1/4W RES. COMP. 43K +/-5%. 1/4W	160937	01121	CB2755 MFF1-82002B 288308 288308 CB7535 CB2245 MFF1-87152C 285155 291609 288308 CB2245 CB4335 CB1035 CB4335 CB4335	RE	<u>-</u>		
R44	RES, COMP, 43K +/-5%, 1/4W	193367	01121	L84335		2		
R45	RES, COMP, 10K +/-5%, 1/4W	148106	01121	CB1035		2		
R46	RES, COMP, 43K +/-5%, 1/4W	193367	01121	UB4335	RE	-		
R47	RES, CUMP, 2.7M +7-3%, 1/4W	122426	01121	CB2755	RE	-		
P.48	RES, COMP, 10K +/-5%, 1/4W	148106	01121	CB1822	K C	_		
R50	RES. COMP. 33 +/-5%. 1/4W	175034	01121	CB3305	RE			
R51	RES, COMP, 2.7 +/-5%, 1/4W	246744	01121	CB27G5		1		
R52	RES, COMP, 1.3 +/-5%, 1/4W	442012	01121	CB13G5		1	_	
U 1	IC, OP AMP, FET INPUT	453357		CA3140T		i	1	
U2	IC, OP AMP	472928		TL080CL		1	1	
U3	XSTR ARRAY, NPN	445123		445213		1	1	
U4	IC. OP AMP	418913		LM4250CN		2	1	
U5	IC, DUAL OF AMP	418566	12040			1	1	
	TO OR OME	410017	120/0	LM4250CN	RE			
U6	IC, OP AMP	418913	12040	LH 9 2386N	NC.	Г		




Table 609-3. True RMS Converter PCB Assembly (cont)

r i

Section 7 General Information

7-1. This section of the manual contains generalized user information as well as supplemental information to the List of Replaceable Parts contained in Section 5.

List of Abbreviations and Symbols

A or amp	ampere	hf	high frequency	(+) or pos	positive
ac	alternating current	Hz	hertz	pot	potentiometer
af	audio frequency	IC	integrated circuit	р-р	peak-to-peak
a/d	analog-to-digital	if	intermediate frequency	ppm	parts per million
assy	assembly	in	inch(es)	PROM	programmabile read-only
AWG	american wire gauge	intl	internal		memory
B	bel	I/O	input/output	psi	pound-force per square inch
bcd	binary coded decimal	k	kilo (10³)	RAM	random-access memory
°C	Celsius	kHz	kilohertz	rl	radio frequency
сар	capacitor	kΩ	kilohm(s)	rms	root mean square
ccw	counterclockwise	kV	kilovolt(s)	ROM	read-only memory
cer	ceramic	Ħ	low frequency	s or sec	second (time)
cermet	ceramic to metal(seal)	LED	light-emitting diode	scope	oscilloscope
ckt	circuit	LSB	least significant bit	SH	shield
cm	centimeter	LSD	least significant digit	Si	silicon
cmrr	common mode rejection ratio	М	mega (10 ⁶)	serno	serial number
comp	composition	m	milli (10 ⁻³)	sr	shift register
cont	continue	mA	milliampere(s)	Та	tantalum
crt	cathode-ray tube	max	maximum	tb	terminal board
CW	clockwise	mf	metal film	tc	temperature coefficient or
d/a	digital-to-analog	MHz	megahertz		temperature compensating
dac	digital-to-analog converter	min	minimum	texo	temperature compensated
dB	decibel	mm	millimeter		crystal oscillator
dc	direct current	ms	millisecond	tp	test point
dmm	digital multimeter	MSB	most significant bit	u or μ	micro (10 ⁻⁶)
dvm	digital voltmeter	MSD	most significant digit	uhf	ultra high frequency
elect	electrolytic	MTBF	mean time between failures	us or μ s	microsecond(s) (10 ⁻⁶)
ext	external	MTTR	mean time to repair	out	unit under test
F	farad	mV	millivolt(s)	٧	volt
°F	Fahrenheit	my	multivibrator	v	voltage
FET	Field-effect transistor	MΩ	megohm(s)	var	variable
ff	flip-flop	n	nano (10-°)	vco	voltage controlled oscillator
freq	frequency	na	not applicable	vhf	very high frequency
FSN	federal stock number	NC	normally closed	vif	very low frequency
9	gram	(-) or neg	negative	W	watt(s)
G	giga (10°)	NO	normally open	ww	wire wound
gd	guard	ns	nanosecond	xfmr	transformer
Ge	germanium	opni ampi	operational amplifier	xstr	transistor
GHz	gigahertz	р	pico (10 ⁻¹²)	xtal	crystal
gmv	guaranteed minimum value	para	paragraph	xtlo	crystal oscillator
gnd	ground	pcb	printed circuit board	Ω	ohm(s)
H	henry	pF	picofarad	μ	micro (10 ⁻⁶)
hd	heavy duty	pn	part number		

00213

Nytronics Comp. Group Inc. Subsidiary of Nytronics Inc. Formerly Sage Électronics Rochester, New York

Welwyn International, Inc. Westlake, Ohio

Aerovox Corp.

New Bedford, Massachusetts

Film Capacitors, Inc. Passaic, New Jersey

AMP Inc.

Harrisburg, Pennsylvania

Allen-Bradley Co. Milwaukee, Wisconsin

TRW Electronic Comp. Semiconductor Operations Lawndale, California

01295

Texas Instruments, Inc. Semiconductor Group

Dallas, Texas

01537 Motorola Communications & Electronics Inc. Franklin Park, Illinois

01686

RCL Electronics Inc. Manchester, New Hampshire

01730

Replaced by 73586

01884 Use 56289

Sprague Electric Co. Dearborn Electronic Div. Lockwood, Florida

02114

Ferroxcube Corp. Saugerties, New York

General Instrument Corp. Harris ASW Div Westwood, Maine

02395

Rason Mfg. Co. Brooklyn, New York

02533

Snelgrove, C.R. Co., Ltd. Don Mills, Ontario, Canada M3B 1M2

Fenwal Labs Div. of Travenal Labs. Morton Grove, Illinois 02660

Bunker Ramo Corp., Conn Div. Formerly Amphenol-Borg Electric Corp.

Broadview, Illinois

Areo Capacitors, Inc. Chatsworth, California

General Electric Co. Semiconductor Products Syracuse, New York

03614

Replaced by 71400

03651

Replaced by 44655

03797

Eldema Div. Genisco Technology Corp. Compton, California

Transistron Electronic Corp. Wakefield, Massachusetts

03888

KDI Pyrofilm Corp. Whippany, New Jersey

Clairex Electronics Div. Clairex Corp. Mt. Vernon, New York

03980

Muirhead Inc.

Mountainside, New Jersey

04009

Arrow Hart Inc. Hartford, Connecticut

04062

Replaced by 72136

04202

Replaced by 81312

Essex International Inc. Wire & Cable Div. Anaheim, California

Aemco, Div. of Midtex Inc. Mankato, Minnesota

04222

AVX Ceramics Div. AVX Corp. Myrtle Beach, Florida

04423

Telonic Industries Laguna Beach, California

04645

Replaced by 75376

04713

Motorola Inc. Semiconductor

Products Phoenix. Arizona 04946

Standard Wire & Cable Los Angeles, California

05082

Replaced by 94988

05236

Jonathan Mfg. Co. Fullerton, California

05245

Components Corp. now Corcom, Inc. Chicago, Illinois

Westinghouse Electric Corp. Semiconductor Div. Youngwood, Pennsylvania

05278

Replaced by 43543

05279 Southwest Machine &

Plastic Co. Glendora, California

05397

Union Carbide Corp. Materials Systems Div. New York, New York

05571

Use 56289 Sprague Electric Co.

Pacific Div. Los Angeles, California

05574

Viking Industries Chatsworth, California

05704

Replaced by 16258

05820

Wakefield Engineering Inc. Wakefield, Massachusetts

06001

General Electric Co. Electronic Capacitor & Battery Products Dept. Columbia, South Carolina

06136

Replaced by 63743

06383

Panduit Corp. Tinley Park, Illinois

Bunker Ramo Corp. Amphenol SAMS Div. Chatsworth, California

Beede Electrical Instrument Co. Penacook, New Hampshire

06739

Electron Corp. Littleton, Colorado

06743 Clevite Corp. Cleveland, Ohio

Components, Inc. Semcor Div. Phoenix, Arizona

06860

Gould Automotive Div. City of Industry, California

Vernitron Corp., Piezo Electric Div. Formerly Clevite Corp., Piezo Electric Div.

06980

Eimac Div. Varian Associates San Carlos, California

Bedford, Ohio

07047

The Ross Milton Co. South Hampton, Pennsylvania

07115

Replaced by 14674

07138

Westinghouse Electric Corp., Electronic Tube Div. Horsehead, New York

TRW Electronic Components Cinch Graphic City of Industry, California

Silicon Transistor Corp. Div. of BBF Group Inc. Chelmsford, Massachusetts

Aumet Corp. Culver City, California

07263

Fairchild Semiconductor Div. of Fairchild Camera & Instrument Corp. Mountain View, California

07344

Bircher Co., Inc. Rochester, New York

07597 Burndy Corp. Tape/Cable Div. Rochester, New York

Lerma Engineering Corp. Northampton, Massachusetts

07910

Teledyne Semiconductor Formerly Continental Device Hawthorne, California

07933 Use 49956 Raytheon Co.

Semiconductor Div. HQ Mountain View, California

08225

Industro Transistor Corp. Long Island City, New York

Spectra Strip Corp. Garden Grove, California

Reliance Mica Corp. Brooklyn, New York

General Electric Co. Miniature Lamp Products Dept Cleveland, Ohio

Nylomatic Corp. Norrisville, Pennsylvania

Use 53085 Skottie Electronics Inc. Archbald, Pennsylvania

G.E. Co. Semi-Conductor Products Dept. Power Semi-Conductor Products OPN Sec. Auburn, New York

C and K Components Watertown, Massachusetts

Scientific Components, Inc. Santa Barbara, California

09922 Burndy Corp. Norwalk, Connecticut

Dale Electronics Inc. Yankton, S. Dakota

10059 Barker Engineering Corp.
Formerly Amerace, Amerace

ESNA Corn Kenilworth, New Jersey

11236 CTS of Berne Berne, Indiana

CTS Keene Inc. Paso Robles, California

CBS Electronic Div. Columbia Broadcasting System Newburyport, Minnesota

11403 Best Products Co. Chicago, Illinois

Keystone Columbia Inc. Warren, Michigan

11532 Teledyne Relays Hawthorne, California

General instrument Corp. Rectifier Division Hicksville, New York

11726 Qualidyne Corp. Santa Clara, California

Chicago Rivet & Machine Co. Bellwood, Illinois

National Semiconductor Corp. Danburry, Connecticut

12060 Diodes, Inc. Chatsworth, California

Philadelphia Handle Co. Camden, New Jersey

Potter-Brumfield Div. AMF Canada LTD. Guelph, Ontario, Canada

12323 Presin Co., Inc. Shelton, Connecticut

12327 Freeway Corp. formerly Freeway Washer & Stamping Co. Cleveland, Ohio

The Budd Co. Polychem Products Plastic Products Div. Bridgeport, Pennsylvania

U.S. Terminals Inc. Cincinnati, Ohio

Hamlin Inc. Lake Mills, Wisconsin

Clarostat Mfg. Co. Dover, New Hampshire

James Electronics Chicago, Illinois

12856 Micrometals Sierra Madre, California

Dickson Electronics Corp. Scottsdale, Arizona

Unitrode Corp. Watertown, Massachusetts

Thermalloy Co., Inc. Dallas, Texas

Solitron Devices Inc. Tappan, New York

Amphenol Cadre Div. Bunker-Ramo Corp. Los Gatos, California

13606 Use 56289 Sprague Electric Co. Transistor Div. Concord, New Hampshire

Replaced by 23732

Semtech Corp. Newbury Park, California

Edison Electronic Div. Mc Gray-Edison Co. Manchester, New Hampshire

Cal-R-Inc. formerly California Resistor, Corp. Santa Monica, California

American Components, Inc. an insilco Co. Conshohocken, Pennsylvania

Cornell-Dublier Electronics Division of Federal Pacific Electric Co. Govt. Control Dept. Newark, New Jersey

Electro Cube Inc. San Gabriel, California

14869 Replaced by 96853

14936 General Instrument Corp. Semi Conductor Products Group Hicksville, New York

15636 Elec-Trol Inc. Saugus, California

Fenwal Electronics Inc. Div. of Kidde Walter and Co., Inc. Framingham, Massachusetts

Teledyne Semiconductors, formerly Amelco Semiconductor Mountain View, California

Litton Systems Inc. Useco Div. formerly Useco Inc. Van Nuys, California

15898 International Business Machines Corp. Essex Junction, Vermont

15909 Replaced by 14140

Space-Lok Inc. Burbank, California

16299 Corning Glass Electronic Components Div. Raleigh, North Carolina

Ī

16332 Replaced by 28478

16473 Cambridge Scientific Ind. Div. of Chemed Corporation Cambridge, Maryland

16742 Paramount Plastics Fabricators, Inc. Downey, California

Delco Electronics Div. of General Motors Corp. Kokomo, Indiana

17001 Replaced by 71468

Circuit Structures Lab. Burbank, California

High Pressure Eng. Co., Inc. Oklahoma City, Oklahoma

Atlantic Semiconductors, Inc. Asbury Park, New Jersey

17856 Siliconix, Inc. Santa Clara, California

Replaced by 14140

18178 Vacted Inc. Maryland Heights, Missouri

Signetics Corp. Sunnyvale California

Vishay Resistor Products Div. Vishay Intertechnology Inc. Malvern, Pennsylvania

Voltronics Corp. Hanover, New Jersey

GTE Sylvania Inc. Precision Material Group Parts Division Titusville, Pennsylvania

Perine Machinery & Supply Co. Seattle, Washington

19701 Electro-Midland Corp. Mepco-Electra Inc. Mineral Wells, Texas

20584 Enochs Mfg. Inc. indianapolis, Indiana

Self-Organizing Systems, Inc.

Dallas, Texas

Bucheye Stamping Co. Columbus, Ohio

Solitron Devices Inc. Transistor Division Riveria Beach, Florida

ITT Semiconductors Palo Alto, California

Product Comp. Corp. Mount Vernon, New York

Tracor Inc.

Rockville, Maryland

Stanford Applied Engrng. Santa Clara, California

Pamotor Div., Wm. J. Purdy Co. Burlingame, California

Replaced by 94222

Analog Devices Inc. Norwood, Massachusetts

24655

General Radio Concord, Massachusetts

Lenox-Fugle Electronics Inc. South Plainfield, New Jersey

25088

Siemen Corp. Isilen, New Jersey

25403

Amperex Electronic Corp. Semiconductor & Micro-Circuits Div. Statersville, Rhode Island

National Semiconductor Corp. Santa Clara, California

Molex Products Downers Grove, Illinois

Minnesota Mining & Mfg. Co. Consumer Products Div. St. Paul, Minnesota

Serv-/-Link formerly Bohannan Industries Fort Worth, Texas

Deltrol Controls Div. **Deltrol Corporation** Milwaukee, Wisconsin 28480

Hewlett Packard Co. Corporate HQ Palo Alto, California

Heyman Mfg. Co. Kenilworth, New Jersey

Monsanto, Co., Inc. Santa Clara, California

Stackpole Components Co. Raleigh, North Carolina

AB Enterprise Inc. Ahoskie, North Carolina

Illinois Tool Works, Inc. Chicago, Illinois

Optimax Inc. Colmar, Pennsylvania

Mura Corp. Great Neck, New York

Griffith Plastic Corp. Burlingame, California

32879

Advanced Mechanical Components Northridge, California

32897

Erie Technological Products, Inc. Frequency Control Div. Carlisle, Pennsylvania

32997 Bourns Inc. Trimpot Products Division Riverside, California

33173

General Electric Co. Products Dept. Owensboro, Kentucky

Silicon General Westminister, California

Advanced Micro Devices Sunnyvale, California

Electromotive Inc. Kenilworth, New Jersey

P.R. Mallory & Co., Inc. Indianapolis, Indiana

National Radio Melrose, Massachusetts 43543 Nytronics Inc. Transformer Co. Div. Geneva, New York

44655 Ohmite Mfg. Co. Skokie, Illinois

49671 RCA Corp.

New York, New York

Raytheon Company Lexington, Massachusetts

Mostek Corp. Carrollton, Texas

Litronix Inc. Cupertino, California

Scientific Components Inc. Linden, New Jersey

Sangamo Electric Co. Springfield, Illinois

Cutler-Hammer Inc. formerly Shallcross, A Cutter-Hammer Co. Selma, North Carolina

55026

Simpson Electric Co. Div. of Am. Gage and Mach. Co. Elgin, Illinois

56289

Sprague Electric Co. North Adams, Massachusetts

Superior Electric Co. Bristol, Connecticut

60399

Torin Corp. formerly Torrington Mfg. Co. Torrington, Connecticut

Ward Leonard Electric Co., Inc. Mount Vernon, New York

West Mfg. Co. San Francisco, California

65092

Weston Instruments Inc. Newark, New Jersey

Winslow Tele-Tronics Inc. Eaton Town, New Jersey

70485

Atlantic India Rubber Works Chicago, Illinois

70563

Amperite Company Union City, New Jersey 70903 Belden Corp. Geneva, Illinois

Birnback Radio Co., Inc. Freeport, New York

71400

Bussmann Mfg.

Div. of McGraw-Edison Co. Saint Louis, Missouri

CTS Corp. Elkhart, Indiana

71468

ITT Cannon Electric Inc. Santa Ana, California

Clare, C.P. & Co. Chicago, Illinois

71590

Centrelab Electronics Div. of Globe Union Inc. Milwaukee, Wisconsin

71707

Coto Cail Co., Inc. Providence, Rhode Island

Chicago Miniature Lamp Works Chicago, Illinois

71785

TRW Electronics Components Cinch Connector Operations Div. Elk Grove Village Chicago, Illinois

72005

Wilber B. Driver Co. Newark, New Jersey

72092

Replaced by 06980

72136

Electro Motive Mfg. Co. Williamantic, Connecticut

Nytronics Inc. Pelham Manor, New Jersey

72619

Dialight Div. Amperex Electronic Corp. Brooklyn, New York

72653

G.C. Electronics Div. of Hydrometals, Inc. Brooklyn, New York

72665

Replaced by 90303

72794 Dzus Fastener Co., Inc.

West Islip, New York 72928

Gulton Ind. Inc. Gudeman Div. Chicago, Illinois

72982

Erie Tech. Products Inc. Erie, Pennsylvania

Bechman Instrument Inc. Helipot Division Fullerton, California

73293

Hughes Aircraft Co. Electron Dynamics Div. Torrance, California

Amperex Electronic Corp. Hicksville, New York

Carling Electric Inc. West Hartford, Connecticut

Circle F Industries Trenton, New Jersey

Federal Screw Products, Inc. Chicago, Illinois

Fischer Special Mfg. Co. Cincinnati, Ohio

JFD Electronics Co. Components Corp. Brooklyn, New York

Guardian Electric Mfg. Co. Chicago, Illinois

Quan Nichols Co. Chicago, Illinois

Radio Switch Corp. Mariboro, New Jersey

74276

Signalite Div. General Instrument Corp. Neptune, New Jersey

74306

Piezo Crystal Co. Carlisle, Pennsylvania

Hoyt Elect. Instr. Works Penacook, New Hampshire

74970

Johnson E.F., Co. Waseca, Minnesota

TRW Electronics Components **IRC Fixed Resistors** Philadelphia, Pennsylvania

Kurz-Kasch Inc. Dayton, Ohio

CTS Knights Inc. Sandwich, Illinois

Kulka Electric Corp. Mount Vernon, New York

75915

Littlefuse Inc. Des Plaines, Illinois

Oak Industries Inc. Switch Div. Crystal Lake, Illinois

AMF Inc.

Potter & Brumfield Div. Princeton, Indiana

General Instrument Corp. Rectifier Division Brooklyn, New York

Rubbercraft Corp. of CA. LTD. Torrance, California

Shakeproof

Div. of Illinois Tool Works Inc. Elgin, Illinois

Sigma Instruments, Inc. South Braintree, Massachusetts

Stackpole Carbon Co. Saint Marys, Pennsylvania

Eaton Corp. Engineered Fastener Div. Tinnerman Plant Cleveland, Ohio

Waldes Kohinoor Inc. Long Island City, New York

Western Rubber Company Goshen, Indiana

Zierick Mfg. Corp. Mt. Kisko, New York

Electro-Midland Corp. Mepco Div.

A North American Phillips Co. Norristown, New Jersey

LFE Corp., Process Control Div. formerly API Instrument Co.

Chesterland, Ohio

Use 56289

Sprague Products North Adams, Massachusetts

Bourns Inc., Instrument Div. Riverside, California

80583

Hammarlund Mfg. Co., Inc. Red Bank, New Jersey

80640

Arnold Stevens, Inc. South Boston, Massachusetts

81073

Grayhill, Inc. La Grange, Illinois

81312

Winchester Electronics Div. of Litton Industries Inc. Oakville, Connecticut

81483

Therm-O-Disc Inc. Mansfield, Ohio

International Rectifier Corp. Los Angeles, California

81590

Korry Mfg. Co. Seattle, Washington

Chicago Lock Co. Chicago, Illinois

Palmer Electronics Corp. South Gate, California

Switchcraft Inc. Chicago, Illinois

82415 North American Phillips Controls Corp. Frederick, Maryland

82872

Roanwell Corp. New York, New York

Rotron Inc.

Woodstock, New York

ITT Royal Electric Div.

Pawtucket, Rhode Island

83003

Varo Inc. Garland, Texas

The Carr Co., United Can Div.

Cambridge, Massachusetts

83298 Bendix Corp. Electric Power Div. Eatontown, New Jersey

83330

Herman H. Smith, Inc. Brooklyn, New York

Rubbercraft Corp. of America, Inc. West Haven, Connecticut 83594

Burroughs Corp. Electronic Components Div. Plainfield, New Jersey

Union Carbide Corp. Battery Products Div. formerly Consumer Products Div. New York, New York

Ī

84171

Arco Electronics Great Neck, New York

TRW Electronic Components TRW Capacitors Ogallala, Nebraska

84613

Fuse Indicator Corp. Rockville, Maryland

84682

Essex International Inc. Industrial Wire Div. Peabody, Massachusetts

Precision Metal Products of Maiden Inc. Stoneham, Massachusetts

Radio Corp. of America Electronic Components Div. Harrison, New Jersey

86928 Seastrom Mfg. Co., Inc. Glendale, California

87034 Illuminated Products Inc. Subsidiary of Oak Industries Inc.

Anahiem, California

88219 Gould Inc. Industrial Div Trenton, New Jersey

Litton Systems Inc. Useco Div. Van Nuys, California

Cornell-Dubilier Electronic Div. Federal Pacific Co. Fuquay-Varian, North Carolina

Plastic Wire & Cable Jewitt City, Connecticut

88690

John Fluke Mfg. Co., Inc.

Replaced by 04217

Seattle, Washington

G.E. Co., Newark Lamp Works Newark, New Jersey

90201

Mallory Capacitor Co. Div. of P.R. Mallory Co., Inc. Indianapolis, Indiana

90211 Use 56365 Square D Co. Chicago, Illinois

90215 Best Stamp & Mfg. Co. Kansas City, Missouri

90303 Mallory Battery Co. Div. of Mallory Co., Inc. Tarrytown, New York

91094
Essex International Inc.
Suglex/IWP Div.
Newmarket, New Hampshire

91293 Johanson Mfg. Co. Boonton, New Jersey

91407 Replaced by 58474

91502 Associated Machine Santa Clara, California

91506 Augat Inc. Attleboro, Massachusetts

91637 Dale Electronics Inc. Columbus, Nebraska

91662 Elco Corp. Willow Grove, Pennsylvania

91737 Use 71468 Gremar Mfg. Co., Inc. ITT Cannon/Gremar Santa Ana, California

91802 Industrial Devices, Inc. Edgewater, New Jersey

Keystone Electronics Corp. New York, New York 91836 King's Electronics Co., Inc. Tuckahoe, New York

91929 Honeywell Inc. Micro Switch Div. Freeport, Illinois

91934 Miller Electric Co., Inc. Div. of Aunet Woonsocket, Rhode Island

92194 Alpha Wire Corp. Elizabeth, New Jersey

93332 Sylvania Electric Products Semiconductor Products Div. Woburn, Massachusetts

94145 Replaced by 49956

94154 Use 94988 Wagner Electric Corp. Tung-Sol Div. Newark, New Jersey

94222 Southco Inc. formerly South Chester Corp. Lester, Pennsylvania

95146 Alco Electronic Products Inc. Lawrence, Massachusetts

95263 Leecraft Mfg. Co. Long Island City, New York

95264 Replaced by 98278

95275 Vitramon Inc. Bridgeport, Connecticut

95303 RCA Corp. Receiving Tube Div. Cincinnati, Ohio

95348 Gordo's Corp. Bloomfield, New Jersey 95354 Methode Mfg. Corp. Rolling Meadows, Illinois

95712
Bendix Corp.
Electrical Components Div.
Microwave Devices Plant
Franklin, Indiana

95987 Weckesser Co. Inc. Chicago, Illinois

96733 San Fernando Electric Mfg. Co. San Fernando, California

96853 Gulton Industries Inc. Measurement and Controls Div. formerly Rustrak Instruments Co. Manchester, New Hampshire

96881 Thomson Industries, Inc. Manhasset, New York

97540 Master Mobile Mounts, Div. of Whitehall Electronics Corp. Ft. Meyers, Florida

97913 Industrial Electronic Hardware Corp. New York, New York

97945 Penwalt Corp. SS White Industrial Products Div. Piscataway, New Jersey

97966 Replaced by 11358

98094 Replaced by 49956

98159 Rubber-Teck, Inc. Gardena, California

98278
Malco A Microdot Co., Inc.
Connector & Cable Div.
Pasadena, California

98291 Sealectro Corp. Mamaroneck, New York

98388 Royal Industries Products Div. San Diego, California

98743 Replaced by 12749

98925 Replaced by 14433

99120 Plastic Capacitors, Inc. Chicago, Illinois

99217
Bell Industries Elect.
Comp. Div.
formerly Southern Elect. Div.
Burbank, California

99392 STM Oakland, California

99515 PTT Jennings Monrovia Plant Div. of ITT Jennings formerty

Marshall Industries Capacitor Div.

Monrovia, California 99779 Use 29587 Bunker-Ramo Corp. Barnes Div.

Landsdowne, Pennsylvania

99800 American Precision Industries Inc. Delevan Division East Aurora, New York

99942 Centrelab Semiconductor Centrelab Electronics Div. of Globe-Union Inc. El Monte, California

Toyo Electronics (R-Ohm Corp.) Irvine, California

National Connector Minneapolis, Minnesota

U.S. SALES AREAS for all Fluke products

AK, Anchorage

Harry Lang & Associates 1371 Hillcrest Drive #303 Anchorage, AK 99503 (907) 279-5741

AL. Huntsville

John Fluke Mfg. Co., Inc. 3322 S. Memorial Parkway Suite 96 Huntsville, AL 35801 (205) 881-6220

AZ, Tempe

John Fluke Mfg. Co., Inc. 2125 S. 48th Street Suite 104 Tempe, AZ 85282 (602) 967-8724 **Tucson** (602) 790-9881

CA, Los Angeles

John Fluke Mfg. Co., Inc. 20902 South Bonita St. Carson, CA 90746 (213) 538-3900 or (714) 761-2449

Santa Clara

John Fluke Mfg. Co., Inc. 2300 Waish Ave., Bldg. K Santa Clara, CA 95051 (408) 727-0513

San Diego

John Fluke Mfg. Co., Inc. 9601 Aero Drive, Suite 290 San Diego, CA 92123 (714) 226-1254

Tustin

John Fluke Mfg. Co., Inc. 15445 Red Hill Ave., Suite F Tustin, CA 92680 (714) 838-8863

CO. Denver

John Fluke Mfg. Co., Inc. 1980 South Quebec St. #4 Denver, CO 80231 (303) 750-1222

CT, Hartford

John Fluke Mfg. Co., Inc. 124 Hebron Ave. Glastonbury, CT 06033 (203) 633-0777

FL. Orlando

John Fluke Mfg. Co..inc. 940 N. Fern Creek Ave. Orlando, FL 32803 (305) 896-4881

GA, Atlanta

2700 Delk Rd., Suite 250 Marietta, GA 30067 (404) 953-4747

HI, Honolulu

EMC Corporation 2979 Ualena St. Honolulu, HI 96819 (808) 836-1138

IA, Iowa City

(319) 354-2811

IL, Chicago

John Fluke Mfg. Co., Inc. 3740 Industrial Ave. Rolling Meadows, IL 60008 (312) 398-0850

IN, Indianapolis

John Fluke Mfg. Co., Inc. 5610 Crawfordsville Rd. Suite 802 Indianapolis, IN 46224 (317) 244-2456

KS, Kansas City

John Fluke Mfg. Co., Inc. 4550 W. 109th St., Suite 130 Shawnee Mission, KA 66211 (913) 381-9800

LA, New Orleans

(504) 455-0814

MA, Burlington

John Fluke Mfg. Co., Inc. 25 "B" Street Burlington MA 01803 (617) 273-4674

MD, Baltimore

(301) 792-7060

Rockville

John Fluke Mfg. Co., Inc. 5640 Fishers Lane Rockville, MD 20852 (301) 770-1570

MI. Detroit

John Fluke Mfg. Co., Inc. 13955 Farmington Rd. Livonia, MI 48154 (313) 522-9140

MN, Minneapolis

John Fluke Mfg. Co., Inc. 7373 W. 147th St., Suite 196 Apple Valley, MN 55124 (612) 432-9400

MO, St. Louis

John Fluke Mfg. Co., Inc. 300 Brookes Dr., Suite 100 Hazelwood, MO 63042 (314) 731-3388

NC, Greensboro

John Fluke Mfg. Co., Inc. 1310 Beaman Place Greensboro, NC 27408 (919) 273-1918

NJ, Paramus

John Fluke Mfg. Co., Inc. P.O. Box 930 West 75 Century Road Paramus, NJ 07652 (201) 262-9550

NM, Albuquerque

John Fluke Mfg. Co., Inc. 1108 Alvarado Drive N.E. Albuquerque, NM 87110 (505) 265-8431

NY, Rochester

John Fluke Mfg. Co., Inc. 4515 Culver Road Rochester, NY 14622 (716) 266-1400

OH, Cleveland

John Fluke Mfg. Co., Inc. 7830 Freeway Circle Middleburg Heights, OH 44130 (216) 234-4540

Columbus

(614) 889-5715

Dayton

John Fluke Mfg. Co., Inc. 4756 Fishburg Rd. Dayton, OH 45424 (513) 233-2238

OR, Portland

John Fluke Mfg. Co., Inc. 18360 S.W. Springfield Lane Aloha, OR 97007 (503) 642-1342

PA, Philadelphia

John Fluke Mfg. Co., Inc. 1010 West 8th Ave., Suite H King of Prussia, PA 19406 (215) 265-4040

Pittsburgh

(412) 261-5171

TX, Austin

John Fluke Mfg. Co., Inc. Creek Gardens, Suite 103 8705 Shoaf Creek Blvd. Austin, TX 78758 (512) 459-3344

Dallas

John Fluke Mfg. Co., inc. 14400 Midway Road Dallas, TX 75234 (214) 233-9990

Houston

John Fluke Mfg. Co., Inc. 4240 Blue Bonnet Dr. Stafford, TX 77477 (713) 491-5995

San Antonio

10417 Gulfdale San Antonio, TX 78216 (512) 340-2621

UT, Salt Lake City

John Fluke Mfg. Co., Inc. 5226 So. 300 West, Suite #2 Salt Lake City, UT 84107 (801) 268-9331

WA, Seattle

John Fluke Mfg. Co., Inc. 975 Industry Drive Seattle, WA 98188 (206) 575-3765

Service Center Areas

CA, Burbank (213) 849-4641 CA, Santa Clara (408) 727-8121 CO, Denver (303) 750-1228 FL, Orlando (305) 896-2296 IL, Chicago (312) 398-5800 MA, Burlington (617) 273-4678 MD, Rockville (301) 770-1576 NJ, Paramus (201) 262-9550 TX, Dallas (214) 233-9945 WA, Everett (206) 356-5560

The following low-cost instruments . . .

are stocked locally and sold by the Authorized Distributors listed on the back of this folder, as well as by the sales offices shown.

Handheld DMM's: 8020A, 8021B, 8022B, 8024B, 8060A, 8062A Portable DMM's: 8000A, 8010A, 8012A, 8030A, 8040A, 8050A Digital Counters: 1900A, 1910A, 1911A, 1912A Digital Thermometers: 2160 - and 2170 - Series

All other instruments are sold by the sales offices only.

For more information on Fluke products or Sales Offices you may dial (800) 426-0361 toll-free in most of U.S. From Alaska, Hawaii, or Washington, phone (206) 356-5400. From Canada and other countries phone (206) 356-5500.



INTERNATIONAL SALES OFFICES

Argentina •

Coasin, S.A. Virrey del Pino 4071 Buenos Aires, Argentina Tel: 552-5248, TLX: 122284

Australia •

Elmeasco Instruments Pty Ltd. P.O. Box 30, Concord, N.S.W. Australia 2137 Tel: (2) 736-2888, TLX: 25887 Elmeasco Instruments Pty Ltd. 21-23 Anthony Drive Mt. Waverly, VIC. 3149 Australia

Tel: 233-4044, TLX: 36206 Elmeasco Instruments Pty Ltd Professional Suites Bldg. G.P.O. Box 2360 Brisbane, 4001, Australia Tel: (07) 229-3161

Eimeasco Instruments Pty Ltd. G.P.O. Box 1240, Adelaide South Australia 5001 Tel: (08) 271-1839

Elmeasco Instruments Pty. Ltd. P.O.Box 95, Gosnells West Australia 6110 Tel: (09) 398-3362

Austria ■

Walter Rekirsch Elektronische Gerate GmbH & Co. Liechtensteinstrasse 97/6 Vienna, Austria Tel: (0222) 235555, TLX: 134759

Bangladesh •

Motherland Corporation 24 Hatkhola Rd., Tikatuli Dacca 3, Bangladesh Tel: 257249

Belglum ■

Fluke (Belgium) S.A./N.V. 6, Rue de Geneve 1140 Brussels, Belgium Tei: (2) 2164090, TLX: 26312

Bolivia •

Coasin Bolivia S.R.L. Casilla 7295, La Paz, Bolivia Tel: 40962, TLX: 5255

Brazil •

Fluke Brasil-Industria E Commercio LTDA Al. Amazonas 422. Aiphaville, Barueri, CEP 06400 Sao Paulo, Brazil Tel: (011) 421-3603, TLX: 01135589

Fluke Brasil-Industria E Commercio LTDA Av. Henrique Valadares, 23/401 Rio de Janeiro, Brazil Tei: 252-1297

Brunei •

Rank O'Connor's (PTE) Limited No. 8, BK.D Surfri Snop House Complex Mile 1, Jalong Tutong Bandar Seri Begawan, Brunei Tel: 26680

Bulgaria ■

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Canada •

Allan Crawford Assoc., Ltd. #14 1935 30th Ave. N.E. Calgary, Alberta T2E 625 Tel: (403) 230-1341, TLX: 03-821186 Allan Crawford Assoc., Ltd. P.O. Bag 3967 Postal Station "D" Edmonton, Alberta T5L 4K1 Tel: (403) 451-4893 Allan Crawford Assoc., Ltd.

Burnaby, British Columbia V5C 3H3 Tel: (604) 294-1326, TLX: 04-54247 Allan Crawford Assoc.. Ltd. 192 Joseph Zatzman Dr. Suite 4 Burnside Industrial Park Dartmouth, Nova Scotia B3B 1N4 Tel: (902) 463-8640, TLX: 01931604

3795 William Street

Allan Crawford Assoc., Ltd. 881 Lady Ellen Place Ottawa, Ontario K1Z 5L3 Tel: (613) 722-7682, TLX: 0533600 Allan Crawford Assoc., Ltd.

6503 Northam Drive Mississauga, Ontario L4V 1J2 Tel: (416) 678-1500, TLX: 06968769 Allan Crawford Assoc., Ltd. 7918 cote de Liesse St. Laurent, Quebec H4T 1E7

Tel: (514) 731-8564, TLX: 05824944

Chade

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Chile •

Intronica Chile Ltda.

Manuel Montt 024 - Of, D
Casilla 16228, Santiago 9, Chile
Tel: 44940, TLX: 340260 Cab. Publ.,
Attn: Intronica Chile

China, People's Republic of ●

Fluke International Corporation P.O. Box C9090 Everett, WA 98206, U.S.A. Tel: (206) 356-5511 TLX: 152662 JOHN FLUKE EVT

Colombia •

Sistemas E Instrumentacion, Ltda. Carrera 13, No. 37-43, Of. 401 Ap. Aerec 29583 Bogota DE, Colombia SA Tel: 232-45-32, TLX: 45787

Cyprus ■

Chris Radiovision Ltd. P.O. Box 1989, Nicosia, Cyprus Tel: 66121, TLX: 8262395

Czechoslovakia ■

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Denmark =

Tage Olsen A/S Ballerup Byvej 222 DK - 2750 Ballerup, Denmark Tel: (2) 658111, TLX: 35293

Ecuador •

Proteco Coasin Cia., Ltda.
Edificio "Jerico"
Ave. 12 de octubre #2285 y
Ave. Oreifana (Planta Baja)
Quito, Ecuador
Tel: 529684, TLX: 2865
Proteco Coasin Cia., Ltda.
Calderon 103 y Malecon
Casilla #9733
Guayaquil, Ecuador
Tel: 526093

Egypt and Sudan ■

Electronic Engineering Liaison Office P.O. Box 2891 Horreya Heliopolis, Cairo. Egypt Tel: 691588, TLX: 92502

England ■

Fluke (Great Britain) LTD. Colonial Way Watford, Herts, WD2 4TT United Kingdom Tel: (0923) 40511, TLX: 934583 Rapifax: (0923) 25067

Ethiopia ■

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Fiji •

AWA Fiji 47 Forster Road, Walu Bay Suva, Fiji Tel: 312079, TLX: FJ2347

Finland ■

Oy Findip AB, Teollisuustie 7 02700 Kauniainen, Finland Puh: (0) 5052255, TLX: 123129

France ■

M.B. Electronique S.A. Rue Fourny 606, Z1 Centre 78530 BUC B.P. No. 31 78530 BUC, France Tel: (3) 9568131, TLX: 695414

German Democratic Republic ■

Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Staines, Middlesex TW18 45Y
United Kingdom
Tel: (784) 63555, TLX: 928855

German Federal Republic ■

Fluke (Deutschland) GmbH Max-Hueber StraBe 8 8045 Ismaning, West Germany Tel: (089) 96050, TLX: 522472 Rapifax: (089) 9605166 Fluke (Deutschland) GmbH Meineckestrasse 53 4000 Dusseldorf 30, West Germany Tel: (0211) 450831, TLX: 8585576

Greece m

Hellenic Scientific Representations Ltd. 11, Vrasside Street Athens 612, Greece Tel: (1) 711140, TLX: 219330

Hong Kong •

Schmidt & Co. (H.K.) Ltd. 28th Fl. Wing on Centre 111 Connaught Road Central Hong Kong Tel: 5-455644 TLX: 74766 SCHMC HX

Hungary ■

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Iceland •

Kristjan O. Skagfjord Ltd. P.O. Box 906 Reykjavik, Iceland Tel: 24120, TLX: 2133

Hinditron Services Pvt. Ltd.

69/A.L. Jagmohandas Marg

Ī

India •

Bombay 400 006, India Tel: 815344, TLX: 112326 Hspl In Hinditron Services Pvt. Ltd. 8th Main Road 33/44-A Raj Mahl Vilas Extension Bangalore 560 080, India Tel: 33139, TLX: 0845741 Hinditron Services Pvt. Ltd. Shantiniketan, Office No.6 6th Floor, 8 Camac Street Calcutta 700 017, India Tel: 434032, 447541 Hinditron Services Pvt. Ltd. 204-206 Hemkunt Tower 98 Nehri Place New Delhi, 110019, India Tel: 640380

Hinditron Services Pvt. Ltd. Srinath Complex, 5th Floor 1-1-58/1 to 1-1-58/11 Sarojini Devi Road Secunderabad 500 003, India Tei: 821117, TLX: 0155 575

Indonesia •

P.T. Dwi Tunggal Jaya Sakti Sangga Buana Bidg., 1st Floor Jl. Senen Raya 44, P.O. Box 4435 Jakarta, Indonesia Tel: 367390-9, TLX: 46624

Iraq ≡

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Ireland •

Euro Electronics 32 Brews Hill Naven County Meath, Ireland Tel: (46) 23577, TLX: 3182

Israel ■

R.D.T. Electronics Engineering Ltd. P.O. Box 75 46, Sokolov Street Ramat Hasharon 47235, Israel Tel: (3) 483212, TLX: 32143

Italy ■ Sistrel S.p.A.

Milan, Italy
Tel: (2) 6181893, TLX: 334643
Sistrel S.p.A.
Via Giuseppe Armellini No. 39
00143 Rome, Italy
Tel: (6) 5915551, TLX: 68356
Sistrel S.p.A.
Via Pelizza da Vilpedo 59
80126 Naples, Italy
Tel: (81) 7679700

Via Pelizza da Volpedo 59

20092 Cinisello Balsano



Japan ●

John Fluke Mfg. Co., Inc.
Japan Branch
(PC Board Testers only)
Sumitomo Higashi
Shinbashi Bldg
1-1-11 Hamamatsucho
Minato-ku, Tokyo
Tel: (03) 434-0181, TLX: 2424331
Tokyo Electron Ltd.
38 FL Shinjuko Nomura Bldg.
1-26-2, Nishi-Shinjuku
Shinjuku-ku
Tokyo 180, Japan

Tel: 03-343-4411, TLX: 2322220 **Kenya •**ADCOM Ltd.

P.O. Box 30070 Nairobi, Kenya, East Africa Tel: 331955, TLX: 22639

Korea •

Electro-Science Korea Co. C.P.O. Box 8446 Room 201, Boondo Bldg. 56-12 Jangchung-IKa Jung-ku Seoul, Korea Tel: 261-7702, TLX: K25381

Kuwalt =

Tareq Company P.O. Box Safat 20506 Kuwait, Arabian Gulf Tel: 436100/436045, TLX: 2315

Lebanon and Jordan ■

Mabek (Electronic Division) P.O. Box 11-3823 Beirut, Lebanon Tel: 252531, TLX: 21381

Libya =

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Malaysia •

Rank O'Connor's (M) Sdn Bhd P.O. Box 91, Petaling Jaya Selangor, West Malaysia Tel: 566599 TLX: OCONOR MA37649

Rank O'Connor's (PTE) Limited Lot No. 5 Taman Mesra Mile 3, Jalan Penampang Kota Kinabulu, East Malaysia Tel: 55329, TLX: MA80286

Mexico •

Electronica y Tecnologia Pafnucio Padilla 53 Circuito Comorcial Satelite Naucalpann Edo. De Mexico Tel: 393 0902 TLX: 1773613 Nepal •

Associated Enterprises GPO Box 790, Pyaphal Tole Kathmandu, Nepal Tel: 13868

Netherlands =

Fluke (Nederland) B.V. Zonnebaan 39 3606 CH Maarssen, The Netherlands P.O. Box 225 3600 AE Maarssen, The Netherlands Tel: (030) 436514, TLX: 47128

New Zealand ●

McLean Information Technology, Ltd. P.O. Box 9464, Newmarket Auckland 1, New Zealand Tel: 501-801; TLX: NZ 215 70 McLean Information Technology, Ltd. P.O. Box 496 Wellington, New Zealand

Tel: 851-450 Nigerla ●

Mofat Engineering Co., Ltd. P.O. Box 6369 Lagos, Nigeria Tel: 960744, TLX: 21353

Norway ■

Morgenstierne & Co A/S Konghellegate 3 P.O. Box 6688, Rodelokka Oslo 5, Norway Tel: (2) 356110, TLX: 71719

Oman ■

OHI Communications P.O. Box 889 Muscat Sultanate of Oman

Pakistan •

Pak International Operations 505 Muhammadi House I.I. Chundrigar Road P.O. Box 5323, Karachi, Pakistan Tel: 221127, TLX: 24494

PDR Yemen ■

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Peru •

Importaciones Y Representaciones Electronicas S A Avda. Franklin D. Roosevelt 105 Lima 1, Peru Tel: 288650, TLX: 37425663

Phillipines •

Spark Radio & Electronics, Inc. P.O. Box 610, Greenhills, San Juan M. Manila, Phillipines, Zip 3113 Tel: 775192 TLX: 27901 RLA PH

Poland =

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Portugal ■

Decada-Equipamentos de Electronica, Lda. Rue Pedro Nunes, 47-C 1000 Lisboa, Portugal P.O. Box 1128, 1003 Lisboa Codex Tel: (19) 574984, TLX: 18469 Oatar #

Technology Organisation P.O. Box 5549, Doha, Qatar Tel: 321431, TLX: 4581

Romania =

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Saudi Arabia ■

Electronic Equipment Marketing Co. P.O. Box 3750 Riyadh, Saudi Arabia Tel: (1) 4783785, TLX: 201120

Singapore •

Rank O'Connor's (PTE) Limited 98 Pasir Panjang Road Singapore 0511 Republic of Singapore Tel: 637944 TLX: OCONSIN RS21023

Somalia =

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

South Africa •

Fluke S.A. (Pty) Ltd. P.O. Box 39797, Bramley 2018 Republic of South Africa Tel: (011) 786-3170, TLX: 424328

Spain ■

Hispano Electronics S.A. Poligono Industrial Urtinsa Apartado de Correos 48 Alcorcon (Madrid), Spain Tel: (1) 6194108 TLX: 22404/42634

Sri Lanka •

Jay-Es Electronics 160 Poorvarama Mawatha Colombo 5, Sri Lanka Tel: 073-2393

Sweden ■

Teleinstrument AB P.O. Box 4490 162 04 Vallingby, Sweden Tel: (8) 380370, TLX: 11347

Switzerland ■ Traco Electronic AG

Jenatschstrasse 1 8002 Zurich, Switzerland Tel: (1) 2010711, TLX: 54318

Syria ■

Mabek (Electronic Division) P.O. Box 4238 Damascus, Syria

Taiwan •

Schmidt Scientific Far East Ltd. 906, Chia Hsin Bldg. 96, Chung Shan N. Rd., Sec. 2 Taipei, Taiwan Tet: 5414600, TLX: 11111

Thailand •

Measuretronix Ltd. 1899/10 Ramkamhaeng Rd. Huamark, Bangkok 24, Thailand Tel: 3143369, TLX: 81143

Tunesia ■

Selep S.A.R.L. 6, Rue de Sparte Tunis - 1000 RP, Tunesia Tel: (1) 248093, TLX: 13030 Turkey ■

Erkman Elektronik Aletler Ticaret Anonim Sirketi Necatibey Cad 92/3 Karakoy, Istanbul, Turkey Tel. (1) 5461 TLX: 23353

United Arab Emirates ■ Al Sanani Trad. Est.

P.O. Box 7187 Abu-Dhabi, United Arab Emírates Tel: 828428/821370/821371/ TLX: 23966

United Kingdom ■

Fluke (Great Britain) Ltd. Colonial Way Watford, Herts, WD2 4TT United Kingdom Tel: (0923) 40511, TLX: 934583 Rapifax: (0923) 25067

Uruguay ●

Coasin Uruguaya S.R.L. Casilia de Correos 1400 Correo Central Montevideo, Uruguay Tel: 29-31-95, TLX: UY5671

U.S.S.R. ■

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

Venezuela •

Coasin, C.A.
Calle 9 Con Calle 4, Edif. Edinurbi
Apartado De Correos
NR-70.136 Los Ruices
Caracas 1070A, Venezuela
Tel: 38-78-42, TLX: 21027

Yemen ■

Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg The Netherlands Tel: (013) 673973, TLX: 52237

Yugoslavia =

Amtest Associates Ltd. Clarence House, 31, Clarence St. Staines, Middlesex TW18 45Y United Kingdom Tel: (784) 63555, TLX: 928855

■ Supplied and Supported by — Fluke (Holland) B.V. P.O. Box 5053, 5004 EB Tilburg Zevenheuvelenweg 53, 5048 AN Tilburg

Tel: (013) 673973, TLX: 52237

The Netherlands

Supplied and Supported by —
Fluke International Corporation
P O. Box C9909
Everett, WA 98206 U.S.A.
Tel: (206) 356-5500
TLX: 152662 JOHN FLUKE EVT



WORLD-WIDE SERVICE ORGANIZATION

North America-Service Centers Supplied & Supported by Fluke, Everett

John Fluke Mig. Co., Inc.

Customer Service Division P D Box C9090 Everett WA 98206 (206) 356-5560

Central Region

3740 Industrial Ave Rolling Meadows, IL 60008 (312) 398-5800

Western Region

2020 N. Lincoln Street Burbank, CA 91504 (213) 849-4641

Eastern Region

P.O. Box 930 Paramus NJ 07652

Fluke Technical Center

2020 N. Lincoln Street Burbank, CA 91504 (213) 849-4641

Fluke Technical Center

2300 Walsh Avenue, Bldg K Santa Clara, CA 95050 (408) 727-8121

Fluke Technical Center

1980 S. Quebec St., Unit 4 Denver, CO 80231 (303) 750-1228

Fluke Technical Center 3740 Industrial Ave. Rolling Meadows, IL 60008 (312) 398-5800

Fluke Technical Center 14400 Midway Road Dallas, TX 75240

(214) 233-9945

Fluke Technical Center 25 "B" Street Burlington, MA 01803 (617) 273-4678

Fluke Technical Center

P O. Box 930 Paramus NJ 07652 (201) 262-9550

Fluke Technical Center

5640 Fishers Lane Rockville, MD 20852 (301) 770-1576

Fluke Technical Center

940 N. Fern Creek Avenue Orlando, FL 32803 (305) 896-2296

Allan Crawford Associates Ltd.

6503 Northam Drive Mississauga Ontario L4V 1J2 (416) 678-1500

Allan Crawford Associates Ltd.

6503 Northam Drive Mississauga Ontario L4V 1J2 (416) 678-1500

Allan Crawford Associates Ltd. #14 1935 30th Ave. N.E.

Calgary Alberta T2E 6Z5 (403) 230-1341

Allan Crawford Associates Ltd.

7918 Cote de Liesse Montreal Quebec H4T 1F? (514) 731-8564

Allan Crawford Associates Ltd.

3795 William Street Burnapy, B.C. V5C 3H3 (604) 294-1326

International Service Representatives Supplied & Supported by Fluke, Everett

Coasin S.A. Virrey del Pino 4071 Buenos Aires, Argentina Tet: 522-5248/3485 TEX: 122284 COASN AR

Elmeasco Instruments Pty Ltd.

P.O. Box 30 Concord, N.S.A. 2137 Australia Tel 02-736-2888 TLX 7902588

Elmeasco Instruments Pty Ltd.

P O Box 107 Mount Waverley Victoria 3149 Austrana Tel 03-233-4044 TLX 36206

Elmeasco Instruments Pty Ltd.

G P O Box 2360 Brisbane Queensland 4001 Australia Tel 07-229-3161

Intronica Chite Ltda.

Manuel Monti 024 - Of D Casilla 16228 Santiago 9. Chile Tel 44940 TLX 240301

Sistemas E Instrumentacion, Ltda.

Carrera 13, No. 37-43, Of. 401 Ap. Aereo 29583 Bogota DE, Colombia SA Tel 232-45-32 TLX 45787 COASN CO

Proteco Coasin Cia., Ltda.

Edificio "Jericho" Avel 12 de octubre #2285 y Ave. Orellana (Planta Baja) Quito Ecuador Tel 529684, 526759 TLX 2865 Protec Ed Cable: PROTECO

Schmidt & Co (H.K.) Ltd.

28th Fl. Wing on Centre 11t Connaught Road Central Hong Kong Tel 5-455644 TLX 74766 SCHMC HX

Hinditron Services Pvt. Ltd.

69/A.L. Jagmohandas Marg Bombay - 400 006, India Tel 811316, 815344 TLX 953-112326 HSPL IN

Hinditron Services Pvt. Ltd.

Field Service Centre 8th Main Boad 33:44-A Raj Maha: Vilas Extr. Bangalore - 560 080, India Tel. 33139 TLX: 0845741

Hinditron Services Pvt. Ltd.

15. Community Centre Panchshila Park New Delbi - 110 017 India Tel: 619118 TLX: 031 4890 SRMP IN

P.T. Dwi Tunggal Jaya Sakti

JI Senen Raya 44 PO Box 4435 Jakarta, Indonesia Tel 376608 367390 TLX 46624 SABBANA IA

Electro-Science Korea Co

CPO Box 8446 Room 201 Boondo Bidg 56-12. Jangchung-1Ka Jung-Ku Seou', Korea Tel 261-7702, 260-1908 TLX K25381

Rank O'Connor's (Malaysia) Sdn. Bhd.

PO Box 91 Petaling Jaya Selangor Wesi Malaysia Tel 566599 TLX OCONOR MA37649 Cable CINECOM PETALING JAYA

Electronica Y Technologia Avanzada, Sa de C.V. (ETA)

Uxmal No. 30 03020 Mexico, D.F. Tel: 520-72-24 y 44 TLX: 1773

McLean Information Technology Ltd.

459 Kyber Pass Road, Newmarke P.O. Box 9464, Newmarket Auckland 1 New Zealand Tel. 501-801, 501-219, 587-037 TLX NZ21570 THERMAL

Pak International Operations

505 Muhammadi House I.I. Chundrigar Road P.O. Box 5323 Karach: Pakistan Tel 221127, 239052 TLX 24494 PIO PK

Importaciones & Representaciones

Electronicas SA Avda Franklin D. Roosevelt 105 Lima 1 Peru TLX 37425663

Spark Radio and Electronics Corp.

P.O. Box 610. Greenhills Metro Manka, Philippines 3113. Tel: 78-78-16 TLX: 27901 RLA PH

Rank O'Connor's (PTE) Limited

98 Pasir Panjang Road Singapore 0511 Republic of Singapore Tel 637944, 239052 TEX OCONSIN RS21023

Schmidt Scientific Far East Ltd.

Taiwan Branch 906, Chia Hsin Building 96 Chung Shan N Road Sec 2 Taipei, Taiwan Tel: 5414616 TLX 11111 Schmidt

Measuretronix Ltd.

1899/10 Ramkamhaeng Rd. Huamark Bangkok 24 Thailand Tel 3143369 3143430 TLX 81143 DEJOBKK TH

Coasin Uruguaya S.R.L.

Cas IIa de Correo N 1400 Correo Central Montevideo Uruquay Tel 29-31-952 TLX UV 6571 OROCUER

Calle 9 Con Calle 4 Edif Edinurbi Apartado de Correus Nr-70 136 Los Ruices Caracas 1070-A, Venezuela Tel 38-78-42, 38-78-86 TLX 21027 EMVEN VE

International-Direct Service Organizations Supplied & Supported by Fluke (Holland) B.V.

Fluke (Holland) B.V.

P.O. Box 5053 5004 EB Tilburg The Netherland Tel. (013) 673973 TLX 52237

Fluke (Belgium) SA/NA

6 Rue de Geneve 1140 Brussels, Belgium Tel: (02) 2164090 TLX. 26312

Fluke (GB) LTD

Colonial Way Watford, Herts WD2 4TT England Tel (0923) 25067 TLX: 934583

Fluke (Deutschland) GmbH

Max-Hueber-Strasse 8 8045 Ismaning/Munchen West Germany Tel: (089) 96050 TLX: 0522472

Fluke (Netherlands) B.V

Zonnebaan 39 P O Box 225 3606 CH Maarssen The Netherlands Tel. (030) 436514 TLX. 47128

Fluke Brasil-Industria E Comercio Ltda.

Al. Amazonas 422 Alphaville, Barueri CEP 06400 Sao Paulo, Brazil Tel: (011) 421-3603 TLX: 01135589 FLKE BR

Beijing Radio Research Institute 89 Dianmen Ave East

Beijing People's Republic of China Tel 445612 John Fluke Mig. Co., Inc. Japan Branch Sumitomo Higashi Shiribashi Bidg 1-1-11 Hamamatsucho Minato-ku Tokyo 105, Japan

Tei (03) 434-0181 TLX. (781) 2424331 (FLUKJPJ)

Fluke S.A. (PTY) Ltd. P.O Box 39797 Bramley 2018 Republic of South Africa Tel (011) 786-3170 TLX 424328

International Service Representatives Supplied & Supported by Fluke (Holland) B.V.

Watter Rekirsch Electronische Gerate

i

GmbH & Co. Vertrieb KG Liechtensteinstrasse 97/6 1090 Vienna, Austria Tel. (0222) 235555 TLX: 134759

Tage Olsen A/S

Ballerup Byveg 222 2750 Ballerup Denmark Tel: (02) 658111 TLX: 35293 TOAS SK

Electronic Engineering Liaison Office

P.O. Box 2891 Horreya Heliopolis Cairo TLX: 92502

Oy Findip A8 Teollisuustie 7 02700 Kaumiainen Finland Tel: (0) 5052255 TLX 123129

M.B. Electronique S.A.

Rue Fourny, P.O. Box 31 78530 BUC, France Tel. (01) 9568131 TLX 695414

Hellenic Scientific Representations

11 Vrassida Street Athens 612, Greece Tel: (01) 711140 TLX: 219330

R.D.T. Electronics Engineering Ltd.

46 Sokolov Street, P.O. Box 75 Ramat Hasharon 47235 Israel Tel (03) 483216 TLX 32143

Sistrel S.p.A.

Via Giuseppe Armellini 37 00143 Rome, Italy Tel: (06) 5915551 TLX 68356

Sistrel S.p.A.

Via Pelizza da Volpedo 59 20092 Cinisello Besamo Milan, Italy Tel (02) 6181893 TLX 334643

Morgenstierne & Co. A/S

Kongheliegate 3 P.O. Box 6688 Rodelokka Oslo 5 Norway Tel. (02) 356110 TLX: 11719

Decada-Equipamentos De Electronica, Lda. Rue Pedro Nunes 47-C

1000 Lisboa P O Box 1128, 1003 Lispoa codex гоныдаг Тег (19) 574984 ТLX 18469 Portuga:

Hispano Electronics S.A.

Apartado de Correos 48 Alcorcon (Madrid), Spain Tel: (01) 6194108 TLX: 22404:42634

P.O. Box 4490 162 04 Vallingby, Sweden Tet (08) 380370 TLX 11346

Teleinstrument AB

Traco Electronic AG Jenatschstrasse 1 8002 Zurich Switzerland Tel. (01) 2010711

Erkman Electronik Aletler

Ticaret Arionim Sirke Necatiby Cad 92:3 Karakoy Islanbul Turkey Tel (01) 546° TLX 23353

TLX 54318



Appendix 7A Manual Change Information

INTRODUCTION

This appendix contains information necessary to backdate the manual to conform with earlier pcb configurations. To identify the configuration of the pcb's used in your instrument, refer to the revision letter (marked in ink) on the component side of each pcb assembly. Table 7A-1 defines the assembly revision levels documented in this manual with an X.

NEWER INSTRUMENTS

As changes and improvements are made to the instrument they are identified by incrementing the revision letter marked on the affected pcb assembly. These changes are documented on a supplemental change/ errata sheet which, when applicable, is inserted at the front of the manual.

OLDER INSTRUMENTS

To backdate this manual to conform with earlier assembly revision levels, perform the changes indicated in Table 7A-1.

CHANGES

There are no backdating changes at this printing. All pcb assemblies are documented at their original revision level.

Ref To adapt manual to earlier rev configurations perform changes Fluke Assembly in desending order (by no.), ending with change under desired rev letter Part Option Name B C D E F G H J K L M N No. No. PU 366245 Main PCB Assembly A1 Х Display PCB Assembly 366278 A2A1 Х --002 Digital Output Unit 366369 Х PCB Assembly -007AC Converter PCB 462846 X Assembly Ohms Converter PCB --008 Х Assembly 456103 -009 True RMS Converter

Х

472449

Table 7A-1. Manual Status and Backdating Information

PCB Assembly

^{*}x = The PCB revision levels documented in this manual.

me These revision letters were never used in the 8810A.

r - F

Section 8 Schematic Diagrams


TABLE OF CONTENTS

FIGURE NO.	TITLE	DRAWING NO.	PAGE
8-1	Al Main PCB Assembly	8800A-1001	8-3
8-2	A2A1 Display PCB Assembly		8-6
8-3	-002 Option, DOU PCB Assembly		8-8
8-4	-007 Option, Ohms Converter PCB Assembly		8-10
8-5	-008 Option, AC Converter PCB Assembly		8-12
8-6	-009 Option, RMS Converter PCB Assembly		8-14

Table 8-1. Mnemonics

F

INT	INTEGRATE
+R	Voltage Reference, Positive
−R	Voltage Reference, Negative
DE	Read Period (Deintegrate)
△ 2	1 Millisecond Settling Period
AZ	Auto Zero Period
CM	Compare
AC	AC Volts Function
β	Low Range Command (Input to U11)
Ω	Ohms Function
α	High Range Command (Input to U11)
DC	DC Volts Function
F	1 MHz Clock Frequency
W-X-Y-Z	(8-4-2-1) Character Serial Display Data
a-b-c	(4-2-1) Range Code
A thru G	Display Segment Bus (See A2A1 Display PCB Schematic)
OL or Q	Overload
RNG1 thru RNG5	Range Commands for selected function
ST1 thru ST6	Strobe 1 through Strobe 6 for range control (manual and auto range)
DS1 thru DS6	Data Strobe 1through Data Strobe 6 to Display PCB LEDs






Figure 8-1. A1 Main PCB Assembly (cont)






Figure 8-1. A1 Main PCB Assembly (cont)









Figure 8-2. A2A1 Display PCB Assembly (cont)











Figure 8-3. -002 Option, DOU PCB Assembly (cont)














GND

NOTES: UNLESS OTHERWISE SPECIFIED.

- I. ALL RESISTANCE VALUES ARE IN OHMS.
- 2. ALL CAPACITANCE VALUES ARE IN MICROFARADS.
- FACTORY SELECTED COMPONENT RSI = 2.7 & NOMINAL

CAUTION
SUBJECT TO DAMAGE BY
STATIC ELECTRICITY

•