

Keysight Technologies

U8903A Audio Analyzer

Creating a Custom Filter for the U8903A Audio Analyzer

Demo Guide



Table of Contents

Demonstration Objectives	2
Step 1: Matlab fdatool (filter design and analysis tool)	3
Step 2: Create Filter	4
Step 3: Export Filter Coefficient	7
Step 4: Settling Time (Delay)	9
Step 5: Transfer to .juf file	11
Step 6: Upload .juf file to U8903A Audio Analyzer	13
Conclusion	14
Ordering Information and Related Literature	15

Demonstration objectives

This demonstration will teach you how to create your own custom filter for the Keysight Technologies, Inc. U8903A Audio Analyzer by using the MATLAB software on your computer.

Steps to create a custom filter

Follow the steps below to create your own custom filter for the U8903A.

Steps

1. Matlab fdatool (filter design and analysis tool)
2. Create Filter
3. Export Filter Coefficient
4. Settling Time (Delay)
5. Transfer to .juf file
6. Upload .juf file to U8903A Audio Analyzer



Step 1

Matlab fdatool (Filter Design and Analysis Tool)

Instructions

1. Start MATLAB program (Figure 1)
2. In the command window, type "fdatool" to start Filter Design and Analysis Tool in MATLAB (Figure 2)




Figure 1. MATLAB command window




Figure 2. Filter Design and Analysis Tool

Step 2

Create filter

Instructions

1. Click on “Set quantization parameter” (Figure 3)
2. Select “Single-precision floating-point” because the architecture of the U8903A is 32 bits (Figure 4)
3. Return to the Design Filter page (Figure 4)




Figure 3. “Set quantization parameter” icon




Figure 4. Selecting “Single-precision floating-point” and “Return to the Design Filter page”

Instructions

4. Select the "Response Type" e.g. Lowpass, Highpass, Bandpass, and Bandstop (Figure 5)
5. Select the "Design Method" e.g. IIR or FIR (Figure 5)
6. Select the "Frequency Specifications" you require e.g. Fpass (1 and 2), Fstop (1 and 2) (Figure 5)

Requirements for Frequency Specifications:

- Low Bandwidth = 78125 Hz
- High Bandwidth = 312500 Hz

7. Select the "Magnitude Specifications" e.g. Wpass (1 and 2), Wstop (1 and 2) (Figure 5)
8. Press the "Design Filter" button (Figure 5)




Figure 5. Selecting "Response Type", "Design Method", "Frequency Specifications", "Magnitude Specification", and Press "Design Filter" Button

Instructions

- The "Order" number (see Figure 6) must be less than 256 in order to meet the architecture of the U8903A Audio Analyzer. Changing the "Design Method" will change the order number.




Figure 6. Order number must be less than 256

Step 3

Export filter coefficient

Export filter coefficient information to a file (figure 7)

Instructions

1. Go to "File", then select "Export..."
2. At "Export To", select "Coefficient File (ASCII)"
3. Click on "Export" button, and Save to *.fcf file
4. The Filter Coefficient Data File will then be displayed




Figure 7. Exporting Filter Coefficient Information to a file

Export filter coefficient as an object for analysis (Figure 8)

- Instructions
1. Go to “File”, then select “Export...”
 2. At “Export To”, select “Workspace”
 3. At “Export As”, select “Object”
 4. At “Variable Names”, for “Discrete Filter”, enter “Hd”, then click the “Export” button
 5. The Hd object is then in the MATLAB window




Figure 8. Export Filter Coefficient as an object for analysis

Step 4

Settling time (Delay)

Knowing the settling time of your filter

You can know the settling time for your filter by creating a 20 Hz Sine Wave for testing the filter you just created using the MATLAB software

Instructions

In the MATLAB command window

1. Type in the code below:
 - fs = 78125
 - f = 20
 - n = 1:65536
 - xn = sin(2*pi*f*n/fs)

These objects (fs, f, n, and xn) are now created in Matlab (Figure 9):

- fs (Frequency Sampling): 78125 for low bandwidth 312500 for high bandwidth
- f(Frequency): 20 Hz
- n(Points): 1 to 65536
- xn (20 Hz Sine wave)

2. Type in the code below to plot the 20 Hz sine wave:
 - plot(xn,'DisplayName','xn','YDataSource','xn');figure(gcf);

A 20 Hz Sine wave graph (Figure 10) is created.




Figure 9. MATLAB command window and objects




Figure 10. 20 Hz Sine wave

Applying filter to the 20 Hz Sine wave

Instructions

In the MATLAB command window

1. Type in the code below to apply filter to 20 Hz sine wave (Figure 11) :
 - `fil=filter(Hd,xn);`

Objects filter is now created in MATLAB

2. Type in the code below to plot the result:
 - `plot(fil,'DisplayName','fil','YDataSource','fil');figure(gcf);`

A 20 Hz Sine wave graph with the filter applied (Figure 12) is created.

3. By zooming into the graph you are able to search for the result (Figure 12)

Result after applying filter with 20 Hz Sine wave:

- Noise level will be fine after 4000 samples




Figure 11. MATLAB command window and objects




Figure 12. Zooming into the graph to see in-depth result

For the IIR Design Method, the transfer to .juf is relatively more complicated compared to the FIR Design Method

Instructions

For Design Method IIR, enter the information below (Figure 15 and 16):

1. '#Type: IIR'

2. '#Delay: ****' (From Settling Time/Delay)

3. "#Sections:"

4. Steps to transferring data:
 - a. Scale Values
 - b. Confirm second part of SOS matrix
 - c. Confirm first part of SOS matrix
 - d. Enter a blank line
 - e. Continue from step a to step d for subsequent Scale Values.





Figure 15. Filter Coefficient Data



Step 6

Upload .juf file to U8903A Audio Analyzer (Figure 17 and 18)

Instructions

1. Copy .juf file to a USB pen drive
 2. Plug the USB pen drive into the U8903A Audio Analyzer
- Steps to upload to the U8903A Audio Analyzer
3. Press “▼” key to access AA1 mode
 4. Press “Meas. Config” softkey
 5. Press “Filter” softkey
 6. Press either “LPF”, “HPF”, or “weighting” softkey
 7. Select “Custom”
 8. Press “Source” softkey
 9. Press “Storage 1” softkey
 10. Select the .juf file and press “Enter” key
 11. The Filter will now be shown on either the LPF, HPF, or Weighting tab depending on your selection




Figure 17. Uploading .juf file and selecting filter




Figure 18. Selecting a source when uploading .juf file to U8903A

Conclusion

Due to differences in the testing environments and standards, general low pass filter, high pass filter, or weighting filter will only satisfy and fulfill some tests. Some users may require some custom filters in order to test DUTs. The U8903A Audio Analyzer provides users the capability to upload their own custom filter. This demonstration will enable users to create their custom filters with a computer using the MATLAB software.

Ordering Information

For further information, refer to *Keysight U8903A Audio Analyzer Quick Fact Sheet*, Literature Number 5990-8504EN.

Related Literature

- *Keysight U8903A Audio Analyzer, Data Sheet*, Literature Number 5990-8499EN
- *Keysight U8903A Audio Analyzer, Quick Start Guide*, Part Number U8903-90032

For the most up-to-date and complete application and product information, visit our product website at: www.keysight.com/find/audioanalyzer

myKeysight

myKeysight

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.



www.axistandard.org

AdvancedTCA® Extensions for Instrumentation and Test (AXIe) is an open standard that extends the AdvancedTCA for general purpose and semiconductor test. Keysight is a founding member of the AXIe consortium. ATCA®, AdvancedTCA®, and the ATCA logo are registered US trademarks of the PCI Industrial Computer Manufacturers Group.



www.lxistandard.org

LAN eXtensions for Instruments puts the power of Ethernet and the Web inside your test systems. Keysight is a founding member of the LXI consortium.



Three-Year Warranty

www.keysight.com/find/ThreeYearWarranty

Keysight's commitment to superior product quality and lower total cost of ownership. The only test and measurement company with three-year warranty standard on all instruments, worldwide.



Keysight Assurance Plans

www.keysight.com/find/AssurancePlans

Up to five years of protection and no budgetary surprises to ensure your instruments are operating to specification so you can rely on accurate measurements.



www.keysight.com/go/quality

Keysight Technologies, Inc.
DEKRA Certified ISO 9001:2008
Quality Management System

Keysight Channel Partners

www.keysight.com/find/channelpartners

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

www.keysight.com/find/audioanalyzer

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

Americas

Canada	(877) 894 4414
Brazil	55 11 3351 7010
Mexico	001 800 254 2440
United States	(800) 829 4444

Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 6375 8100

Europe & Middle East

Austria	0800 001122
Belgium	0800 58580
Finland	0800 523252
France	0805 980333
Germany	0800 6270999
Ireland	1800 832700
Israel	1 809 343051
Italy	800 599100
Luxembourg	+32 800 58580
Netherlands	0800 0233200
Russia	8800 5009286
Spain	800 000154
Sweden	0200 882255
Switzerland	0800 805353
	Opt. 1 (DE)
	Opt. 2 (FR)
	Opt. 3 (IT)
United Kingdom	0800 0260637

For other unlisted countries:
www.keysight.com/find/contactus
(BP-09-23-14)

