


Silkscreen Top

NOTES : Unless Otherwise Specified

1. BREAK BOARDS FROM THE PANEL WHEN ASSEMBLY IS COMPLETE.
2. OPTIONAL COMPONENTS ARE UNSTUFFED AND SHOULD BE FREE OF SOLDER AFTER ASSEMBLY.
3. J1 SHOULD BE FULLY TOUCH WITH THE BOARD EDGE AFTER SOLDERING.

ASSY DRAWING

REVISIONS			
REV	DESCRIPTION	APPR	DATE

APPROVALS		 1630 McCarthy Blvd. Milpitas, CA 95035 PH: (408)432-1900	
DRAWN	INIT	DATE	
CHECK			
DESIGN	JUNE WU	12/13/01	
ENGR	Vladimir D.	12/13/01	
TITLE:		LTC5507ES6 RF Power Detector	
SIZE	A	DC489A	REV. A
SCALE = NONE		DES-260013	
		SHT 1 of 1	